

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

UM-B-141

Abstract

This document outlines the system design, configuration options and supported features of DA14531 SMARTBOND TINY™ MODULE Development Kit, PCB version 376-25-C.

Contents

Abstract	1
1 Terms and Definitions.....	4
2 References	4
3 Introduction.....	5
4 System Overview.....	6
4.1 Features	6
4.2 System and components description	7
4.3 Block Diagram	10
5 DA14531 SmartBond TINY™ Module Daughterboard	11
5.1 Power Section	11
5.1.1 Default Power Supply Option Configuration	11
5.1.2 Optional USB power section.....	12
5.2 Reset operation	12
5.3 General Purpose Buttons.....	12
5.4 General Purpose LEDs	13
5.5 MikroBUS™ Module.....	14
5.6 JTAG	16
5.7 UART.....	17
5.8 GPIOs and pin assignment on DA14531 SMARTBOND TINY™ MODULE DB	17
5.9 Programming and debugging interface setup.....	19
5.9.1 Single wire UART, JTAG, RESET	20
5.9.2 2-wire UART, JTAG, RESET	21
5.9.3 4-wire UART, JTAG, RESET	21
5.10 First Steps with DA14531 SMARTBOND TINY™ MODULE DEVKIT	23
Appendix A.....	25
A.1 Schematic	25
A.2 Placed Components.....	26
Revision History	27

Figures

Figure 1: DA14531 SMARTBOND TINY™ MODULE DB	5
Figure 2: DA14531 SMARTBOND TINY™ MODULE DEVKIT	6
Figure 3: Component description. Top side.	7
Figure 4: Component description. Bottom side.	8
Figure 5: DA14531 SMARTBOND TINY™ MODULE DB Block Diagram	10
Figure 6: Power option selection for DA14531 SMARTBOND TINY™ MODULE DB	11
Figure 7: Power option default configuration.....	11
Figure 8: Optional USB power supply section.....	12
Figure 9: Reset Button on DA14531 SMARTBOND TINY™ MODULE DB.....	12
Figure 10: General purpose push buttons on DA14531 SMARTBOND TINY™ MODULE DB	13
Figure 11: Default general purpose push button (SW2) on DA14531 SMARTBOND TINY™ MODULE DB.....	13
Figure 12: SW2 configuration on DA145xx DEVKT-P PRO-MB	13

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

Figure 13: General Purpose LEDs on DA14531 SMARTBOND TINY™ MODULE DB	14
Figure 14: Default LED on DA14531 SMARTBOND TINY™ MODULE DB	14
Figure 15: D5 LED configuration on DA145xx DEVKT-P PRO-MB	14
Figure 16: Default programming interface of MikroBUS™ module on DA14531 SMARTBOND TINY™ MODULE DB	15
Figure 17: MikroBUS™ module Socket on DA14531 SMARTBOND TINY™ MODULE DB	15
Figure 18: Example of mounting MikroBUS™ module.....	16
Figure 19: Optional debug port.....	16
Figure 20: DA145xx DEVKT-P PRO-MB jumper setup for Single wire UART, JTAG and RESET operation.....	20
Figure 21: DA145xx DEVKT-P PRO-MB jumper setup for 2-wire UART, JTAG and RESET operation	21
Figure 22: DA145xx DEVKT-P PRO-MB jumper setup for 4-wire UART, JTAG and RESET operation	22
Figure 23: DA145xx DEVKT-P PRO-MB First Steps Jumper Configuration with DA14531 SMARTBOND TINY™ MODULE DB attached	23
Figure 24: Schematic of DA14531 SMARTBOND TINY™ MODULE DB [376-25-C].....	25
Figure 25: Components on top and bottom sides for DA14531 SMARTBOND TINY™ MODULE DB [376-25-C].....	26

Tables

Table 1: Test Points Description	8
Table 2: MikroBUS™ GPIOs multiplexing.....	15
Table 3: JTAG signals assignment.....	16
Table 4: DA14531 SMARTBOND TINY™ MODULE DB UART Signals	17
Table 5: GPIO multiplexing on DA14531 SMARTBOND TINY™ MODULE DB.....	17
Table 6: Power, SPI Flash and programming/debugging jumper setup of DA145xx DEVKT-P PRO-MB for TINY™ MODULE	19
Table 7: Pin assignment for DA14531 SMARTBOND TINY™ MODULE Configuration 1	20
Table 8: Pin assignment for DA14531 SMARTBOND TINY™ MODULE configuration 2	21
Table 9: Pin assignment for DA14531 SMARTBOND TINY™ MODULE configuration 3	21

1 Terms and Definitions

DEVKIT	Development Kit
DB	Daughterboard
USB	Universal Serial Bus
JTAG	Join Test Action Group
UART	Universal Asynchronous Receiver-Transmitter
SDK	Software Development Kit
SoC	System on Chip
GPIO	General Purpose Input Output
LDO	Low Dropout
QSPI	Quad Serial Peripheral Interface
SPI	Serial Peripheral Interface
I ² C	Inter-Integrated Circuit
SMD	Surface-Mount Device
PCB	Printed Circuit Board

2 References

- [1] UM-B-114, DA14531_Devkit_Pro_Hardware_User_manual, Revision 1.1, Dialog Semiconductor.
- [2] DA14531MOD_Datasheet_v1.0, Datasheet, Revision 1.0, Dialog Semiconductor.
- [3] DA14531_datasheet_3v0, Datasheet, Revision 3.0, Dialog Semiconductor

3 Introduction

This document describes the DA14531 SMARTBOND TINY™ MODULE Development Kit. The development kit is implemented on a single Daughterboard (DB) PCB and it comes with DA145xx DEVKT-P PRO-MB for SW development, programming, debugging and measuring current but also can be used stand alone.

The block diagram, the actual board, the various sections and settings as well as the connectivity are presented. The purpose of this Daughterboard is to provide users with the capability for:

- Access to the DA14531 SMARTBOND TINY™ MODULE, via UART or JTAG
- Connecting MikroBUS™ module
- User access to general purpose LED(s)
- User access general purpose button(s)
- Reset button
- Test points for all output signals
- Stand-alone operation



Figure 1: DA14531 SMARTBOND TINY™ MODULE DB




Figure 2: DA14531 SMARTBOND TINY™ MODULE DEVKIT

4 System Overview

4.1 Features

The features of DA14531 SMARTBOND TINY™ MODULE DB include:

- Integrated Dialog Semiconductor DA14531 SMARTBOND TINY™ MODULE
- Reset push button (SW3)
- A set of general-purpose LED and button (LED1 and SW2)
- Supply from VLDO (3V) from DA145xx DEVKT-P PRO-MB or from coin cell battery
- Capability of mounting a MikroBUS™ module (J3, J4)
- JTAG and UART interface over DA145xx DEVKT-P PRO-MB
- JTAG and UART interface over on-board header (J2)
- Stand-alone operation
- A dimension of 58.43x44.46 mm
- Optional features:
 - Power supply option from USB connector (only for power not for debugging). User must solder the components.

- ## 4.2 System and components description



1. DA14531 SMARTBOND TINY™ MODULE (U1)
2. Reset button (SW3/RESET)
3. General purpose LED (D2)
4. General purpose button (SW2)
5. JTAG debugger connector (J2)
6. GND pad (TP26)
7. Power supply configuration resistor (VLDO of PRO-MB/ Coin cell battery or USB)
8. MikroBUS™ connection points (J3, J4)
9. MikroBUS™ configuration resistors for I²C interface
10. MikroBUS™ configuration resistors for SPI interface

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

11. Power switch (SW4). Selection between VLDO from PRO-MB/ Coin cell battery or USB power supply. **Optional.**
12. USB power supply section with OVP circuit. **Optional.**
13. Jumper header for LED isolation(J5). **Optional.**
14. General purpose button (SW1). **Optional.**
15. General purpose LED (D1). **Optional.**
16. Mating connector on the PCB (J1).




Figure 4: Component description. Bottom side.

The bottom side of the kit provides battery case for a CR2032 coin cell battery. Test points have been placed for monitoring various signal behaviors and voltage levels of the components. The marked and numbered sections of the system are:

17. Coin cell battery (BT1)
18. Test points (see Table 1 for more details)
19. Dialog label

Table 1: Test Points Description

Test Point	Assigned to	Comments
TP1	FIDUCIAL	Not electrically connected
TP2	FIDUCIAL	Not electrically connected
TP3	GND	Ground
TP7	SWCLK	JTAG Interface- Clock Signal
TP8	VLED1	Voltage level of RED LED (D1)
TP9	SWDIO	JTAG Interface DIO Signal

DA14531 SMARTBOND TINY™ MODULE Development
Kit Hardware User Manual

Target

Test Point	Assigned to	Comments
TP10	VLED2	Voltage Level of Green LED (D2)
TP12	RESET	Reset
TP13	SW1	General purpose button (driven from P0_6 signal)
TP14	SW2	General purpose button (driven from P0_11 signal)
TP15	SW3	Reset button (driven from P0_0 signal)
TP16	MikroBUS™ LOGO	Not electrically connected
TP18	5V	USB +5V voltage level after OVP circuit
TP19	VBUS_IN	USB +5V voltage level
TP20	VLDO	LDO (U2) 3.3V output voltage level
TP21	VBAT_MOD	Power supply rail of DA14531 SMARTBOND TINY™ MODULE
TP22	VBAT	Power supply rail of VLDO of DA145xx DEVKT-P PRO-MB or external coin cell battery
TP23	ESD_WARNING SIGN	Not electrically connected
TP24	GND	Ground
TP25	GND	Ground
TP26	GND	Ground
TP27	URX	4-wire UART RX Signal
TP28	UTX	4-wire UART TX Signal
TP29	UCTS	4-wire UART CTS Signal
TP30	URTS	4-wire UART RTS Signal

4.3 Block Diagram




Figure 5: DA14531 SMARTBOND TINY™ MODULE DB Block Diagram

5 DA14531 SmartBond TINY™ Module Daughterboard

5.1 Power Section

The power supply on the DA14531 SMARTBOND TINY™ MODULE DB supports three options:

- Power supply from DA145xx DEVKT-P PRO-MB. The supply voltage comes from VLDO setup (U5) with output voltage range to meet recommended operating conditions of DA14531 SmartBond TINY™ Module. See [2] for recommended operating conditions and Table 6 for VLDO selection.
- Power supply from Coin cell battery (BT1). Battery case is mounted on bottom side of the daughterboard. **Notice: User must not mount coin cell battery when daughterboard is supplied from DA145xx DEVKT-P PRO-MB.**
- +5V USB Power Supply (J6 connector) with Over Voltage Protection Circuit (OVP). **Optional.**

Using power supply from VLDO of DA145xx DEVKT-P PRO-MB, allows user to measure Current drawn from the DA14531 SmartBond TINY™ Module by using the current sensing circuit and the power profiler of Dialog's SmartSnippets Toolbox. For more information regarding current measurement refer to [1].

5.1.1 Default Power Supply Option Configuration

Power selection between DA145xx DEVKT-P PRO-MB VLDO/ Coin Cell battery and USB Power Supply is done in two ways:

- Using resistors R41, R42:
 - R41 - Power supply from DA145xx DEVKT-P PRO-MB / Coin Cell. **Default configuration.**
 - R42 - VLDO (3.3V) of USB power section. **Optional.**
- Using SW4 power switch. **Optional.**




Figure 6: Power option selection for DA14531 SMARTBOND TINY™ MODULE DB




Figure 7: Power option default configuration

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

5.1.2 Optional USB power section

USB power section consists of the following parts:

- Mini Type B USB connector (J6)
- OVP circuit
- LDO (3.3V) regulator (U2)

USB power section is not populated.




Figure 8: Optional USB power supply section

5.2 Reset operation

Reset operation on the DA14531 SMARTBOND TINY™ MODULE can be activated with one of the following ways:

- By pressing the on board RESET button (SW3)
- Through software from the UART & JTAG interface of DA145xx DEVKT-P PRO-MB
- By pressing RESET button on DA145xx DEVKT-P PRO-MB (SW1)

Reset signal is connected to P0_0.




Figure 9: Reset Button on DA14531 SMARTBOND TINY™ MODULE DB

5.3 General Purpose Buttons

Push button SW2 is populated and placed on top side of the board (Figure 11). It is connected to P0_11 (Figure 10) and shares the same configuration with SW2 button of DA145xx DEVKT-P PRO-MB (SW2 is connected to P3_1 on the motherboard which is P0_11 on DA14531). See Figure 12.

SW1 is not populated (Figure 11). It is connected to P0_6 (Figure 10).




Figure 10: General purpose push buttons on DA14531 SMARTBOND TINY™ MODULE DB




Figure 11: Default general purpose push button (SW2) on DA14531 SMARTBOND TINY™ MODULE DB




Figure 12: SW2 configuration on DA145xx DEVKT-P PRO-MB

5.4 General Purpose LEDs

LED D2 is a general-purpose LED and it is driven by P0_9. LED D2 shares same configuration as LED D5 of DA145xx DEVKT-P PRO-MB (D5 is driven by P1_0 of motherboard which is P0_9 of DA14531). See Figure 15.

LED D1 is driven by P0_8 and it is not populated. User can mount a LED like D2.

General purpose LEDs circuitry is completed with Jumper header J5. J5 is optional and it isolates signals P0_8 and P0_9 when LEDs function is not used, so signals can be directed to other functions.

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

Header J5 by default is not populated. Instead resistors R39 and R40 are used in order to configure the connection of LEDs to the signals (Figure 13, Figure 14).




Figure 13: General Purpose LEDs on DA14531 SMARTBOND TINY™ MODULE DB




Figure 14: Default LED on DA14531 SMARTBOND TINY™ MODULE DB




Figure 15: D5 LED configuration on DA145xx DEVKT-P PRO-MB

5.5 MikroBUS™ Module

The DA14531 SMARTBOND TINY™ MODULE DB can support MikroBUS™ modules. It requires some level of GPIOs multiplexing to avoid conflict with other functions driven by same GPIOs.

A MikroBUS™ module requires a power supply of 5V, 3.3V or both, depending on the module. The current configuration of the daughterboard supports only 3.3V. If a voltage of 5V is required, then USB power section needs to be populated.

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

Signals available for MikroBUS™ module can be seen in the Table 2. I²C signals and INT are the default configuration for the MikroBUS™ module. For SPI interface and RST additional resistors must be populated (Figure 16, Figure 17).

DA14531 SMARTBOND TINY™ MODULE DB MikroBUS™ doesn't share same GPIO signals as DA145xxx DEVKT-P PRO-MB MikroBUS™.




Figure 16: Default programming interface of MikroBUS™ module on DA14531 SMARTBOND TINY™ MODULE DB




Figure 17: MikroBUS™ module Socket on DA14531 SMARTBOND TINY™ MODULE DB

Table 2: MikroBUS™ GPIOs multiplexing

DA14531 SMARTBOND TINY™ MODULE GPIOs	Peripherals	MikroBUS™		
		I ² C	SPI	Other
P0_6	SW1		SCK	
P0_11	SW2	SDA (default)	MISO	
P0_8	LED D1	SCL (default)	CS	
P0_9	LED D2		MOSI	
P0_7				INT (default)
				RST



DA14531 SMARTBOND TINY™ MODULE DB provides JTAG interface with SWDIO and SWCLK signals assigned to P0_2 and P0_10 (Table 3). JTAG signals are also available on header J2 (Figure 19).

Function		The Signals	
		DA145xx DEVKT-P PRO-MB	DA14531 SMARTBOND TINY™ MODULE DEVKIT
Enabled by Jumpers (on PRO-MB)		J2	DA14531 SMARTBOND TINY™ MODULE
SW_CLK	J1:21-22 (Default)	SWCLK	P0_2
SW_DIO	J1:23-24 (Default)	SWDIO	P0_10



5.7 UART

Three modes of UART can be used: single wire UART, 2 wire-UART or full UART.

Table 4: DA14531 SMARTBOND TINY™ MODULE DB UART Signals

Function		The signals		
		DA145xx DEVKT-P PRO-MB		DA14531 SMARTBOND TINY™ MODULE DB
		J2	J1	DA14531 SMARTBOND TINY™ MODULE
UTX	2-wire or Full UART Transmit	P2_6	P0_4	P0_6
URX	2-wire or Full UART Receive	P2_5	P0_5	P0_5
UCTS	2-wire or Full UART Clear to Send	P2_8	P0_6	P0_8
URTS	2-wire or Full UART Request to Send	P2_7	P0_7	P0_7
RxTx	Single wire UART Receive and Transmit	P2_5	P2_5	P0_5

Note 1 UART signals are directly mapped to J1 connector of DA145xx DEVKT-P PRO-MB: Rx, Tx, RTS and CTS.

For enabling the different configurations check section 5.8.

5.8 GPIOs and pin assignment on DA14531 SMARTBOND TINY™ MODULE DB

The DA14531 SMARTBOND TINY™ MODULE DB comes in with a pre-defined default configuration. However, due to the low GPIO pin count, several functions are multiplexed and can be enabled as needed.

On Table 5 DA14531 SMARTBOND TINY™ MODULE GPIOs use on the various functions can be found. On the last column of the table users can check which of the functions are enabled by default with the default hardware setup and which require some hardware modification by adding resistors.

Table 5: GPIO multiplexing on DA14531 SMARTBOND TINY™ MODULE DB

DA14531 SMARTBOND TINY™ MODULE Signals	J1 connector Daughterboard	Function 1	Function 2	Function 3	Comments for functions supported		
P0_0		SW3 (RESET Button)				Default	
	MB2_0						
	RESET		RESET on J2 JTAG connector		Default		Default
P0_2							
	MB2_2						
	SWCLK		SWCLK JTAG connector (J2)		Default		Default

**DA14531 SMARTBOND TINY™ MODULE Development
Kit Hardware User Manual**

Target

DA14531 SMARTBOND TINY™ MODULE Signals	J1 connector Daughterboard	Function 1	Function 2	Function 3	Comments for functions supported		
P0_5				URX (2-wire) on JTAG connector (J2)			R36
	MB2_5		RxTx (1-wire UART)			Default	
	MB0_5	URx (4- wire UART)			Default		
P0_6		SW1 (User button)	UTx (2-wire) on JTAG connector (J2)	MikroBUS™ SCK	R7, SW1	R35	R13
	MB2_6						
	MB0_4	UTx (4- wire UART)			Default		
P0_7			MikroBUS™ RST	MikroBUS™ INT		R10	Default
	MB2_7						
	MB0_7	URTS (4- pin UART)			Default		
P0_8		RED LED (D1)	MikroBUS™ CS	MikroBUS™ SCL	D1, R1, R39 or J5	R11	Default
	MB2_8						
	MB0_6	UCTS (4- pin UART)			Default		
P0_9		GREEN LED (D2)	MikroBUS™ MOSI		Default	R16	
	MB2_9						
P0_10	MB3_0						
	SWDIO		SWDIO JTAG connector (J2)			Default	
P0_11		SW2 (User button)	MikroBUS™ MISO	MikroBUS™ SDA	Default	R14	Default
	MB3_1						

5.9 Programming and debugging interface setup

On this section the settings required for configuring the PRO-MB development kit for DA14531 SMARTBOND TINY™ MODULE are described:

- DA14531 SMARTBOND TINY™ MODULE DB
- DA145xx DEVKT-P PRO-MB

Configurations applied by adding/removing jumpers on the DA145xx DEVKT-P PRO-MB. No modification is required on the DA14531 SMARTBOND TINY™ MODULE DB.

Please notice that the SPI flash on DA145xx DEVKT-P PRO-MB will not be used as DA14531 SMARTBOND TINY™ MODULE has integrated QSPI Flash. See Table 6.

The settings of three configurations are presented:

- Configuration 1: Single wire UART, JTAG and RESET
- Configuration 2: UART (2 wires), JTAG and RESET
- Configuration 3: Full UART, JTAG and RESET

Table 6: Power, SPI Flash and programming/debugging jumper setup of DA145xx DEVKT-P PRO-MB for TINY™ MODULE

Device		Configuration	Setting	Comments
DA145xx DEVKT-P PRO-MB	SPI Data Flash	Use SPI Data Flash of DA14531 SMARTBOND TINY™ MODULE	Remove J1: 1-2 J1: 3-4 J1: 5-6 J1: 7-8 J1: 9-10	Remove jumpers from J1 connector that enable PRO-MB SPI Data Flash
	Voltage provided to DA14531 (VLDO)		J9:1-2 J9:3-4	Current sense circuit of PRO-MB
		1.8V	J5:1-3	Default voltage for TINY™ MODULE
		3.0V	J5:2-4	
		3.3V	J5:1-3 J5:2-4	
	DA14531 DCDC configuration	Buck	J4:3-4	Power mode of TINY™ MODULE
	Programming/debugging interface	Single wire UART	J1:19-20 J10:1-J1:15 J10:2-J1:17	
		2-wire UART	J1:15-16 J1:17-18	
		4 wire UART	J1:11-12 J1:13-14 J1:15-16 J1:17-18	

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

Device		Configuration	Setting	Comments
		JTAG	J1:21-22 J1:23-24	
		RESET	J1:25-26	

5.9.1 Single wire UART, JTAG, RESET

Table 7: Pin assignment for DA14531 SMARTBOND TINY™ MODULE Configuration 1

Configuration	P0_0	P0_2	P0_5	P0_10
1 JTAG & single UART	Reset	SWLCK	RxTx	SWDIO




Figure 20: DA145xx DEVKT-P PRO-MB jumper setup for Single wire UART, JTAG and RESET operation

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

5.9.2 2-wire UART, JTAG, RESET

Table 8: Pin assignment for DA14531 SMARTBOND TINY™ MODULE configuration 2

Configuration	P0_0	P0_2	P0_6	P0_5	P0_10
2 JTAG & 2 wire UART	Reset	SWLCK	Tx	Rx	SWDIO




Figure 21: DA145xx DEVKT-P PRO-MB jumper setup for 2-wire UART, JTAG and RESET operation


5.9.3 4-wire UART, JTAG, RESET

Table 9: Pin assignment for DA14531 SMARTBOND TINY™ MODULE configuration 3

Configuration	P0_0	P0_2	P0_6	P0_5	P0_7	P0_8	P0_10
3 JTAG & 2 wire UART	Reset	SWLCK	Tx	Rx	RTS	CTS	SWDIO

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target



DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

5.10 First Steps with DA14531 SMARTBOND TINY™ MODULE DEVKIT

The DA145xx DEVKT-P PRO-MB as well as DA14531 SMARTBOND TINY™ MODULE DB come in with a pre-defined default configuration. The initial steps that must be taken when the Daughterboard is mounted on the PRO-MB are depicted in Figure 23.




Figure 23: DA145xx DEVKT-P PRO-MB First Steps Jumper Configuration with DA14531 SMARTBOND TINY™ MODULE DB attached

Steps to be followed:

1. Remove SPI Data Flash Jumpers J1 1:2, 3:4, 5:6, 7:8, 9:10
2. Remove J5 1:3 header (LDO(U5) output at 3.0V)

3. Leave J1 21:22, 23:24, 25:26 for RESET, JTAG
4. Leave J9 1:2,3:4 (current measurement circuit)
5. Leave J4 3:4 (Buck mode)
6. Leave J8 as is (in case a MikroBUS™ module is used J8 is advised to be removed)
7. Leave J19 as is (in case a MikroBUS™ module is used J19 2:3 is advised to be removed)
8. Configure UART operation as per configuration 1, 2 or 3

Appendix A

A.1 Schematic




Figure 24: Schematic of DA14531 SMARTBOND TINY™ MODULE DB [376-25-C]

A.2 Placed Components




Figure 25: Components on top and bottom sides for DA14531 SMARTBOND TINY™ MODULE DB [376-25-C]

Revision History

Revision	Date	Description
<>	<DD-Mmm-YYYY>	<Latest revision. Summary of important changes.>
Change details:		
1.0	10-04-2020	Initial version.

DA14531 SMARTBOND TINY™ MODULE Development Kit Hardware User Manual

Target

Status Definitions

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

Disclaimer

Unless otherwise agreed in writing, the Dialog Semiconductor products (and any associated software) referred to in this document are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of a Dialog Semiconductor product (or associated software) can reasonably be expected to result in personal injury, death or severe property or environmental damage. Dialog Semiconductor and its suppliers accept no liability for inclusion and/or use of Dialog Semiconductor products (and any associated software) in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Information in this document is believed to be accurate and reliable. However, Dialog Semiconductor does not give any representations or warranties, express or implied, as to the accuracy or completeness of such information. Dialog Semiconductor furthermore takes no responsibility whatsoever for the content in this document if provided by any information source outside of Dialog Semiconductor.

Dialog Semiconductor reserves the right to change without notice the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications. Notwithstanding the foregoing, for any automotive grade version of the device, Dialog Semiconductor reserves the right to change the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications, in accordance with its standard automotive change notification process.

Applications, software, and semiconductor products described in this document are for illustrative purposes only. Dialog Semiconductor makes no representation or warranty that such applications, software and semiconductor products will be suitable for the specified use without further testing or modification. Unless otherwise agreed in writing, such testing or modification is the sole responsibility of the customer and Dialog Semiconductor excludes all liability in this respect.

Nothing in this document may be construed as a license for customer to use the Dialog Semiconductor products, software and applications referred to in this document. Such license must be separately sought by customer with Dialog Semiconductor.

All use of Dialog Semiconductor products, software and applications referred to in this document is subject to Dialog Semiconductor's [Standard Terms and Conditions of Sale](#), available on the company website (www.dialog-semiconductor.com) unless otherwise stated.

Dialog, Dialog Semiconductor and the Dialog logo are trademarks of Dialog Semiconductor Plc or its subsidiaries. All other product or service names and marks are the property of their respective owners.

© 2020 Dialog Semiconductor. All rights reserved.

RoHS Compliance

Dialog Semiconductor's suppliers certify that its products are in compliance with the requirements of Directive 2011/65/EU of the European Parliament on the restriction of the use of certain hazardous substances in electrical and electronic equipment. RoHS certificates from our suppliers are available on request.

Contacting Dialog Semiconductor

United Kingdom (Headquarters)

Dialog Semiconductor (UK) LTD
Phone: +44 1793 757700

Germany

Dialog Semiconductor GmbH
Phone: +49 7021 805-0

The Netherlands

Dialog Semiconductor B.V.
Phone: +31 73 640 8822

Email:

enquiry@diasemi.com

North America

Dialog Semiconductor Inc.
Phone: +1 408 845 8500

Japan

Dialog Semiconductor K. K.
Phone: +81 3 5769 5100

Taiwan

Dialog Semiconductor Taiwan
Phone: +886 281 786 222

Web site:

www.dialog-semiconductor.com

Hong Kong

Dialog Semiconductor Hong Kong
Phone: +852 2607 4271

Korea

Dialog Semiconductor Korea
Phone: +82 2 3469 8200

China (Shenzhen)

Dialog Semiconductor China
Phone: +86 755 2981 3669

China (Shanghai)

Dialog Semiconductor China
Phone: +86 21 5424 9058

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Dialog Semiconductor:](#)

[DA14531MOD-00F1DB-P](#) [DA14531MOD-00DEVKT-P](#)