

# Ethernet Plus USB Applications Based on the MCF52259

## HTTP/TFTP Server Plus USB Mass Storage Host

by: Li Kan  
32-Bit Application Team

## 1 Introduction

This application note describes implementation of a HTTP/TFTP server based on the ColdFire MCF5225x processor with a USB file system where web pages or other files are stored. It details how to integrate a USB stack with a NicheTask and accessing the USB file system through a HTTP/TFTP server.

## 2 MCF52259

The MCF52259 is a highly-integrated 32-bit microcontroller based on the V2 ColdFire micro-architecture. Featuring 64 Kbytes of internal SRAM, 512 Kbytes of flash memory, a fast Ethernet controller, a USB on-the-go controller, an external bus interface, four 32-bit timers, a 4-channel DMA controller, two IIC modules, three UARTs, and a queued SPI. The MCF52259 family has been designed for general-purpose industrial control applications.

### Contents

1	Introduction .....	1
2	MCF52259.....	1
3	Stack .....	2
3.1	Interniche.....	2
3.2	CMX USB-Lite.....	2
4	HTTP Server Implementation .....	2
4.1	Project Archtecture .....	2
4.2	Implementation .....	3
4.3	Running HTTP Web Server on the MCF52259EVB	8
4.4	Connecting to the Web Page on the USB Flash ..	8
5	TFTP Server Implementation .....	10
5.1	Software Architecture .....	10
5.2	Implementation .....	10
5.3	Project Compile .....	12
5.4	Running the TFTP Server on the MCF52259EVB.	12
5.5	Uploading a File to TFTP Server .....	13
5.6	Downloading a File from TFTP Server .....	14
6	Conclusion.....	15

## 3 Stack

The applications detailed in this document use the fast ethernet controller and USB on-the-go controller receiving full support from the InterNiche and CMX.

### 3.1 InterNiche

This ColdFire® TCP/IP stack is a public source stack provided for use with the ColdFire line of processors. It can be divided into two parts; a mini-TCP layer library and a mini-IP layer library. It also includes a virtual file system (VFS) that supports the american standard code for information interchange (ASCII) and binary data, integrated with a round-robin tasking system named NicheTask. For more details on the ColdFire TCP/IP stack refer to application notes *AN3470—ColdFire TCP/UDP/IP Stack and RTOS* and *AN3455—ColdFire Lite HTTP Server*.

### 3.2 CMX USB-Lite

The CMX USB-Lite is provided by Freescale and CMX for ColdFire and S08 USB microcontrollers. It supports a USB device, host, and on-the-go (OTG) functionality to meet various design requirements. Included are high-level class drivers for keyboards, mouse devices, and generic human interface devices (HID). Communication device classes (CDC) to universal asynchronous receivers and transmitters (UART) provide communication between UART and USB (mass storage demos for the host mode). The stacks can be accessed at [www.freescale.com/USB](http://www.freescale.com/USB).

## 4 HTTP Server Implementation

### 4.1 Project Architecture

This project is created with CodeWarrior 7.0. The architecture is listed in [Table 1](#).

**Table 1. HTTP Web Server Project Architecture**

Module	Description
CodeWarrior specific	Linker file for the M52259EVB.
ColdFirelite	InterNiche stack containing multiple folders for the Ethernet TCP/IP stack, supported protocols, and RTOS processor independent files.
Common	Standard C functions and UART input and output support.
CPU	Contains respective processor dependent files.
Drivers	Drivers for MII interface.
Freescale_Web_Server	Applications for HTTP web server.
Project files	Main and interrupts source files.
CMXUSB_LITE	CMX USB stack containing multiple folders for USB mass host support.

## 4.2 Implementation

This project is implemented based on the *MCF52259EVB*.

### 4.2.1 Integration of InterNiche and CMX USB Stack

In this project InterNiche is used to manage network protocols and the CMX stack is used to manage file operations based on the USB file system. The key point of this project is to combine the two stacks to work concurrently.

#### 4.2.1.1 Creating usb-mass-host-task.c for NicheTask

The InterNiche also provides a RTOS named NicheTask which is a cooperative multi-tasking scheduler. In this architecture each task has its own call-stack. Voluntarily manages control back to the master scheduler. The integrating method is to invoke APIs from CMX stack as tasks through the NicheTask. This is achieved by a source file named `usb-mass-host-task.c` where a state machine is created for a USB mass host. This file provides several APIs for a NicheTask listed in [Table 2](#).

**Table 2. CMX APIs for InterNiche**

Function	Description
<code>void demo_process(void)</code>	State machine for the usb mass host
<code>int cmd_dir(void * pio)</code>	Commands for struct <code>menu_op* usbmassmenu</code>
<code>int cmd_dump(void * pio)</code>	
<code>int cmd_type(void * pio)</code>	
<code>TK_ENTRY(tk_cmxmasshosttask)</code>	Task object defined by nicheTask, using APIs from CMX-USB-LITE and InterNiche
<code>void create_cmxusb_task( void )</code>	Add CMX task the NicheTask's TCB table and gets executed once per loop

#### 4.2.1.2 Invoking APIs from the `usb-mass-host-task.c` in NicheTask

In `usb-mass-host-task.c` a function named `create_cmxusb_task()` is created to support NicheTask. It is invoked in the task object `tk_keyboard` that supports the standard I/O in NicheTask and added to the task control block (TCB) table after reset.

```
TK_ENTRY( tk_keyboard )
{
    for ( ; ; )
    {
        TK_SLEEP(1);                                /* make keyboard yield some time */
        kbdio();                                     /* let Iniche menu routines poll for char */
        keyboard_wakes++;                            /* count wakeups */
        #ifdef MCF52259
        if((usbmst_attach == 1)&&(usbtok_created == 0))
        {
            create_cmxusb_task();
            usbtok_created = 1;
        }
        else if((usbmst_attach == 0)&&(usbtok_created == 1))
        {
            /* do nothing */
        }
    }
}
```

```

    {
        tk_kill(to_cmxmasshosttask);
        usbtask_created = 0;
    }
#endif
if (net_system_exit)
    break;
}
TK_RETURN_OK();
}
}

```

#### 4.2.1.3 Adding a Timer for Integration from CMX and OS

NicheTask tk\_sleep(tick) is used to delay tasks and in the CMX host\_ms\_delay(ms) is used for almost the same purpose. The time delayed is different between them. One tick equals 5 ms. For integration, host\_ms\_delay(ms) is replaced with tk\_sleep(tick) and modified in the usb\_host.c.

```

void host_ms_delay(hcc_u32 delay)
{
#ifdef MCF52259
    delay/=5;          // 5 ms is used for 1 tick
    delay+=1;          //there might be a decimal fraction cut as 0 after the division, add 1
    tk_sleep(delay);
#else
    start_mS_timer((hcc_u16)delay);
    do {
    } while(!check_mS_timer());
#endif
}

```

#### 4.2.2 Adding File Operation for the USB File Type

The Freescale\_Web\_Server module file operation supports only html and text files. In this project web pages can be stored in the USB device. Therefore, a new file type definition is added in freescale\_http\_server.h that supports a USB file type named FILE\_TYPE\_DYANMIC3.

```

// File types scanned for dynamic HTML content
#define FILE_TYPE_DYANMIC1          'html'
#define FILE_TYPE_DYANMIC2          'text'
#ifdef MCF52259
#define FILE_TYPE_DYANMIC3          'usbf'
#endif

```

The function emg\_web\_open() is used to open web pages. Codes are now inserted in it to support the new file type defined as FILE\_TYPE\_DYANMIC3. To avoid destroying the original code structure, the inserted codes are enclosed by a macro defined as MCF52259\_MST.

```

void emg_web_open( unsigned char session, unsigned char *filename )
{
...
#endif
#ifdef MCF52259_MST
if(usbmst_attach == 1)
{
    F_FIND find;
    int ret;
    volatile unsigned char* fname;

```

```

F_FILE *file;

if(filename[0] == 0)
    fname = (volatile unsigned char*)"index.htm";
else
    fname = filename;
#if HTTP_VERBOSE>4
    printf("open session %d, %s\n\r", session, fname);
#endif
file=f_open((const char*)fname, "r");
if(file!=0)
{
    freescale_http_sessions[session].file_type = FILE_TYPE_DYNAMIC3;
    freescale_http_sessions[session].file_size = f_filelength((const char*)fname);
    freescale_http_sessions[session].file_pointer =(void *)file; //used here is a file pointer
    to pass the file handle
    freescale_http_sessions[session].file_index = 0;
    freescale_http_sessions[session].state = EMG_HTTP_STATE_SEND_FILE;
    found = 1;
    return;
}
}//if(usbmst_attach == 1)
#endif
...
}

```

The html/text file read operation is supported by a function named emg\_web\_read(). A function named usb\_web\_read() is created to support reading data from a USB file. These functions are located in freescale\_file\_api.c.

```

unsigned long usb_web_read( unsigned char session, unsigned char *buffer_out, unsigned long
max_bytestoread )
{
    unsigned long      i, k, j;
    unsigned long      read_index, bytes_to_read, last_read, read_size;
    unsigned char      *data;
    unsigned long      r;

if(freescale_http_sessions[session].file_index>=freescale_http_sessions[session].file_size )
{
    return(0);
}

if( (freescale_http_sessions[session].file_index + max_bytestoread) >
    freescale_http_sessions[session].file_size )
{
    max_bytestoread = freescale_http_sessions[session].file_size -
freescale_http_sessions[session].file_index;
}

r=f_read(buffer_out,1,max_bytestoread,(F_FILE*)(freescale_http_sessions[session].file_pointer
));
//#if HTTP_VERBOSE>4
printf("session %d read %d\n\r", session, r);
//#endif
freescale_http_sessions[session].file_index+=r;

```

```

        return r;
}
#endif

```

### 4.2.3 Adding a USB Detecting Device in CMX

This HTTP web server also contains a web page in the internal flash. The application can also provide a web page in case there is no USB device attached. An application knows if a USB device is attached by adding a variable named `usbmst_attach` in the USB interrupt service routine, this tells the application that a USB device is attached or not.

```

extern unsigned char usbmst_attach;
__declspec(interrupt)
void usb_it_handler(void)//
{
    unsigned char istr;
    /* Save irq USB status. */
    //istr=MCF_USB_INT_STAT;
    if(MCF_USB_INT_STAT & MCF_USB_INT_STAT_ATTACH)
    {
        MCF_USB_INT_ENB &= ~MCF_USB_INT_ENB_ATTACH;//clear interrupt flag
        usbmst_attach = 1;           //tell applications that a usb flash is attached
    }
}

```

The device attach interrupt is disabled after reset and needs to be enabled in `main()`. To achieve this, two registers need be configured. One is `MCF_USB_INT_STAT`, the other is `MCF_USB_INT_ENB`.

```

int main(void)
{
...
MCF_USB_INT_STAT = MCF_USB_INT_STAT_ATTACH; //write to clear it
MCF_USB_INT_ENB |= MCF_USB_INT_ENB_ATTACH;
...
}

```

### 4.2.4 Displaying Sensor Data and Network Status on a Web Page

This project is implemented on the MCF52259EVB. On the board there is a rheostat connected to the ADC port that can be used to collect data and provide the web server with it. The server also places network statistic data on the web page. The codes to collect data are located in a function named `evb_specific_collect_sensor_data()` that can be referenced in `MCF52259_evb.c`. The ADC collecting data is achieved by a function named `read_AD()`. Information about the network status comes from a data structure `ip_mib` used by the InterNiche stack to store IP status for simple network management protocol (SNMP).

```

void evb_specific_collect_sensor_data(void) //FSL new function for evb specific implementation
{
    ...
    html_vars[3] = read_AD(0);
    html_vars_flags[3] = 1;

    html_vars[4] = read_AD(1);
    html_vars_flags[4] = 1;
}

```

```
html_vars[5] = read_AD(2);
html_vars_flags[5] = 1;

html_vars[6] = read_AD(3);
html_vars_flags[6] = 1;

html_vars[7] = read_AD(4);
html_vars_flags[7] = 1;

html_vars[8] = read_AD(5);
html_vars_flags[8] = 1;

html_vars[9] = read_AD(6);
html_vars_flags[9] = 1;

html_vars[10] = read_AD(7);
html_vars_flags[10] = 1;

...

html_vars[14] = ip_mib.ipInReceives;           /* total received datagrams (bad too) */
html_vars_flags[14] = 1;

html_vars[15] = ip_mib.ipInHdrErrors;          /* Header Err (xsum, ver, ttl, etc) */
html_vars_flags[15] = 1;

html_vars[16] = ip_mib.ipInAddrErrors;          /* nonsense IP addresses */
html_vars_flags[16] = 1;

html_vars[17] = ip_mib.ipUnknownProtos;         /* unknown protocol types */
html_vars_flags[17] = 1;

html_vars[18] = ip_mib.ipInDelivers;            /* delivered receive packets */
html_vars_flags[18] = 1;

html_vars[19] = ip_mib.ipOutRequests;           /* sends (not including routed) */
html_vars_flags[19] = 1;

html_vars[20] = ip_mib.ipOutDiscards;           /* sends dropped (no buffer) */
html_vars_flags[20] = 1;

html_vars[21] = ip_mib.ipOutNoRoutes;           /* dropped, does not route */
html_vars_flags[21] = 1;
}
```


## 4.2.5 Project Compiling

Modifications listed in “[Section 4.2.1](#), [4.2.2](#) and [4.2.3](#)” are inserted in the original codes. To avoid destroying the original code structure they are all enclosed by a macro named MCF52259. Please predefine this macro before compiling the project.

```
#define MCF52259
```

## 4.3 Running HTTP Web Server on the MCF52259EVB

Before running the HTTP web server, the evaluation board (EVB) must be connected to a PC through a UART0 port. The baudrate of the HyperTerminal must be set to 115200-8N1. After power on reset, information appears as in [Figure 1](#).



115200-8N1 - HyperTerminal

File Edit View Call Transfer Help

Copyright 2008 by Freescale Semiconductor Inc.  
Use of this software is controlled by the agreement  
found in the project LICENSE.H file.  
Built on Aug 22 2008 10:41:43

IP Address = 0 -> 0.0.0.0  
Mask = 0 -> 0.0.0.0  
Gateway = 0 -> 0.0.0.0

InterNiche ColdFireLite TCP/IP for ColdFire, v3.0

Copyright 1997-2006 by InterNiche Technologies.  
All rights reserved.  
Preparing device for networking  
Ethernet started on Iface: 0

Acquired IP address via DHCP client for interface:  
IP address : 10.192.221.30  
Subnet Mask: 255.255.254.0  
Gateway : 10.192.221.254  
INET> Device connection detected.  
Mass-storage driver started.

Connected 0:03:01 Auto detect 115200 8-N-1 SCROLL CAPS NUM Capture Print echo

**Figure 1. HyperTerminal**

The HTTP web server also has a DHCP client, therefore it can automatically obtain an IP address. In [Figure 1](#) the IP address for the server is 10.192.221.30. If a USB device is plugged in, information about this is output.

## 4.4 Connecting to the Web Page on the USB Flash

Because the IP address is obtained, the HTTP web server can be visited through Internet Explorer by typing <http://10.192.221.30> in the address bar.




Figure 2. Internet Web Page

## 5 TFTP Server Implementation

### 5.1 Software Architecture

This architecture is similar to the HTTP web server. The architecture includes source files supporting TFTP protocol instead of HTTP server support, as in [Table 3](#).

**Table 3. TFTP Server Project Architecture**

Module	Description
CodeWarrior specific	Linker file for the M52259EVB
ColdFirelite	InterNiche stack containing multiple folders for the Ethernet TCP/IP stack, supported protocols, and RTOS processor independent files
Common	Standard C functions and UART input/output support
CPU	Contains respective processor dependent files
Drivers	Drivers for MII interface
Project files	Main and interrupts source files
CMXUSB_LITE	CMX USB stack containing multiple folders for USB mass host support

### 5.2 Implementation

This project is also implemented based on the MCF52259EVB. The TFTP server has been already provided by InterNiche. That particular example accesses files stored in the internal flash through VFS and therefore there is a critical file size limitation. In this project, files are stored in a USB device that allows for a larger file size. The key point is to make the TFTP server access the USB files through the CMX file system instead of VFS.

#### 5.2.1 Adding File Operation Support for a USB File

In this project, the APIs regarding file operation are all replaced by the CMX file system.

##### 5.2.1.1 Replacing File Descriptor in VFS with the CMX File

The file descriptor is an important parameter used by the file system. The VFILE is defined for VFS and now replaced by the CMX file system.

```
#ifdef MCF52259_MST
    F_FILE*tf_fd;
#else
    VFILE *      tf_fd;                                /* file descriptor for xfer */
#endif
```

### 5.2.1.2 Replacing File Open Function in VFS with CMX File

The function `vfopen()` is used as a file open function in VFS and is replaced by `f_open()` from the CMX file system.

```
#ifdef MCF52259_MST
#include "thin_usr.h"
#endif

...
#ifndef MCF52259_MST // 
    cn->tf_fd = f_open(fname, "w");
    #else
    cn->tf_fd = vfopen(fname, "w");
    #endif
else if(mode == OCTET)
    #ifdef MCF52259_MST
    cn->tf_fd = f_open(fname, "w");
    #else
    cn->tf_fd = vfopen(fname, "wb");
    #endif
...
if(mode == ASCII)
    #ifdef MCF52259_MST
    cn->tf_fd = f_open(fname, "r");
    #else
    cn->tf_fd = vfopen(fname, "r");
    #endif
else if(mode == OCTET)
    #ifdef MCF52259_MST
    cn->tf_fd = f_open(fname, "r");
    #else
    cn->tf_fd = vfopen(fname, "rb");
    #endif
else
    return("Invalid mode");
...
...
```

### 5.2.1.3 Replacing File Close Function in VFS with CMX File

The function `vfclose()` is used as the file close function in VFS and is replaced by `f_close()` from the CMX file system.

```
if(cn->tf_fd != NULL)
#ifndef MCF52259_MST
    f_close(cn->tf_fd);
    #else
    vfclose(cn->tf_fd);
#endif
```

### 5.2.1.4 Replacing File Write Function in VFS with CMX File

The function vfwrite() is used as a file write function in VFS, and is replaced by f\_write() from the CMX file system.

```
#ifdef MCF52259_MST
    if((int)f_write(data,1,len,cn->tf_fd)!=(int)len)
    #else
    if((int)vfwrite(data, 1, len, cn->tf_fd) != (int)len)
#endif
```

### 5.2.1.5 Replacing File Read Function in VFS with CMX File

The function vfread() is used as a file read function in VFS and is replaced by f\_read() from the CMX file system.

```
/* load file data into tftp buffer */
if(!cn->tf_NR)                                /* if this is NOT a retry, read in new data */
{
    #ifdef MCF52259_MST
    bytes = f_read(tfdata->tf_data, 1, NORMLEN, cn->tf_fd);
    #else
    bytes = vfread(tfdata->tf_data, 1, NORMLEN, cn->tf_fd);    /* read next block from file */
    #endif
    if(bytes < NORMLEN)                         /* end of file? */
    {
        #ifndef MCF52259_MST
        if(vferror(cn->tf_fd))      /* check if it is an error */
        {
            if(cn->callback)
                cn->callback(TFC_FILEREAD, cn, "file read error");
            return FALSE;
        }
        #endif
        /* else at End Of File; fall through to do the last send */
    }
    cn->tf_flen = bytes;                         /* bytes in last packet sent */
    cn->tf_size += bytes;                        /* total bytes sent so far */
}
...
...
```

### 5.2.2 Adding the TFTP Server Task in the NicheTask

Predefining the TFTP\_SERVER to activate the TFTP server codes. Do not forget to comment out the macro defined for including VFS.

```
#ifdef TFTP_PROJECT
#define TFTP_SERVER      1 /* include TFTP server code */
//#define VFS_FILES       1 /* include Virtual File System */
#endif
```


## 5.3 Project Compile

Similar to the HTTP project, predefines must be executed before compiling this project.

```
#define TFTP_PROJECT
#define MCF52259_MST
```

## 5.4 Running the TFTP Server on the MCF52259EVB

Before running the TFTP server, the EVB must be connected to the PC through the UART0 port. The baudrate of the HyperTerminal must be set to 115200-8N1. After power on reset, information is displayed as in [Figure 3](#).



**Figure 3. HyperTerminal**


The TFTP server also has a DHCP client. It can obtain the IP address automatically. In [Figure 3](#) the IP address for the server is 10.192.221.30. If a USB device is plugged in information is output. After, type the command tfsrv to activate the TFTP server.

## 5.5 Uploading a File to the TFTP Server

After the IP address for the TFTP server is obtained files can be uploaded to this server by DOS command tftp –i <dst\_addr> put filename.xx. The dst\_addr is 10.192.221.30 and the filename can be any file in the opened folder.

### NOTE

Never forget the option –i.



The screenshot shows a Windows Command Prompt window with the following text:

```
C:\> C:\WINDOWS\system32\cmd.exe
(C) Copyright 1985-2001 Microsoft Corp.

D:\Profiles\b17977>dir
 Volume in drive D is DATA
 Volume Serial Number is B4CC-9308

 Directory of D:\Profiles\b17977

2008-08-14  13:34    <DIR>      .
2008-08-14  13:34    <DIR>      ..
2008-04-08  10:42    <DIR>      Contacts
2008-08-20  11:24    <DIR>      Desktop
2008-07-11  16:50    <DIR>      Favorites
2008-06-18  16:14    <DIR>      My Documents
2008-05-13  09:07    <DIR>      Start Menu
2008-05-07  11:02    <DIR>      WINDOWS
2008-05-07  19:09            16 .gtk-bookmarks
2008-05-07  15:52            590 install.log
                           2 File(s)      606 bytes
                           8 Dir(s)   23,600,000,000 bytes free


D:\Profiles\b17977>tftp -i 10.192.221.30 put install.log
Transfer successful: 590 bytes in 1 second, 590 bytes/s

D:\Profiles\b17977>
```

Figure 4. Uploading Files to the TFTP Server

## 5.6 Downloading a File from the TFTP Server

The same as uploading the file. Files can be downloaded from this server with a DOS command tftp –i <dst\_addr> get filename.xx.



The screenshot shows a Windows command prompt window titled 'C:\WINDOWS\system32\cmd.exe'. The command 'dir' is run to show the contents of the 'D:\test' directory. The output shows two empty directories ('.' and '..') and two files ('0 File(s)' and '2 Dir(s)'). The total free space is '23,598,246,912 bytes free'. Then, the command 'tftp -i 10.192.221.30 get install.log' is run to download a file named 'install.log' from a TFTP server at IP address 10.192.221.30. The transfer is successful, taking 1 second at a rate of 590 bytes/s. Finally, another 'dir' command is run, showing the newly downloaded 'install.log' file in the directory.

```
C:\WINDOWS\system32\cmd.exe
Volume Serial Number is B4CC-9308

Directory of D:\test

2008-08-22  14:00    <DIR>      .
2008-08-22  14:00    <DIR>      ..
          0 File(s)           0 bytes
          2 Dir(s)  23,598,246,912 bytes free

D:\test>tftp -i 10.192.221.30 get install.log
Transfer successful: 590 bytes in 1 second, 590 bytes/s

D:\test>dir
Volume in drive D is DATA
Volume Serial Number is B4CC-9308

Directory of D:\test

2008-08-22  14:01    <DIR>      .
2008-08-22  14:01    <DIR>      ..
2008-08-22  14:01           590 install.log
          1 File(s)           590 bytes
          2 Dir(s)  23,598,246,912 bytes free

D:\test>
```

Figure 5. Downloading Files from the TFTP Server

## 6 Conclusion

The HTTP/TFTP server projects are implemented based on the FEC and USB module MCF52259 that provide not only high performance but also flexible connectivity. Applications based on the MCF52259 are not limited in the HTTP/TFTP server. If a USB camera is connected to the MCU instead of a flash a web monitor is achieved with minimal changes to the HTTP/TFTP server. It can monitor what is happening through the web page. The MCF52259 is ideal for applications in the industrial controlling field. Further development regarding Network applications can be achieved functionality based on this application note.

**How to Reach Us:****Home Page:**[www.freescale.com](http://www.freescale.com)**Web Support:**<http://www.freescale.com/support>**USA/Europe or Locations Not Listed:**

Freescale Semiconductor, Inc.

Technical Information Center, EL516  
2100 East Elliot Road  
Tempe, Arizona 85284  
1-800-521-6274 or +1-480-768-2130  
[www.freescale.com/support](http://www.freescale.com/support)

**Europe, Middle East, and Africa:**

Freescale Halbleiter Deutschland GmbH

Technical Information Center

Schatzbogen 7  
81829 Muenchen, Germany  
+44 1296 380 456 (English)  
+46 8 52200080 (English)  
+49 89 92103 559 (German)  
+33 1 69 35 48 48 (French)  
[www.freescale.com/support](http://www.freescale.com/support)

**Japan:**

Freescale Semiconductor Japan Ltd.

Headquarters

ARCO Tower 15F  
1-8-1, Shimo-Meguro, Meguro-ku,  
Tokyo 153-0064  
Japan  
0120 191014 or +81 3 5437 9125  
[support.japan@freescale.com](mailto:support.japan@freescale.com)

**Asia/Pacific:**

Freescale Semiconductor China Ltd.

Exchange Building 23F

No. 118 Jianguo Road

Chaoyang District

Beijing 100022

China

+86 10 5879 8000

[support.asia@freescale.com](mailto:support.asia@freescale.com)**For Literature Requests Only:**

Freescale Semiconductor Literature Distribution Center

P.O. Box 5405

Denver, Colorado 80217

1-800-441-2447 or +1-303-675-2140

Fax: +1-303-675-2150

[LDCForFreescaleSemiconductor@hibbertgroup.com](mailto:LDCForFreescaleSemiconductor@hibbertgroup.com)

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.



Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2008. All rights reserved.

AN3779

Rev. 0

09/2008