

Quick-Connect IoT DA16600 Provisioning Demo

This quick start guide explains the process of running the Quick-Connect IoT DA16600 (WiFi BLE) Provisioning demo on an EK-RA6M4. The demo demonstrates provisioning the DA16600 module to a WiFi network using the BLE interface and reading temperature and humidity data from the HS3001 sensor into the RA6M4 microcontroller.

A smartphone application is used to provision the DA16600 module to an existing WiFi network using the BLE interface. A web browser is then used to display the temperature and humidity data read from the HS3001 sensor. Instructions for loading the example project are included at the end of the document as a next step after running the demo.

Target Devices

- RA6M4 MCU (R7FA6M4AF3CFB)
- HS3001 Temperature / Humidity Sensor (HS3001)
- DA16600 WiFi BLE Module (DA16600MOD)

Contents


1. Kit Contents	2
1.1 Hardware Components.....	2
1.2 Software Components	3
2. Features	3
3. Overview	3
4. Build Environment	4
5. Building and Downloading	4
6. Preparing the Demo	5
6.1 Download the Smartphone Application	5
6.2 Obtain WiFi Network Details.....	5
6.3 Status Indication	5
6.4 Start the Hardware.....	5
7. Running the Demo	6
7.1 Provision Module to WiFi Network.....	6
7.1 View Sensor Data.....	8
7.2 Resetting the Demo	8
8. Starting Development with the Application Project	8
9. Reference Documents	9
10. Revision History	9

1. Kit Contents

To set up this demo, the following components are needed. Please ensure the Pmod™ boards are connected in the correct order, including on the correct Pmod ports. Connect the micro USB cable between the EK-RA6M4 MCU development board and the Windows PC.

1.1 Hardware Components

- EK-RA6M4 (RTK7EKA6M4S00001BE)
- HS3001 Pmod (US082-HS3001EVZ)
- Pmod Interposer Board (US082-INTERPEVZ)
- DA16600MOD WiFi Bluetooth LE Combo Pmod (US159-DA16600MEVZ)
- Micro USB cable



1.2 Software Components

The following software is required. The demo and application projects are both contained inside the Quick_Connect_IoT_DA16600_Provisioning_Demo.zip file that accompanies this document.

Category	Item	Note
e ² studio project	Quick_Connect_IoT_DA16600_Provisioning_Demo.zip	Project can be directly imported to e ² studio and the FSP (v3.4 and higher).
Mobile App	Dialog WiFiProvisioning Tool for iOS	Apps available globally on Google Play and Apple App Store.
	Dialog WiFiProvisioning Tool for Android	


2. Features

- System power supplied by micro USB cable
- RA6M4 MCU reads measured data from HS3001 temperature and humidity sensor
- BLE connectivity provided by DA16600 allows easy provisioning to WiFi networks
- WiFi connectivity allows the web browser to display raw humidity and temperature values

3. Overview

The DA16600 Module contains both WiFi and Bluetooth LE radios. A typical use case for such a module is to use the Bluetooth LE interface to quickly and easily join (provision) the WiFi radio to an existing network. This demonstration uses an app running on a smartphone to provision the DA16600 module to an existing WiFi network by using the Bluetooth LE interface to select the network and enter the password.

After the DA16600 is provisioned to the network, the RA6M4 Microcontroller reads temperature and humidity data via the HS3001 sensor and embeds this information into a simple webpage. This data can be displayed by connecting a PC to the same WiFi network as the DA16600 and then using a web browser to view the webpages served by the RA6M4 Microcontroller.



4. Build Environment

The example application was developed using the following environment.

Item	Description
IDE	e ² Studio 2021-10
C Compiler	GCC ARM Embedded 9.3.1.20200408
FSP	3.4.0
RTOS	None
Emulator	On board (J-LINK)

If this environment is not already installed, see the [Official Renesas RA Family Beginner's Guide](#) for complete installation instructions.

5. Building and Downloading

When the build environment is installed, import the project contained within the zip file into e² Studio and build the Debug or Release targets. Then, load the application onto the EK-RA6M4 board using the debugger. If you are not familiar with the build/debug process, see sections 3, 4, and 5 in the [Official Renesas RA Family Beginner's Guide](#).

6. Preparing the Demo

6.1 Download the Smartphone Application

The DA16600 module is provisioned to a WiFi network using a smartphone application that is available on the Apple App and Google Play stores. This app can be downloaded using the following QR code links:









6.2 Obtain WiFi Network Details

You will need to know the SSID and password of the WiFi network to which you want to provision the DA16600 module. When you have this information, keep them at hand because they are required in the next section.

6.3 Status Indication

The red, green, and blue LEDs on the EK-RA6M4 evaluation kit board indicate the status of the demo software as follows:

LED State	Description
	Device is booting.
	Device is waiting to be provisioned to a WiFi network.
	Device is provisioned and waiting to join a WiFi network.
	Device is provisioned and connected to a WiFi network.
	Device is provisioned, connected to a WiFi network, and a TCP client is connected.
	An error has occurred; check boards are connected correctly and restart.

6.4 Start the Hardware


Apply power to the EK-RA6M4; the red, green, and blue LEDs should illuminate for a few seconds while the device boots. When completed, the red LED should begin to blink indicating the demo is ready to be provisioned to a WiFi network.

7. Running the Demo


7.1 Provision Module to WiFi Network

Open the WiFiProvisioning Tool application on your smartphone and then perform the following steps.


Note: The following instructions are based on the use of an iOS device. When using an Android device the interface may appear different.




Step 1: Start the WiFiProvisioning Tool and select the **Start DA1600-based** option.




Step 2: Press the **Start** button to begin scanning the DA16600 device.




Step 3: Devices discovered during the scan are listed in the display.



Step 4: When the scan is complete press the **Connect** button next to the DA16600-xxxx device.



Step 5: When connected press the **Start Wi-Fi network scan** button to start searching for a WiFi network to join.




Step 6: The DA16600 starts searching for available WiFi networks.


Quick-Connect IoT DA16600 Provisioning Demo Quick Start Guide




Step 7: Select the WiFi network you want the DA16600 to join.




Step 8: Enter the password for the WiFi network then press **OK**.




Step 9: Connect the DA16600 device to the select WiFi network by pressing the **Connect to xxx** button.



Step 10: The DA16600 attempts to connect to the select network. This might take up to 1 minute.



Step 11: When connected to the WiFi network, press **Complete** to finish the process.




Step 12: When provisioning is completed, the red LED on the EK-RA6M4 EK turns on. It turns green when the DA16600 has connected to the WiFi network.

7.1 View Sensor Data

Now that the DA16600 Module has been provisioned to a WiFi network, the sensor data can be read using a web browser as follows:

1. Discover the IP Address of the DA16600. To do this, log in to the WiFi AP that the DA16600 joined and determine what IP address it has been assigned. The assigned IP address is also output using the serial debug interface and can be viewed using the Segger J-Link RTT Viewer.
2. Use a web browser to access the sensor data. When the browser has connected to the DA16600, the blue LED on the EK-RA6M4 turns on.
3. Press the S1 button on the EK-RA6M4 and the value displayed in the **Button Push Count** field increments.



7.2 Resetting the Demo

When provisioned, the DA16600 stores information about the WiFi network it has joined in non-volatile memory, allowing it to re-join the network if it is reset or the power is turned off and on. If you want to provision the DA16600 to a different WiFi network, this information must be erased. This can be achieved using the following procedure:

1. Press and hold switch SW1 (factory reset) on the DA16600 Pmod for 20 seconds, then release and wait 10 seconds.
2. Reset the EK-RA6M4 board by pressing switch S3. The red led on the EK-RA6M4 should be flashing, indicating the DA16600 it not provisioned.

8. Starting Development with the Application Project

The source code used to create the demo project is also included in the zip bundle. This project can be imported into the RA Flexible Software Package (FSP), version 3.4 or higher. The FSP must be downloaded and installed on a Windows or Linux machine. The e2 studio IDE is included as part of the FSP install. For more information on the FSP and how it can be downloaded and installed to your local machine, see the resource links in the following section.

9. Reference Documents

- [Renesas Quick-Connect](#)
- [Renesas RA6M4 MCU](#)
- [EK-RA6M4](#)
- [Renesas RA Flexible Software Package \(FSP\)](#)
- [Renesas DA16600MOD](#)
- [Renesas HS3001](#)
- Technical Updates / News - The latest information can be downloaded from the Renesas Electronics Website.

Website and Support:

- [Renesas Electronics](#)
- [Inquiries](#)

10. Revision History

Revision	Date	Description
1.00	Jul 5, 2022	Initial release.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.

9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev. 4.0-2 April 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.