

Getting started with the X-NUCLEO-53L4A2 expansion board for STM32 Nucleo based on the VL53L4CX


Introduction

The **X-NUCLEO-53L4A2** is an expansion board for any **STM32 Nucleo** development board equipped with the Arduino R3 connectors. It provides a complete evaluation kit that allows you to learn, evaluate, and develop applications using the **VL53L4CX** Time-of-Flight sensor with extended range measurement.

The expansion board is delivered with a cover glass holder in which you can fit three different spacers of 0.25, 0.5, and 1 mm height below the cover glass to simulate various air gaps. A small oval cover glass fitting the sensor is included.

Several ST expansion boards can be stacked through the Arduino connectors, which allow, for example, the development of **VL53L4CX** applications with Bluetooth or Wi-Fi interfaces.

Figure 1. X-NUCLEO-53L4A2 expansion board, spacers, cover glass holder, and oval cover glass



1 Getting started

1.1 Safety considerations

1.1.1 Electrostatic precautions

Warning: Take electrostatic precautions, including ground straps, when using the [X-NUCLEO-53L4A2](#) expansion board. Failure to prevent electrostatic discharge could damage the device.

Figure 2. Electrostatic logo



1.1.2 Laser safety considerations

The [VL53L4CX](#) contains a laser emitter and the corresponding drive circuitry.

The laser output is designed to remain within Class 1 laser safety limits under all reasonable foreseeable conditions, including single faults, in compliance with the IEC 60825-1:2014 (third edition).

The laser output remains within Class 1 limits as long as you use the STMicroelectronics recommended device settings and respect the operating conditions specified in the data sheet.

The laser output power must not be increased and no optics should be used with the intention of focusing the laser beam.

Figure 3. Class 1 laser product label



1.2 Features

- [VL53L4CX](#) Time-of-Flight sensor with extended range measurement
- Accurate absolute ranging distance, independent of the reflectance of the target
- Distance measurement from 0 mm up to 6 m
- Short distance linearity down to 10 mm
- Histogram-based technology
- Multiobject detection capability
- Targets beyond 80 cm range are immune to crosstalk from cover glass, and smudge
- 0.25, 0.5, and 1 mm spacers to simulate air gaps
- Two different cover glasses to protect the sensor from the dust
- Compatible with [STM32 Nucleo](#) development boards
- Equipped with Arduino UNO R3 connectors
- Full system software supplied, including code examples and graphical user interface
- RoHS, CE, UKCA, and China RoHS compliant

1.3 Spacers and covers

The X-NUCLEO-53L4A2 expansion board is delivered with:

- three spacers of 0.25 mm, 0.5 mm, and 1 mm height, used to simulate different air gaps between the VL53L4CX and the rectangular-shaped cover glass;
- an oval-shaped cover glass to simulate the integration of the VL53L4CX into the customer's final product;
- two six-pin headers that allow connecting the two breakout boards to the X-NUCLEO-53L4A2 expansion board.

Attention: The VL53L4CX is delivered with a liner to prevent potential foreign material from piercing the module holes during the assembly process. Remove this liner before use.

1.4 Ordering information


To order the Time-of-Flight high-accuracy proximity sensor expansion board based on the VL53L4CX, refer to the table below.

Table 1. Ordering information

Order code	PCB version	Core product
X-NUCLEO-53L4A2-	X\$NUCLEO-53L4A2-	VL53L4CX

1.5 Simplified schematic

Figure 4. X-NUCLEO-53L4A2 expansion board - simplified schematic



2 Using the expansion board

The [X-NUCLEO-53L4A2](#) expansion board allows the user to test the [VL53L4CX](#) sensor functionality, to program it and to understand how to develop an application using this sensor.

The [X-NUCLEO-53L4A2](#) integrates:

- the [VL53L4CX](#) sensor;
- Arduino UNO R3 connectors;
- Connectors for [SATEL-VL53L4CX](#) optional breakout boards;

Important: Program a microcontroller to control the [VL53L4CX](#) through the I2C bus.

The application software and an example of the C-ANSI source code are available on the [sensor web page](#).

The [X-NUCLEO-53L4A2](#) expansion board can be connected to the [STM32 Nucleo](#) development board through the Arduino UNO R3 connectors (CN5, CN6, CN8, and CN9) as shown in [Figure 4](#).

3 Breakout boards


The [X-NUCLEO-53L4A2](#) package does not include the [VL53L4CX](#) breakout boards.

You can purchase them in a pack of two PCBs as [SATEL-VL53L4CX](#).

The [X-NUCLEO-53L4A2](#) supplies the [VL53L4CX](#) breakout boards at 3.3 V (see [Figure 4](#)).

For mechanical integration purposes, it could be interesting to use the mini PCB by breaking the [SATEL-VL53L4CX](#) along the red line as shown in the figure below. It is easier to integrate this setup into a customer's device thanks to its small size.

Figure 5. SATEL-VL53L4CX



The [SATEL-VL53L4CX](#) boards can be directly plugged onto the [X-NUCLEO-53L4A2](#) through the two 6-pin headers (see [Figure 6](#)).

As an alternative, they can be connected to the [X-NUCLEO-53L4A2](#) by using the mini PCB through flying wires (see [Figure 7](#)).

Figure 6. SATEL-VL53L4CX breakout boards connected to the X-NUCLEO-53L4A2 expansion board





Figure 7. VL53L4CX mini PCB flying wire connection to the X-NUCLEO-53L4A2 expansion board



4 Graphical user interface (GUI) and programming example for the X-NUCLEO-53L4A2

To evaluate the [VL53L4CX](#) device performance, use the related GUI or the [X-CUBE-TOF1](#).

The [X-NUCLEO-53L4A2](#) expansion board requires the [NUCLEO-F401RE](#) development board to use the GUI or run the ranging examples included in the [X-CUBE-TOF1](#).


Important: *Despite the fact that the [X-NUCLEO-53L4A2](#) can be stacked on any [STM32 Nucleo](#) board equipped the Arduino R3 connectors, the GUI is designed to work with the [NUCLEO-F401RE](#) only.*

Download the GUI (in the Tools and Software tab of the [X-NUCLEO-53L4A2](#) web page) or the [X-CUBE-TOF1](#) to evaluate the [VL53L4CX](#).

5 Schematic diagrams

Note: These schematic diagrams refer to the board latest version.

Figure 8. X-NUCLEO-53L4A2 circuit schematic (1 of 6)



Note: The display connector is an optional connector to connect an SSD1306 I2C OLED display to output the ranging data or other meaningful information if required. The related application note and example code will be available on st.com.

Figure 9. X-NUCLEO-53L4A2 circuit schematic (2 of 6)




Figure 10. X-NUCLEO-53L4A2 circuit schematic (3 of 6)

Nucleo Arduino Connectors




Figure 11. X-NUCLEO-53L4A2 circuit schematic (4 of 6)

Header for LCD




Figure 12. X-NUCLEO-53L4A2 circuit schematic (5 of 6)





Figure 13. X-NUCLEO-53L4A2 circuit schematic (6 of 6)



6 Bill of materials

Note: This BOM refers to the board latest version.

Table 2. X-NUCLEO-53L4A2 bill of materials

Item	Quantity	Reference	Part/value	Description	Manufacturer	Order code
1	0	J3	4-position, SNGL, 4x1, 2.54 mm, T/H	Connector header (not mounted)	Samtec	SSW-104-01-G-S
2	1	C1	4.7 μ F, 6.3 V, X5R, 0402	Ceramic capacitor	TDK	C1005X5R0J475K050BC
3	1	C2	100 nF, 10 V, X5R, 0201	Ceramic capacitor	Murata	GRM033R61A104KE15D
4	1	CN5	10-position, SNGL, 2.54 mm, T/H	Connector header	Samtec	SSQ-110-03-F-S
5	1	CN8	6-position, POS, SNGL, 2.54 mm, T/H	Connector header	Samtec	SSQ-106-03-F-S
6	1	U1	VL53L4CX	Time-of-Flight long ranging sensor with short distance capability	ST	VL53L4CX
7	2	J1, J2	2-position, 2.54 mm, T/H, vertical	Connector headers	Harwin	M20-9990245
8	2	J4_Left, J4_Right	6-position, SNGL, 6x1, 2.54 mm, T/H	Connector headers	Samtec	SSW-106-01-G-S
9	2	CN6, CN9	8-position, SNGL, 2.54 mm, T/H	Connector headers	Samtec	SSQ-108-03-F-S
10	2	R5, R6	10 k, $\pm 1\%$, 1/16 W, 0402	Resistors	Stackpole Electronics	RMCF0402FT10K0
11	2	LK1, LK2	2.54 mm	Headers	Harwin	M7571-05
12	4	R1, R2, R3, R4	2.2 k, $\pm 1\%$, 1/16 W, 0402	Resistors	Stackpole Electronics	RMCF0402FT2K20
13	1	Glass piece	PMMA	Glass piece	Hornix	Custom
14	1	Spacer	Black, PVC, rigid, 0.25 mm	Thick spacer	STEP File	Custom
15	1	Spacer	Black, PVC, rigid, 0.5 mm	Thick spacer	STEP File	Custom
16	1	Spacer	Black, PVC, rigid, 1.0 mm	Thick spacer	STEP File	Custom
17	1	Foam piece	Polyurethane, foam flexible, 25 mm x 3 mm x 2.4 mm	Foam piece	STEP File	Custom
18	2	Tapping screw	Black steel, M 1.7 x 8.0 mm	Black cross, round-head, self-tapping screw	—	—
19	1	Glass holder	Epoxy 1mm	Cover glass holder	STEP File	Custom
20	1	Cover glass	PMMA	Oval cover glass	Hornix	Custom

7 Board versions

Table 3. X-NUCLEO-53L4A2 versions

PCB version	Schematic diagrams	Bill of materials
X\$NUCLEO-53L4A2- ⁽¹⁾	X\$NUCLEO-53L4A2- schematic diagrams	X\$NUCLEO-53L4A2-bill of materials

1. This code identifies the X-NUCLEO-53L4A2 evaluation board first version. It is printed on the board PCB.

8 Regulatory compliance information

Formal Notice Required by the U.S. Federal Communications Commission

FCC NOTICE:

This kit is designed to allow:

(1) Product developers to evaluate electronic components, circuitry, or software associated with the kit to determine

whether to incorporate such items in a finished product and

(2) Software developers to write software applications for use with the end product.

This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter 3.1.2.

The evaluation kit has been designed to comply with part 15 of the FCC Technical Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Standard applied: FCC CFR 47 Part 15 Subpart B. Test method applied: ANSI C63.4 (2014).

Formal Product Notice Required by Industry Canada Innovation, Science and Economic Development

Canada compliance:

For evaluation purposes only. This kit generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to Industry Canada (IC) rules.

À des fins d'évaluation uniquement. Ce kit génère, utilise et peut émettre de l'énergie radiofréquence et n'a pas été testé pour sa conformité aux limites des appareils informatiques conformément aux règles d'Industrie Canada (IC).

This device has been tested with Innovation, Science and Economic Development RSS standards. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Standard applied: ICES-003 Issue 7 (2020), Class B. Test method applied: ANSI C63.4 (2014).

Cet appareil a été testé pour les normes RSS d'Innovation, Science et Développement économique. L'utilisation est soumise aux deux conditions suivantes: (1) cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter de recevoir tous les types d'interférence, y comprises les interférences susceptibles d'entraîner un fonctionnement indésirable.

Norme appliquée: NMB-003, 7e édition (2020), Classe B. Méthode d'essai appliquée: ANSI C63.4 (2014).

Formal product notice required by EU

This device is in conformity with the essential requirements of the Directive 2014/30/EU (EMC) and of the Directive 2015/863/EU (RoHS).

Standards applied (Class B): IEC 61000-6-1:2016, IEC 61000-6-3:2020, EN 61000-6-1:2019, EN 61000-6-3:2021, CISPR 32:2015 + A1:2019, EN 55032:2015 + A1:2020, CISPR 35:2016, EN 55035:2017 + A1:2020, IEC 61000-3-2:2018 + A1:2020, EN 61000-3-2:2019, IEC 61000-3-3:2013 + A1:2017 + A2:2021, EN 61000-3-3:2013 + A1:2019

Appendix A References

- [VL53L4CX data sheet](#)
- [X-NUCLEO-53L4A2 data brief: DB4624](#)
- [X-CUBE-TOF1 data brief: DB4449](#)

Revision history

Table 4. Document revision history

Date	Revision	Changes
16-Dec-2021	1	Initial release.
03-Mar-2022	2	Updated Section 1.2 Features.
04-Apr-2022	3	Added Section 1.4 Ordering information.

Contents

1	Getting started	2
1.1	Safety considerations	2
1.1.1	Electrostatic precautions	2
1.1.2	Laser safety considerations	2
1.2	Features	2
1.3	Spacers and covers	3
1.4	Ordering information	3
1.5	Simplified schematic	4
2	Using the expansion board	5
3	Breakout boards	6
4	Graphical user interface (GUI) and programming example for the X-NUCLEO-53L4A2	9
5	Schematic diagrams	10
6	Bill of materials	14
7	Board versions	15
8	Regulatory compliance information	16
Appendix A	References	17
	Revision history	18
	List of tables	20
	List of figures	21

List of tables

Table 1.	Ordering information.	3
Table 2.	X-NUCLEO-53L4A2 bill of materials.	14
Table 3.	X-NUCLEO-53L4A2 versions	15
Table 4.	Document revision history	18

List of figures

Figure 1.	X-NUCLEO-53L4A2 expansion board, spacers, cover glass holder, and oval cover glass.	1
Figure 2.	Electrostatic logo	2
Figure 3.	Class 1 laser product label	2
Figure 4.	X-NUCLEO-53L4A2 expansion board - simplified schematic.	4
Figure 5.	SATEL-VL53L4CX	6
Figure 6.	SATEL-VL53L4CX breakout boards connected to the X-NUCLEO-53L4A2 expansion board	7
Figure 7.	VL53L4CX mini PCB flying wire connection to the X-NUCLEO-53L4A2 expansion board	8
Figure 8.	X-NUCLEO-53L4A2 circuit schematic (1 of 6).	10
Figure 9.	X-NUCLEO-53L4A2 circuit schematic (2 of 6).	11
Figure 10.	X-NUCLEO-53L4A2 circuit schematic (3 of 6).	12
Figure 11.	X-NUCLEO-53L4A2 circuit schematic (4 of 6).	12
Figure 12.	X-NUCLEO-53L4A2 circuit schematic (5 of 6).	13
Figure 13.	X-NUCLEO-53L4A2 circuit schematic (6 of 6).	13

IMPORTANT NOTICE – READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2022 STMicroelectronics – All rights reserved