
USB-to-SPI Bridging with Microchip USB7002 and USB705x Hubs

Author: **Shiva Balasubramanian**
Microchip Technology Inc.

INTRODUCTION

The USB-to-SPI bridging feature provides system designers who use Microchip hubs an expanded system control and a potential BOM reduction. The use of a separate USB-to-SPI device is no longer required, and a downstream USB port is not lost as a result of implementing the standalone USB-to-SPI device. This feature is available on Microchip hubs that contain an internal Hub Feature Controller (HFC) and a Serial Peripheral Interface (SPI) interface. These hubs include USB7002, USB7050, USB7051, USB7052, and USB7056.

Commands may be sent from the USB Host to the internal HFC device in the Microchip hub to perform the following functions:

- Get hub information
- Reset the hub
- Force boot from internal ROM
- Enable SPI pass-through interface
- Disable SPI pass-through interface
- SPI pass-through read/write

Sections

This document includes the following topics:

[General Information on page 2](#)

[Part Number Information on page 4](#)

[MPLABCC DLL Implementation on page 4](#)

[Low-Level Implementation on page 5](#)

References

Consult the following documents for details on the specific parts referred to in this document:

- [USB7002 Data Sheet](#)
- [USB7050 Data Sheet](#)
- [USB7051 Data Sheet](#)
- [USB7052 Data Sheet](#)
- [USB7056 Data Sheet](#)
- [SST26VF016B Data Sheet](#)
- [Configuration of the USB7002 and USB705x Application Note](#)

GENERAL INFORMATION

The USB7002/USB705x series of USB hubs support native USB Type-C on the upstream side and a combination of native USB Type-C and standard USB 2.0 ports on the downstream side. On successful enumeration of the hub, the USB device tree on the host shows a USB2.0 hub instance, a USB3.0 hub instance, and a third device which is the HFC. Refer to [Table 1](#) for details on the default HFC settings by part number.


TABLE 1: DEFAULT SETTINGS FOR HUB FEATURE CONTROLLER ENABLE

Part Number	Part Summary	Hub Controller Default Setting	USB3 PID	USB2 PID
USB7002	4-Port USB3.1 Gen1 Hub	Enabled on Port 6	0x7002	0x4002
USB7050	4-Port USB3.1 Gen1 Hub with power delivery on 3 ports	Enabled on Port 6	0x7050	0x4050
USB7051	4-Port USB3.1 Gen1 Hub with power delivery on 2 ports	Enabled on Port 6	0x7051	0x4051
USB7052	4-Port USB3.1 Gen1 Hub with power delivery on 1 port	Enabled on Port 6	0x7052	0x4052
USB7056	6-Port USB3.1 Gen1 Hub with power delivery on 1 port	Enabled on Port 8	0x7056	0x4056

The HFC is a USB device that enumerates on an extra internal non-removable USB2.0 port ([Figure 1](#)). For example, in a 4-port hub, the HFC is connected to Port 5. The base Product ID (PID) for the HFC is 0x7040. Based on the features enabled in an SKU, the last nibble of this PID may vary. The HFC is enabled by default in all the SKUs and can be disabled by setting bit 8 of the runtime flag register at address 0xBFD23408.

To use the bridging features of the hub, all bridging host commands must be addressed to the HFC which in turn will transmit the data to the appropriate serial interface lines.

FIGURE 1: MICROCHIP HUB FEATURE CONTROLLER BLOCK DIAGRAM



SPI Bridging Commands

The following SPI functions are supported:

- [Get Hub Information](#)
- [Reset the Hub](#)
- [Force Boot from Internal ROM](#)
- [Disable the SPI Pass-Through Interface](#)
- [Enable the SPI Pass-Through Interface](#)
- [SPI Pass-Through Read/Write](#)

GET HUB INFORMATION

The host can get information about the hub by issuing the GET_HUB_INFO command. In response, the hub sends a packet that contains information about the device revision, firmware version, and boot mode.

RESET THE HUB

The host can soft reset the hub externally by issuing the CMD_DEV_RESET command. This forces the hub firmware to start execution from 0x000000 and go through the boot sequence again.

FORCE BOOT FROM INTERNAL ROM

In situations where the hub is executing out of an external SPI ROM and the host wants to perform SPI pass-through transfers with the SPI ROM, this command sequence can be used to force the hub to boot and execute from the internal ROM.

ENABLE THE SPI PASS-THROUGH INTERFACE

To acquire the SPI interface, the host must send a CMD_SPI_ENTER_PASSTHRU SETUP packet before performing any SPI read/write commands. The SPI interface may operate at either 30 MHz or 60 MHz.

DISABLE THE SPI PASS-THROUGH INTERFACE

The SPI pass-through interface can be disabled after read/write operations by sending a CMD_SPI_EXIT_PASSTHRU SETUP packet.

SPI PASS-THROUGH READ/WRITE

The SPI pass-through interface allows single-/multi-byte write access and read access. In case of these operations, the SPI interface functions as a complete pass-through, which means any SPI data sent as a payload in the USB transfer gets transferred to the SPI lines directly. Therefore, the host must properly arrange data payloads in the appropriate SPI-compatible format and bit order, including the SPI slave device address. Up to 256 bytes can be written to an SPI peripheral using an SPI Write command sequence.

Data can also be read from an SPI peripheral using a combination of SPI read/write pass-through transfers. The host first needs to send a SETUP packet that informs the hub about the number of bytes to be read. Following this command, the hub stores the requested data bytes in an internal register at 0xBFD22310. The SPI Read command sequence can then be initiated by the host to retrieve the data. Up to 512 bytes of data can be read per SPI Read command sequence.

SPI Interface SETUP Requirements

SPI MASTER INTERFACE

The SPI interface always acts as an SPI master.

SELECTING SPI FREQUENCY

The SPI interface can operate at either 30 MHz or 60 MHz. The hub firmware configures the SPI interface to operate at 60 MHz by default. This can be changed by writing to bit 7 of the SPI_CTL register at address 0xBF802400, where:

- 0 = 30 MHz
- 1 = 60 MHz

SPI firmware images are designed to operate at specific speeds. Refer to the release notes of the SPI firmware image in use prior to making any modifications to the SPI interface speed.

SPI MODES OF OPERATION

Both SPI modes 0 and 3 are supported:

- Mode 0: Clock Polarity = 0, Clock Edge = 1
- Mode 3: Clock Polarity = 1, Clock Edge = 0

Dual Output Enable mode is also supported.

The default mode of operation is Mode 0 with the Dual Output Enable mode disabled. If the mode of operation is to be modified, a register write to the SPI_CTL (0xBF802400) register must be performed.

PART NUMBER INFORMATION

Part Summary

In USB7002/705x devices, SPI interface signals are associated with dedicated pins. See [Table 2](#) for information on the pins.

TABLE 2: USB7002 AND USB705X SPI INTERFACE PIN NUMBERS

Device	SPI_DI/ SPI_D1	SPI_CE_N	SPI_DO/ SPI_D0	SPI_CLK	SPI_D2	SPI_D3
USB7002	71	69	70	68	72	73
USB7050	71	69	70	68	72	73
USB7051	71	69	70	68	72	73
USB7052	71	69	70	68	72	73
USB7056	71	69	70	68	72	73

MPLABCC DLL IMPLEMENTATION

The simplest method for implementing the USB-to-SPI bridging functions is to use the publicly available MPLABCC DLL. MPLABCC is available for Windows® operating system. Visit the product page on [microchip.com](#) for any of the hubs listed in this document and to download the MPLABCC package. Using the libraries available in MPLABCC, the bridging features can be implemented in the C programming language.

The MPLABCC package contains the following:

- User's guide: A detailed description of how to use the DLL API to call each function
- Release notes
- Library files:
 - For Windows, a ".dll" and a ".lib" file
- Example code

Commands Included in SDK

- MchpUsbSpiSetConfig: This API enables or disables the SPI interface.
- MchpUsbSpiFlashWrite: This API performs write operation to the SPI Flash memory.
- MchpUsbSpiFlashRead: This API performs read operation from the SPI Flash memory.
- MchpUsbSpiTransfer: This API performs write operation to the SPI interface. SPI transfer to and from arbitrary SPI slaves is not supported.

For additional details on how to use the MPLABCC DLL for implementation of USB-to-SPI bridging, download the MPLABCC package and refer to the user's guide.

LOW-LEVEL IMPLEMENTATION

The USB-to-SPI bridging features may be implemented at the lowest level if you have the ability to build USB packets. This approach is required if Windows or the SDK cannot be used.

The details of these low-level USB packets are shown in the following sub-sections.

Get Hub Information

The following GET_HUB_INFO SETUP packet must be sent to obtain the hub-related information (Figure 2). Refer to Table 3 for the USB SETUP command details.

TABLE 3: USB SETUP COMMAND: GET HUB INFORMATION

SETUP Packet	Value	Description
bmRequestType	0xC0	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x09	GET_HUB_INFO command
wValue	0x0000	Reserved
wIndex	0x0000	Reserved
wLength	0x0006	Size of the HUB_INFO structure

The hub responds with a Hub Information Structure (HUB_INFO) during the DATA phase (Figure 2). The details on the hub information structure (DATA phase) are in Table 4.

TABLE 4: HUB INFORMATION STRUCTURE (DATA PHASE)

Offset	Size	Field	Description
0x00	2	FW Revision	Firmware revision
0x02	1	Device Revision	Silicon mask revision
0x03	2	ASIC Type	ASIC type: 0xA0 0xB0
0x05	1	Feature Flag	Bit 0: Current code execution area; 0: ROM, 1: SPI

FIGURE 2: GET_HUB_INFO (SETUP AND DATA PHASE)

Transaction	H	SETUP	ADDR	ENDP	T	D	Tp	R	bRequest	wValue	wIndex	wLength	ACK	Time Stamp
1235	S	0xB4	7	0	0	D->H	V	I	0x09	0x0000	0x0000	6	0x4B	4 . 944 684 716
Cho	Packet	H	H	SETUP	ADDR	ENDP	CRC5	Pkt Len		Duration	Idle		Time Stamp	
41978			S	0xB4	7	0	0x16	10		166.667 ns	167.330 ns		4 . 944 684 716	
Cho	Packet	H	H	DATA0		Data	CRC16	Pkt Len		Duration	Idle		Time Stamp	
41979			S	0xC3	C1 09 00 00 00 00 06 00		0x1713	18		300.000 ns	266.000 ns		4 . 944 685 050	
Cho	Packet	H	H	ACK	Pkt Len		Duration	Time		Time Stamp				
41980			S	0x4B	8		133.333 ns	910.150 us		4 . 944 685 616				Feature Flag
Transaction	H	IN	ADDR	ENDP	T		Data		ACK				Time Stamp	
1279	S	0x96	7	0	1	26	01 B1 06 03	01	0x4B				4 . 945 595 766	
Cho	Packet	H	H	IN	ADDR	ENDP	CRC5	Pkt Len		Duration	Idle		Time Stamp	
42074			S	0x96	7	0	0x16	8		133.333 ns	332.660 ns		4 . 945 595 766	
Cho	Packet	H	H	DATA1		Data	CRC16	Pkt Len		Duration	Idle		Time Stamp	
42075			S	0xD2	6 bytes	0xC3F4	16			266.667 ns	333.330 ns		4 . 945 596 232	
Cho	Packet	H	H	ACK	Pkt Len		Duration	Time		Time Stamp				
42076			S	0x4B	8		133.333 ns	6.268 us		4 . 945 596 832				

Reset the Hub

The hub can be soft reset externally from the host by issuing the CMD_DEV_RESET command. This command does not have a DATA phase (Figure 3). The existing device handle becomes invalid when the hub is reset. The host must acquire a new device handle by reopening the hub. See Table 5 for the USB SETUP command information.

TABLE 5: USB SETUP COMMAND: RESETTING THE HUB

SETUP Packet	Value	Description
bmRequestType	0x41	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x29	CMD_DEV_RESET command
wValue	0x0001	Reserved
wIndex	0x0000	Reserved
wLength	0x0000	No DATA phase

FIGURE 3: RESETTING THE HUB (SETUP PHASE)

Transaction	H	SETUP	ADDR	ENDP	T	D	Tp	R	bRequest	wValue	wIndex	wLength	ACK	Time Stamp
1859	S	0xB4	7	0	0	H->D	V	I	0x29	0x0001	0x0000	0	0x4B	4.964 601 082
	Ch0	Packet	H	H	SETUP	ADDR	ENDP	CRC5	Pkt Len	Duration	Idle	Time Stamp		
		43402			0xB4	7	0	0x16	10	166.660 ns	167.330 ns		4.964 601 082	
	Ch0	Packet	H	H	DATA0	Data		CRC16	Pkt Len	Duration	Idle	Time Stamp		
		43403			0xC3	41 29 01 00 00 00 00 00		0xC3D8	18	300.000 ns	300.000 ns		4.964 601 416	
	Ch0	Packet	H	H	ACK	Pkt Len	Duration	Time		Time Stamp				
		43404			0x4B	6	100.000 ns	1.394 ms		4.964 602 016				

Force Boot from Internal ROM

If the hub is executing out of the external SPI ROM and the host must perform SPI pass-through operations on the SPI ROM, then the hub must be forced to execute from the internal ROM for the operations to succeed. This can be achieved with the following command sequence:

1. Write the disable the SPI (DSPI) signature to the XDATA memory location 0xBFD227EC (Figure 4). The hub checks for this signature during the boot sequence. Refer to Table 6 for the USB SETUP command.

TABLE 6: USB SETUP COMMAND: WRITING DSPI SIGNATURE

SETUP Packet	Value	Description
bmRequestType	0x40	Vendor-specific command with host-to-device data transfer
bRequest	0x03	CMD_MEMORY_WRITE
wValue	0x27EC	ADDR_LO
wIndex	0xBFD2	ADDR_HI
wLength	0x0004	Number of data bytes to write

During the DATA phase of this transaction, the DSPI signature is sent to the hub.

EP0 OUT Data = 0x44, 0x53, 0x50, 0x49 ('D', 'S', 'P', 'I')

FIGURE 4: XDATA (0XBFD227EC) WRITE (SETUP AND DATA PHASE)

Transaction		H	SETUP	ADDR	ENDP	T	D	Tp	R	bRequest	wValue	wIndex	wLength	ACK	Time Stamp
1485	S	0xB4	7	0	0	H->D	V	D	0x03	0x27EC	0xBFD2	4	0x4B	4.956 678 832	
Ch0	Packet	H	H	42583	0xB4	7	0	0x16	8	CRC5	Pkt Len		Duration	Idle	Time Stamp
Ch0	Packet	H	H	42584	0xC3	40 03 EC 27 D2 BF 04 00	Data		0x05CC	16		266.660 ns	299.330 ns	4.956 679 166	
Ch0	Packet	H	D	42585	0x4B	8				ACK	Pkt Len		Duration	Idle	Time Stamp
Ch0	Packet	D	S	42585	14					100.000 ns			1.500 ms	4.956 679 732	
Transaction		H	OUT	ADDR	ENDP	T	Data			NYET				Time Stamp	
1558	S	0x87	7	0	1	4	bytes			0x69				4.958 179 432	
Ch0	Packet	H	H	42743	0x87	7	0	0x16	10	CRC5	Pkt Len		Duration	Idle	Time Stamp
Ch0	Packet	H	H	42744	0xD2	44 53 50 49	Data		0x6733	14		233.330 ns	300.660 ns	4.958 179 766	
Ch0	Packet	H	D	42745	0x69	8				NYET	Pkt Len		Duration	Time	Time Stamp
Ch0	Packet	D	S	42745	133.330 ns					1.329 ms				4.958 180 300	

2. Set bit 3 of XDATA memory address 0xBFD1DA1C (Figure 5). See [Table 7](#) for the USB SETUP command information.

TABLE 7: USB SETUP COMMAND: SETTING BIT 3 AT 0XBFD1DA1C

SETUP Packet	Value	Description
bmRequestType	0x40	Vendor-specific command with host-to-device data transfer
bRequest	0x03	CMD_MEMORY_WRITE
wValue	0xDA1C	ADDR_LO
wIndex	0xBFD1	ADDR_HI
wLength	0x0001	Number of data bytes to write

During the DATA phase of this transaction, the signature 0x08 is sent to the hub (Figure 5).

EP0 OUT Data = 0x08

FIGURE 5: XDATA (0XBFD1DA1C) WRITE (SETUP AND DATA PHASE)

Transaction		H	SETUP	ADDR	ENDP	T	D	Tp	R	bRequest	wValue	wIndex	wLength	ACK	Time Stamp
1621	S	0xB4	7	0	0	H->D	V	D	0x03	0xDA1C	0xBFD1	1	0x4B	4.959 594 966	
Ch0	Packet	H	H	42882	0xB4	7	0	0x16	8	CRC5	Pkt Len		Duration	Idle	Time Stamp
Ch0	Packet	H	H	42883	0xC3	40 03 1C DA D1 BF 01 00	Data		0x5BC0	16		266.660 ns	299.330 ns	4.959 595 300	
Ch0	Packet	H	D	42884	0x4B	8				ACK	Pkt Len		Duration	Time	Time Stamp
Ch0	Packet	D	S	42884	133.330 ns					1.395 ms				4.959 595 866	
Transaction		H	OUT	ADDR	ENDP	T	Data			NYET				Time Stamp	
1690	S	0x87	7	0	1	1	byte			0x69				4.960 990 466	
Ch0	Packet	H	H	43033	0x87	7	0	0x16	10	CRC5	Pkt Len		Duration	Idle	Time Stamp
Ch0	Packet	H	H	43034	0xD2	08 0x829E	Data		10	166.660 ns		167.330 ns	4.960 990 466		
Ch0	Packet	H	D	43035	0x69	6				NYET	Pkt Len		Duration	Time	Time Stamp
Ch0	Packet	D	S	43035	100.000 ns					3.640 ms				4.960 991 300	

3. Reset the hub as specified in [Reset the Hub on page 6](#).

Enable SPI Pass-Through Interface


The following SETUP packet command is required to enable the SPI pass-through interface (Figure 6). The interface must be enabled before any read/write commands could be issued by the host.

Note: There is no DATA phase to this USB transaction. Refer to [Table 8](#) for the USB SETUP command.

TABLE 8: USB SETUP COMMAND: ENABLING PASS-THROUGH INTERFACE

SETUP Packet	Value	Description
bmRequestType	0x41	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x60	CMD_SPI_ENTER_PASSTHRU
wValue	0x0000	Reserved
wIndex	0x0000	Reserved
wLength	0x0000	No DATA phase

FIGURE 6: ENABLE SPI PASS-THROUGH INTERFACE (SETUP PHASE)



Disable SPI Pass-Through Interface

The following SETUP packet command is required to disable the SPI pass-through interface (Figure 7).

Note: There is no DATA phase to this USB transaction. Refer to [Table 9](#) for the USB SETUP command.

TABLE 9: USB SETUP COMMAND: DISABLING SPI PASS-THROUGH INTERFACE

SETUP Packet	Value	Description
bmRequestType	0x41	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x62	CMD_SPI_EXIT_PASSTHRU
wValue	0x0000	Reserved
wIndex	0x0000	Reserved
wLength	0x0000	No DATA phase

FIGURE 7: DISABLE SPI PASS-THROUGH INTERFACE (SETUP PHASE)

Transaction	H	SETUP	ADDR	ENDP	T	D	Tp	R	bRequest	wValue	wIndex	wLength	ACK	Time Stamp
81795	S	0xB4	9	0	0	H->D	V	I	0x62	0x0000	0x0000	0	0x4B	15.286 565 716
		Packet	H	H	SETUP	ADDR	ENDP	CRC5	Pkt Len	Duration	Idle	Time Stamp		
		286258			0xB4	9	0	0x19	10	166.667 ns	167.330 ns	15.286 565 716		
		Packet	H	H	DATA0			Data	CRC16	Pkt Len	Duration	Idle	Time Stamp	
		286259			0xC3	41 62 00 00 00 00 00 00 00 00 00 00 00 00 00 00		0x9C73	18	300.000 ns	266.000 ns	15.286 566 050		
		Packet	D	S	ACK	Pkt Len	Duration	Time		Time Stamp				
		286260			0x4B	8	133.333 ns	64.266 us	15.286 566 616					
Transaction	H	IN	ADDR	ENDP	T	Data		ACK		Time		Time Stamp		
81799	S	0x96	9	0	1	0 bytes		0x4B		289.968 us	15.286 630 882			

SPI Pass-Through Read/Write

The SPI pass-through read/write command sequence consists of the following phases:

CMD_SPI_ACCESS PHASE

Note: Prior to initiating this phase, ensure that bit 13 of the XDATA memory address 0xBFD23408 is set. For more details on this, refer to the *Configuration of the USB7002 and USB705x Application Note*.

The host sends the following SETUP packet command during the CMD_SPI_ACCESS phase. The non-zero wIndex in this case holds configurable fields that instruct the hub firmware to poll any Status bits (like Busy bits in case of an SPI Flash) during an SPI read/write access. Refer to [Table 10](#) for the USB SETUP command.

TABLE 10: USB SETUP COMMAND: CMD_SPI_ACCESS

SETUP Packet	Value	Description
bmRequestType	0x41	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x61	CMD_SPI_PASS_THRU_WRITE
wValue	0xNNNN	Total length is the total number of data bytes to be sent to the SPI peripheral during the DATA phase that follows this SETUP packet. Total length = Signature length + Configurable field number + Command length + Response length ("SPID" Signature (4 bytes) + Configurable fields (4 bytes) + Number of bytes to transmit in the Command buffer + Number of bytes to receive in Response buffer)
wIndex	0xNN00	This value holds the number of configurable fields required for polling the Status bit. NN is the number of configurable fields. The configurable parameters are: <ul style="list-style-type: none"> • Status (Busy) bit location to Poll • Opcode for Status Read • Number of dummy bytes in the response • Index of the Response buffer to fetch the Status register value being polled Here NN is 04.
wLength	N	Number of bytes the SPI interface will transmit in the following data stage wLength = Total length – Response length

DATA PHASE

During this phase, the host sends an OUT DATA packet to the SPI peripheral. This packet is formatted as follows:

EP0 DATA =

- Index 0: S (0x53)
- Index 1: P (0x50)
- Index 2: I (0x49)
- Index 3: D (0x44)
- Index 4: Busy bit (0x01)
- Index 5: Read Status opcode
- Index 6: Number of dummy bytes in response
- Index 7: Index of the Response buffer to fetch the Status register value being polled
- Index 8 to Index n: Command buffer data (command byte, address byte, dummy bytes, and up to 256 data bytes)

RETRIEVING THE DATA (APPLIES TO BLOCK READ ONLY)

These additional SETUP and DATA phases are applicable only in case of SPI Block Reads. During the previous DATA phase (see [Data Phase on page 10](#)), based on the opcode, the hub retrieves the requested number of data bytes from the SPI peripheral and stores it internally in a register at location 0xBFD22310.

During this phase, the hub first sends the following SETUP packet to read the hub's internal register that contains the requested data. See [Table 11](#) for the USB SETUP command.

TABLE 11: USB SETUP COMMAND: SPI BLOCK READ

SETUP Packet	Value	Description
bmRequestType	0xC0	Vendor-specific command with device-to-host to data transfer
bRequest	0x04	CMD_MEMORY_READ
wValue	0x2310	ADDR_LO
wIndex	0xBFD2	ADDR_HI
wLength	0xNNNN	Number of data bytes to be retrieved

This is followed by a DATA phase where the hub responds to the host with an IN packet containing the requested number of bytes retrieved from the SPI peripheral.

Single-Byte Instruction Write Example

Figure 8 shows an example where a single-byte instruction (WREN) is written to enable the write latch in case of a SST26VF016B SPI Flash memory. Refer to Table 12 for the USB SETUP command information.

TABLE 12: USB SETUP COMMAND: SPI SINGLE-BYTE WRITE

SETUP Packet	Value	Description
bmRequestType	0x41	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x61	CMD_SPI_PASS_THRU_WRITE
wValue	0x0009	Total length = Signature length (4 bytes) + Configurable field number (4 bytes) + Command length (1 byte) + Response length (0 byte)
wIndex	0x0400	<p>Number of configurable fields for polling status</p> <p>The configurable parameters are:</p> <ul style="list-style-type: none"> • Busy bit location to Poll (0x01) • RDSR opcode (0x05) • Number of dummy bytes in the response (0x00) • Index of the Response buffer to fetch the Status register value that was returned (0x01)
wLength	0x0009	<p>Number of bytes the SPI interface will transmit in the following data stage.</p> <p>wLength = Total length – Response length</p> <p>wLength = 9 – 0 = 9 bytes</p>


0x05 is the Read Status register (RDSR) instruction, and 0xC7 is the Chip Erase instruction for SST26VF016B.

During the DATA phase of this command sequence, the host sends an OUT packet containing nine bytes to the SPI Flash as shown in Figure 8.

EP0 OUT Data =

- Index 0: S (0x53)
- Index 1: P (0x50)
- Index 2: I (0x49)
- Index 3: D (0x44)
- Index 4: Busy Bit (0x01)
- Index 5: Read Status opcode (RDSR:0x05)
- Index 6: Number of dummy bytes in response (0x00)
- Index 7: Index of the Response buffer to fetch the read status byte (0x01)
- Index 8 to Index 9: Command buffer data [Command byte: Chip Erase (0xC7)]

FIGURE 8: SINGLE-BYTE SPI WRITE (SETUP AND DATA PHASE)



SPI Block Write Example

The SPI pass-through interface allows the host to perform a block write of up to 256 bytes. [Figure 9](#) shows the SETUP packet for performing a block write to a SST26VF016B SPI Flash memory. See [Table 13](#) for the USB SETUP command details.

TABLE 13: USB SETUP COMMAND: SPI BLOCK WRITE

SETUP Packet	Value	Description
bmRequestType	0x41	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x61	CMD_SPI_PASS_THRU_WRITE
wValue	0x010C	Total length = Signature length (4 bytes) + Configurable field number (4 bytes) + Command length (1-byte opcode + 3 bytes of address + 256 data bytes) + Response length (0 byte)
wIndex	0x0400	<p>Number of configurable fields for polling status.</p> <p>The configurable parameters are:</p> <ul style="list-style-type: none"> Busy bit location to Poll (0x01) RDSR opcode (0x05) Number of dummy bytes in the response (0x00) Index of the Response buffer to fetch the Status register value that was returned (0x01)
wLength	0x010C	<p>Number of bytes the SPI interface will transmit in the following data stage</p> <p>wLength = Total length – Response length</p> <p>wLength = 268 – 0 = 268 bytes (0x010C)</p>

FIGURE 9: SPI BLOCK WRITE (SETUP PHASE)

Transaction													Time Stamp					
2545		H	SETUP		ADDR		ENDP		T D		Tp R bRequest		wValue wIndex wLength		ACK		Time Stamp	
Ch0	1265387	H	1265387	H	1265387	0xB4	32	0	0	H>D	V	I	0x61	0x010C 0x0400	268	0x4B	5.744 721 016	
Ch0	1265388	H	1265388	H	1265388	0xC3	41	61	0C 01	00 04	0C 01	0x4DC3	18	300.000 ns	268.000 ns	5.744 721 382		
Ch0	1265389	H	1265389	H	1265389	0x4B	8						133.330 ns	56.766 us	5.744 721 950			

During the DATA phase (Figure 10) of this command sequence, 268 bytes are transferred to the SPI Flash via the hub's pass-through interface. The DATA packet consists of the following:

EP0 OUT Data =

- Index 0: S (0x53)
- Index 1: P (0x50)
- Index 2: I (0x49)
- Index 3: D (0x44)
- Index 4: Busy bit (0x01)
- Index 5: Read Status opcode (RDSR:0x05)
- Index 6: Number of dummy bytes in response (0x00)
- Index 7: Index of the Response buffer to fetch the read status byte (0x01)
- Index 8 to Index 267: Command buffer data [Command byte: PAGE PROGRAM (0x02), address byte (0x00, 0x00, 0x00), dummy byte (none), and up to 256 data bytes]

In this case, PAGE PROGRAM (0x02) instruction is specific to SST26VF016B.

FIGURE 10: SPI BLOCK WRITE (DATA PHASE)

Transaction													Time Stamp					
2545		H	SETUP		ADDR		ENDP		T D		Tp R bRequest		wValue wIndex wLength		ACK		Time Stamp	
Ch0	1265387	H	1265387	H	1265387	0xB4	32	0	0	H>D	V	I	0x61	0x010C 0x0400	268	0x4B	5.744 721 016	
Ch0	1265388	H	1265388	H	1265388	0xC3	41	61	0C 01	00 04	0C 01	0x4DC3	18	300.000 ns	268.000 ns	5.744 721 382		
Ch0	1265389	H	1265389	H	1265389	0x4B	8						133.330 ns	56.766 us	5.744 721 950			
Transaction													Time Stamp					
Ch0	2549	H	2549	OUT	ADDR	ENDP	T	1	0: 53 50 49 44 01 05 00 01 02 00 00 00 03 00 00 10 00 00 00 00 F8 F3 B3 03 00 00 00 00 B3 03 F8 0F 32: 00 00 00 00 E9 4F EB CB 4D 2E A3 41 D2 BF 63 30 F4 4D 4C ED 44 00 10 2A BA 05 31 09 A1 EE A2 94	N/ET	0x69	75.134 us	5.744 778 716					
Ch0	2553	H	2553	OUT	ADDR	ENDP	T	1	0: 64 bytes	0x69	49.850 us	5.744 853 850						
Ch0	2556	H	2556	OUT	ADDR	ENDP	T	1	164 bytes	0x69	68.266 us	5.744 903 700						
Ch0	2560	H	2560	OUT	ADDR	ENDP	T	1	64 bytes	0x69	47.366 us	5.744 971 986						
Ch0	2563	H	2563	OUT	ADDR	ENDP	T	1	12 bytes	0x69	1.286 ms	5.745 019 332						
Ch0	2624	H	2624	IN	ADDR	ENDP	T	1	0 bytes	0x4B	53.034 us	5.746 305 332						


SPI Block Read Example

The SPI pass-through interface allows the host to perform a block read of up to 512 bytes. [Figure 11](#) shows the SETUP packet for this transaction in case of a SST26VF016B SPI Flash memory. See [Table 14](#) for the USB SETUP command information.

TABLE 14: USB SETUP COMMAND: SPI BLOCK READ

SETUP Packet	Value	Description
bmRequestType	0x41	Host-to-device data transfer with a vendor-specific command that targets the device
bRequest	0x61	CMD_SPI_PASS_THRU_WRITE
wValue	0x0212	Total length = Signature length (4 bytes) + Configurable field number (4 bytes) + Command length (1-byte opcode + 3 bytes of address + 1 dummy byte) + Response length (512 data bytes) + 5 bytes (first five bytes to be ignored)
wIndex	0x0400	Number of configurable fields for polling status. The configurable parameters are: <ul style="list-style-type: none">• Busy bit location to Poll (0x01)• RDSR opcode (0x05)• Number of dummy bytes in the response (0x00)• Index of the Response buffer to fetch the Status register value that was returned (0x01)
wLength	0x000D	Number of bytes the SPI interface will transmit in the following data stage wLength = Total length – Response length wLength = 530 – 517 = 13 bytes (0x000D)

FIGURE 11: SPI BLOCK READ (SETUP PHASE 1 AND DATA PHASE 1)



During the DATA phase ([Figure 11](#)), 13 bytes are transferred to the hub. The DATA packet consists of the following:

EP0 OUT Data =

- Index 0: S (0x53)
- Index 1: P (0x50)
- Index 2: I (0x49)

- Index 3: D (0x44)
- Index 4: Busy bit (0x01)
- Index 5: Read Status opcode (RDSR:0x05)
- Index 6: Number of dummy bytes in response (0x00)
- Index 7: Index of the Response buffer to fetch the read status byte (0x01)
- Index 8 to Index 12: Command buffer data [Command byte: HIGH SPEED READ (0x0B), address byte (0x02, 0x82, 0x00), dummy byte (0x00)]


In this case, HIGH-SPEED READ (0x0B) instruction is specific to SST26VF016B.

The host then initiates the second SETUP phase by sending a SETUP packet for reading the hub's internal register at 0xBFD22310 containing the data bytes to be read. [Figure 12](#) shows this SETUP packet. Refer to [Table 15](#) for the USB SETUP command details.

TABLE 15: USB SETUP COMMAND: SPI BLOCK READ

SETUP Packet	Value	Description
bmRequestType	0xC0	Vendor-specific command with device-to-host-to-data transfer
bRequest	0x04	CMD_MEMORY_READ
wValue	0x2310	ADDR_LO
wIndex	0xBFD2	ADDR_HI
wLength	0x0205	Number of data bytes to be retrieved (517 bytes). The first five bytes of any SPI read must be ignored. Therefore, five must be added to the number of bytes to be read.

FIGURE 12: SPI BLOCK READ (SETUP PHASE 2 AND DATA PHASE 2)



During the DATA phase that follows this, the hub responds with IN packets ([Figure 12](#)) containing a total of 517 bytes retrieved from the SPI Flash via the pass-through interface. The first five bytes returned during the DATA phase are 0s, and they need to be ignored.

APPENDIX A: APPLICATION NOTE REVISION HISTORY

TABLE A-1: REVISION HISTORY

Revision Level & Date	Section/Figure/Entry	Correction
DS00002790A (09-12-18)	Initial release	

NOTES:

THE MICROCHIP WEB SITE

Microchip provides Online support via our WWW site at www.microchip.com. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQ), technical support requests, online discussion groups, Microchip consultant program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

CUSTOMER CHANGE NOTIFICATION SERVICE

Microchip's customer notification service helps keep customers current on Microchip products. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at www.microchip.com. Under "Support", click on "Customer Change Notification" and follow the registration instructions.

CUSTOMER SUPPORT

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or Field Application Engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: <http://microchip.com/support>

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. **MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE.** Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, AnyRate, AVR, AVR logo, AVR Freaks, BitCloud, chipKIT, chipKIT logo, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, Heldo, JukeBlox, KeeLoq, Kleer, LANCheck, LINK MD, maXStylus, maXTouch, MediaLB, megaAVR, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, Prochip Designer, QTouch, SAM-BA, SpyNIC, SST, SST Logo, SuperFlash, tinyAVR, UNI/O, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

ClockWorks, The Embedded Control Solutions Company, EtherSynch, Hyper Speed Control, HyperLight Load, IntelliMOS, mTouch, Precision Edge, and Quiet-Wire are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, BodyCom, CodeGuard, CryptoAuthentication, CryptoAutomotive, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, INICnet, Inter-Chip Connectivity, JitterBlocker, KleerNet, KleerNet logo, memBrain, Mindi, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, PowerSmart, PureSilicon, QMatrix, REAL ICE, Ripple Blocker, SAM-ICE, Serial Quad I/O, SMART-I.S., SQL, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2018, Microchip Technology Incorporated, All Rights Reserved.

ISBN: 978-1-5224-3523-5

**QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
= ISO/TS 16949 =**

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KeeLoq® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



MICROCHIP

Worldwide Sales and Service

AMERICAS

Corporate Office
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
<http://www.microchip.com/support>
Web Address:
www.microchip.com

Atlanta

Duluth, GA
Tel: 678-957-9614
Fax: 678-957-1455

Austin, TX

Tel: 512-257-3370

Boston

Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago

Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Dallas

Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit

Novi, MI
Tel: 248-848-4000

Houston, TX

Tel: 281-894-5983

Indianapolis

Noblesville, IN
Tel: 317-773-8323
Fax: 317-773-5453
Tel: 317-536-2380

Los Angeles

Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608
Tel: 951-273-7800

Raleigh, NC

Tel: 919-844-7510

New York, NY

Tel: 631-435-6000

San Jose, CA

Tel: 408-735-9110
Tel: 408-436-4270

Canada - Toronto

Tel: 905-695-1980
Fax: 905-695-2078

ASIA/PACIFIC

Australia - Sydney
Tel: 61-2-9868-6733
China - Beijing
Tel: 86-10-8569-7000
China - Chengdu
Tel: 86-28-8665-5511
China - Chongqing
Tel: 86-23-8980-9588
China - Dongguan
Tel: 86-769-8702-9880
China - Guangzhou
Tel: 86-20-8755-8029
China - Hangzhou
Tel: 86-571-8792-8115
China - Hong Kong SAR
Tel: 852-2943-5100
China - Nanjing
Tel: 86-25-8473-2460
China - Qingdao
Tel: 86-532-8502-7355
China - Shanghai
Tel: 86-21-3326-8000
China - Shenyang
Tel: 86-24-2334-2829
China - Shenzhen
Tel: 86-755-8864-2200
China - Suzhou
Tel: 86-186-6233-1526
China - Wuhan
Tel: 86-27-5980-5300
China - Xian
Tel: 86-29-8833-7252
China - Xiamen
Tel: 86-592-2388138
China - Zhuhai
Tel: 86-756-3210040

ASIA/PACIFIC

India - Bangalore
Tel: 91-80-3090-4444
India - New Delhi
Tel: 91-11-4160-8631
India - Pune
Tel: 91-20-4121-0141
Japan - Osaka
Tel: 81-6-6152-7160
Japan - Tokyo
Tel: 81-3-6880- 3770
Korea - Daegu
Tel: 82-53-744-4301
Korea - Seoul
Tel: 82-2-554-7200
Malaysia - Kuala Lumpur
Tel: 60-3-7651-7906
Malaysia - Penang
Tel: 60-4-227-8870
Philippines - Manila
Tel: 63-2-634-9065
Singapore
Tel: 65-6334-8870
Taiwan - Hsin Chu
Tel: 886-3-577-8366
Taiwan - Kaohsiung
Tel: 886-7-213-7830
Taiwan - Taipei
Tel: 886-2-2508-8600
Thailand - Bangkok
Tel: 66-2-694-1351
Vietnam - Ho Chi Minh
Tel: 84-28-5448-2100

EUROPE

Austria - Wels
Tel: 43-7242-2244-39
Fax: 43-7242-2244-393
Denmark - Copenhagen
Tel: 45-4450-2828
Fax: 45-4485-2829
Finland - Espoo
Tel: 358-9-4520-820
France - Paris
Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79
Germany - Garching
Tel: 49-8931-9700
Germany - Haan
Tel: 49-2129-3766400
Germany - Heilbronn
Tel: 49-7131-67-3636
Germany - Karlsruhe
Tel: 49-721-625370
Germany - Munich
Tel: 49-89-627-144-0
Fax: 49-89-627-144-44
Germany - Rosenheim
Tel: 49-8031-354-560
Israel - Ra'anana
Tel: 972-9-744-7705
Italy - Milan
Tel: 39-0331-742611
Fax: 39-0331-466781
Italy - Padova
Tel: 39-049-7625286
Netherlands - Drunen
Tel: 31-416-690399
Fax: 31-416-690340
Norway - Trondheim
Tel: 47-7288-4388
Poland - Warsaw
Tel: 48-22-3325737
Romania - Bucharest
Tel: 40-21-407-87-50
Spain - Madrid
Tel: 34-91-708-08-90
Fax: 34-91-708-08-91
Sweden - Gothenberg
Tel: 46-31-704-60-40
Sweden - Stockholm
Tel: 46-8-5090-4654
UK - Wokingham
Tel: 44-118-921-5800
Fax: 44-118-921-5820