

STK600-RC044U-25 (for AT90USB-44 pin)

J3 and J4 mates up to the socket card, while J1 and J2 goes down to the mother board. J1 is physical placed below J3, and J2 below J4.

