


Preface

The dsPIC33CK256MC005 Curiosity Nano evaluation kit (EV08P02A) is a hardware platform for evaluating the dsPIC33CK256MC005 family. This board features the dsPIC33CK256MC005 (referred to as the target device in this document) mounted on the board.

The Curiosity Nano series of evaluation boards include an on-board programmer and debugger. No external tools are necessary to program and debug the dsPIC33CK256MC005.



- [Kit Website](#) - Kit information, the latest user guide, and design documentation.
- [Device Website](#) - Find documentation, data sheets, samples, and purchase devices.
- [Microchip Direct](#) - Purchase this kit from Microchip Direct.
- [MPLAB® Discover](#) - Get started with code examples on MPLAB® Discover.
- [Schematics](#) - Board schematics and revision history.
- [Design Documentation](#) - Production files for every revision.

Table of Contents

Preface.....	1
1. Pinout.....	4
2. Board Features.....	5
2.1. Board Features.....	5
2.2. Board Overview.....	5
2.3. Block Diagram.....	6
2.4. Curiosity Nano Pinout.....	6
3. Setup Essentials.....	8
3.1. Quick Start.....	8
3.2. Using Pin Headers.....	8
4. On-Board Nano Debugger.....	10
4.1. Overview.....	10
4.2. Power and Status LED.....	10
4.3. Connections.....	10
4.4. Disconnecting the On-Board Debugger.....	11
4.5. Connecting External Debuggers.....	12
5. Hardware Peripherals.....	14
5.1. LED.....	14
5.2. Mechanical Switch.....	14
5.3. MEMS Oscillator.....	15
6. Power Supply.....	16
6.1. Target Regulator.....	16
6.2. External Supply.....	17
6.3. VBUS Output Pin.....	18
6.4. Cut Straps.....	18
6.5. Low-Power Measurement.....	19
6.6. Power Supply Exceptions.....	19
7. Hardware Revision History and Known Issues.....	21
7.1. Identifying Product ID and Revision.....	21
8. Document Revision History.....	22
9. Appendix.....	23
9.1. Schematic.....	24
9.2. Assembly Drawing.....	26
9.3. Curiosity Nano Explorer.....	27
9.4. Curiosity Nano Base for Click boards™.....	28
9.5. Bill of Materials.....	29
Microchip Information.....	30
Trademarks.....	30
Legal Notice.....	30


Microchip Devices Code Protection Feature.....	30
--	----

1. Pinout

dsPIC33CK256MC005 Curiosity Nano pinout diagram.

All the dsPIC33CK256MC005 I/O pins are accessible at the edge connectors on the board. The image below shows the board's pinout.

Figure 1-1. dsPIC33CK256MC005 Curiosity Nano Pinout



Info: Peripheral signals shown in the image above, such as UART, I²C, SPI, ADC, PWM, and others, are shown at specific pins to comply with the Curiosity Nano Board standard. These signals can usually be routed to alternate pins using the Peripheral Pin Select (PPS) feature in the dsPIC33CK256MC005.

2. Board Features


Features of Curiosity Nano, board layout picture, board block diagram, and Curiosity Nano pinout standard.

2.1. Board Features

- dsPIC33CK256MC005 Microcontroller
- On-Board Nano Debugger
 - Programming and debugging
 - Virtual serial port via USB CDC
 - Green power and status LED
 - One debug GPIO channel (DGI GPIO)
 - Board identification in Microchip development environments
- Power and Connectivity
 - USB Type-C® for power and data
 - Adjustable target voltage (3.0–3.6V, up to 500 mA) controlled by the on-board debugger
- Hardware Peripherals
 - Yellow user LED
 - Mechanical user switch
 - 8MHz MEMS Oscillator
- Curiosity Nano Edge Connector
 - Sockets into Curiosity Nano baseboards
 - Staggered layout for press-fit pin headers
 - Breadboard compatible
 - Castellated edges for surface mounting


2.2. Board Overview

Figure 2-1. dsPIC33CK256MC005 Curiosity Nano Board Overview



2.3. Block Diagram

Figure 2-2. dsPIC33CK256MC005 Curiosity Nano Board Block Diagram



2.4. Curiosity Nano Pinout

All Curiosity Nano boards follow a standardized pinout for key functions, as illustrated in the image below. Specific pins are reserved for the debugger interface, which supports programming protocols such as UPDI, SWD, or ICSP. Additional dedicated pins are provided for the CDC virtual serial port and the Data Gateway Interface (DGI).

Serial communication interfaces are consistently mapped to designated pins:

- UART
- I2C
- SPI

The CDC UART may share pins with the serial communication section, be available on dedicated pins located directly below the serial section, or, in some cases, be accessible only through the debugger section.


Analog capability is guaranteed only for pins within the analog section. At least two of these pins support PWM output, and some kits may offer a third optional PWM pin.

The placement and availability of additional features, such as extra serial or analog functions, may vary depending on the specific Curiosity Nano board. For this reason, only GPIO functionality is guaranteed for pins outside the sections mentioned above.



Tip: The location of debugger, serial communication, and analog pins on the edge connector is consistent across all Curiosity Nano boards, ensuring compatibility and ease of use.

Figure 2-3. Curiosity Nano Pinout



Info: Features shown in parentheses are optional and may not be available on all Curiosity Nano boards.

3. Setup Essentials

Step-by-step project setup and pin-header assembly instructions.

3.1. Quick Start


1. Choose your preferred integrated development environment (IDE):
 - MPLAB® Tools for VS Code®
 - Partner Toolchains: Microchip supports a range of partner toolchains. For more information and a list of supported tools, visit the [Development Tool Partners](#) page.
2. For VS Code follow these steps:
 - a. Download and install [VS Code](#) for your operating system.
 - b. Install [MPLAB Tools for VS Code](#).
 - c. Browse and select an example project using [MPLAB® Discover](#)
 - d. Download and open the selected example project in VS Code.
 - e. Connect the dsPIC33CK256MC005 Curiosity Nano to your computer using a USB cable.
 - f. Program the target device with the example code using MPLAB Tools for VS Code.
 - g. Refer to this [this guide](#) for tips and tricks on using the extensions.

Next Steps

- Explore additional example projects in [MPLAB® Discover](#) and try customizing them for your application
- Use the dsPIC33CK256MC005 Curiosity Nano with a Curiosity Nano Base Board:
 - [Curiosity Nano Explorer](#)
 - [Curiosity Nano Base for Click Boards™](#)
- Monitor data output:
 - Use the integrated terminal in VS Code or your preferred terminal to access the UART interface on your board
 - For advanced data monitoring and visualization, use [MPLAB Data Visualizer](#)



Tip: Take a look at [this](#) free Microchip University course.



The Curiosity Nano platform enables rapid prototyping and includes built-in debugging for working with new microcontrollers.

3.2. Using Pin Headers

The edge connector footprint on the dsPIC33CK256MC005 Curiosity Nano has a staggered design, where each hole is shifted 8 mils (~0.2 mm) off-center. This hole shift allows the use of standard 100 mil pin headers without soldering them to the board. The pin headers can be used in applications such as pin sockets and prototyping boards once they are firmly in place.

Figure 3-1. Connecting Curiosity Nano Board to Base Board Using Pin Headers**Tip:**

- Start at one end of the pin header and gradually insert the header along the length of the board. Once all the pins are in place, use a flat surface to push them in.
- For applications that permanently use pin headers, it is still recommended to solder them in place
- Once the pin headers are in place, they are difficult to remove by hand. Use a set of pliers and carefully remove the pin headers to avoid damage to the headers, the PCB, or yourself.

4. On-Board Nano Debugger

This section describes the features and interfaces of the on-board debugger for programming and debugging.

4.1. Overview

The dsPIC33CK256MC005 Curiosity Nano features an on-board Nano Debugger for programming and debugging. When connected to a host computer, the Nano Debugger appears as a composite USB device offering several interfaces:

- **Debugger:** Enables programming and debugging of the target device.
- **Virtual serial port (CDC):** Provides access to the target device's UART interface.
- **Data Gateway Interface (DGI):** Microchip's proprietary interface for streaming data to the host computer.
- **Mass storage device:** Provides kit information files and supports utility commands.



Tip: For detailed instructions and advanced features, refer to the [Nano Debugger Manual](#).

4.2. Power and Status LED

The on-board debugger controls a Power and Status LED (marked PS) on the dsPIC33CK256MC005 Curiosity Nano board. The table below shows how the different operation modes control the LED.

Table 4-1. On-Board Debugger LED Control

Operation Mode	Power and Status LED
Boot Loader mode	The LED blinks slowly during power-up
Power-up	The LED is ON
Normal operation	The LED is ON
Programming	Activity indicator: The LED blinks slowly during programming or debugging
Fault	The LED blinks rapidly if a power fault is detected
Off	When the on-board debugger is powered down, the LED is OFF



Info: Slow blinking is approximately 1 Hz, while rapid blinking is about 5 Hz.

4.3. Connections


The table below lists the connections between the target device and the debugger. When the debugger is inactive, these connections are set to high-impedance (tri-state) mode. This allows users to use these pins for any function without interference from the debugger. The debugger lines include series resistors to prevent short-circuits and potential damage to the target I/O pins when both the debugger and target attempt to drive a pin simultaneously.



Info: The 12 edge connections closest to the debugger USB connector have a standardized pinout, but the function of the programming and debugging pins varies depending on the programming interface used.

Table 4-2. On-Board Debugger Connections

Debugger Pin	dsPIC33CK256MC005 Pin		Description
CDC TX	RC11	UART RX	USB CDC TX line
CDC RX	RC10	UART TX	USB CDC RX line
DBG0	RB5	ICSPDAT	Debug data line
DBG1	RB6	ICSPCLK	Debug clock line
DBG2	RD13	GPIO0	Debug GPIO0/SW0
DBG3	MCLR	MCLR	Reset line
VTG	—	—	Target voltage
VOFF	—	—	Pull VOFF low to disable the on-board regulator and allow external power on VTG; VOFF is monitored by the debugger
ID	—	—	Identification of supported base boards and extensions at power-up

Figure 4-1. Curiosity Nano Debugger Pinout

Tip: For the complete dsPIC33CK256MC005 Curiosity Nano pinout, see the [dsPIC33CK256MC005 Curiosity Nano Pinout](#).

4.4. Disconnecting the On-Board Debugger

All signals between the on-board debugger and the target device are routed through cut straps on the bottom of the board. These cut straps can be used to disconnect the debugger from the target for various purposes, such as:


- Evaluating the target device's power consumption in isolation removes the on-board debugger's influence on current measurements
- Using the target device with an external programmer/debugger
- Using the on-board debugger as a standalone programmer/debugger for other devices

The following cut straps are available to separate the debugger from the target:

- Debugger Pins (J101, J102, J103, J104, J105, J106)
- [Power](#)



Attention: Cutting the GPIO straps to the on-board debugger disables the virtual serial port, programming, debugging, and data streaming functions.

Figure 4-2. Curiosity Nano Debugger Cut Straps

Tip: To reconnect any cut connections, use solder or mount a 0 Ω 0402-size resistor across the cut strap.

4.5. Connecting External Debuggers

Although the board includes an on-board debugger, external debuggers can also be connected directly to the target device for programming and debugging. When the on-board debugger is not actively in use, it keeps all pins connected to the board edge and the target device in a tri-state condition. This ensures that the on-board debugger does not interfere with any external debug tools.

Figure 4-3. Connecting an External Debugger/Programmer to a Curiosity Nano Board

**MPLAB® PICKit®
SIL Connector (UPDI)**

1	RESET	DBG3
2	VDD	VTG
3	GND	GND
4	UPDI	DBG0
5		
6		
7		
8		

**MPLAB® PICKit®
SIL Connector (ICSP)**


1	MCLR	DBG3
2	VDD	VTG
3	GND	GND
4	ICSPDAT	DBG0
5	ICSPCLK	DBG1
6		
7		
8		

**MPLAB® PICKit®
SIL Connector (SWD)**

1	RESET	DBG3
2	VDD	VTG
3	GND	GND
4		
5	SWCLK	DBG1
6		
7		
8	SWDIO	DBG0

**CORTEX® SWD
2x5 Connector**

VTG	VDD	1	2	SWDIO	DBG0
GND	GND	3	4	SWCLK	DBG1
GND	GND	5	6		
		7	8		
		9	10	RESET	DBG3



The MPLAB® PICKit™ 5 In-circuit Debugger/Programmer can deliver high voltage on the $\overline{\text{MCLR}}$ pin. High voltage can permanently damage R102. If R102 is broken, the on-board debugger cannot enter the programming mode of the dsPIC33CK256MC005 and will typically fail at reading the device ID.



To prevent contention, do not use the on-board debugger for programming or debugging while the external debugger is connected.

5. Hardware Peripherals

Kit hardware peripherals overview.

5.1. LED

One yellow user LED is available on the dsPIC33CK256MC005 Curiosity Nano board. It can be controlled by either GPIO or PWM. Driving the connected I/O line to GND will activate the LED.

Figure 5-1. dsPIC33CK256MC005 Curiosity Nano LED0 Block Diagram





Table 5-1. LED Connection

dsPIC33CK256MC005 Pin	Description	Default Connection
RD10	User LED (yellow), active low	- LED0 - Edge connector

5.2. Mechanical Switch

The dsPIC33CK256MC005 Curiosity Nano board has one mechanical switch - a generic, user-configurable switch. Pressing it connects the I/O pin to ground (GND).

Figure 5-2. dsPIC33CK256MC005 Curiosity Nano SW0 Block Diagram



Tip: There is no externally connected pull-up resistor on the switch. Enable the internal pull-up resistor on Pin RD13 to use it.

Table 5-2. Mechanical Switch Connection

dsPIC33CK256MC005 Pin	Description	Default Connection
RD13	User switch (SW0), supports DGI event monitoring	- SW0 - Edge connector On-board debugger



5.3. MEMS Oscillator

The dsPIC33CK256MC005 Curiosity Nano is equipped with an 8 MHz MEMS oscillator. By default, the MEMS oscillator is not connected to the dsPIC33CK256MC005 because the associated GPIOs are routed to the edge connector. Therefore, hardware modifications are required to enable the use of the MEMS oscillator.

The MEMS oscillator Y1 (MCHP clock oscillator, single 8.000 MHz, DSC6011J12B-008.0000) and the capacitor C8 (TDK C1005X7R1E104K050BB), or comparable parts, are populated on the board. The I/O line routed to the edge connector should be disconnected to reduce the chance of contention with the MEMS and to remove excessive capacitance on the line. This can be done by cutting the strap on the bottom side of the board, marked RB0, as shown in [Figure 5-3](#). Next, add solder to the solder point next to the MEMS on the top side of the board, as shown in [Figure 5-4](#).

Table 5-3. MEMS I/O

dsPIC33CK256MC005	Function	Shared Functionality
RB0	OSCI	Edge connector

Figure 5-3. RB0**Figure 5-4.** Solder Point Location


6. Power Supply

The USB port serves as the primary power source for the board. The power supply uses two LDO regulators: A fixed 3.3V regulator for the on-board debugger and an adjustable regulator for the target device and its peripherals.

When the USB is connected, there is a 1 ms start-up delay before power is applied, and a dedicated current-limiting IC restricts the supply current to approximately 500 mA to protect the board and connected devices. The figure below shows the full power supply design of the dsPIC33CK256MC005 Curiosity Nano.

The maximum input voltage to the target device depends on both the USB input voltage and the on-board debugger's configuration. While the debugger can be set to allow up to 5.5V, the actual voltage will never exceed the USB input, which typically ranges from 4.4V to 5.25V. The lower of these two values determines the maximum voltage available to the target device.

Figure 6-1. Power Supply Block Diagram




6.1. Target Regulator

The [MIC5353](#) variable output LDO supplies power to the target section. The on-board debugger controls the regulator's output voltage by adjusting its feedback. The on-board debugger restricts the output voltage to the safe operating range of the dsPIC33CK256MC005 (3.0–3.6V).

By default, the board is configured to run at 3.3V. This setting can be changed in Microchip IDEs, and any changes made will persist through power cycles. The board voltage can be adjusted using one of the following methods:

- **Microchip IDE:** Configure the voltage setting in the IDE. Voltage changes are applied when the debugger is accessed (e.g., during programming, reading memory, or refreshing tool status).
- **Drag-and-drop command files:** Set common voltages quickly using command files. For details, see [Nano Debugger Manual](#).
- **pymcuprog:** Use the [pymcuprog](#) tool to set the board voltage

The MIC5353 can supply up to 500 mA, but the actual maximum current may be lower due to thermal shutdown, which depends on input voltage, output voltage, and ambient temperature. The figure below illustrates the maximum output current limits of the regulator at a 5.1V input and 23°C ambient temperature.

Figure 6-2. MIC5353 Maximum Output Current vs. Output Voltage at 5.1V Input, 23°C Ambient

The on-board debugger monitors target voltage. If the voltage deviates by more than ± 100 mV from the set target voltage, or if external voltage is applied to VTG without VOFF pulled low, the on-board debugger disables the regulator and blinks the status LED rapidly. See the [Nano Debugger Manual](#) for more details.

6.2. External Supply

The dsPIC33CK256MC005 Curiosity Nano can be powered by an external voltage through the VTG pin, as an alternative to the on-board target regulator.

To safely use external power, follow these steps:

- Pull the VOFF pin to GND to disable the on-board regulator
- Apply external voltage to the VTG pin



WARNING

- Never apply voltage to VOFF; leave it floating to enable the on-board supply
- Only apply external voltage to VTG after pulling VOFF to GND. Failing to do so may cause damage to the board

The on-board debugger monitors the supplied voltage. If VOFF is not pulled to ground and the external voltage differs by more than ± 100 mV from the regulator setting, the debugger disables the regulator and begins blinking the status LED rapidly. When the voltage returns to within ± 100 mV, normal operation resumes and the LED stops blinking.

Programming, debugging, and data streaming with external power are only supported when the USB cable is connected, as it supplies power to the debugger and level shifters. With the USB connected, about 100 μ A is drawn from the external supply for level shifters and voltage monitoring. If the USB cable is disconnected, the level shifters may draw up to 5 μ A (typically as little as 100 nA).

Table 6-1. Voltage Limits

Parameter	Value
dsPIC33CK256MC005 operating range	3.0–3.6V

Table 6-1. Voltage Limits (continued)

Parameter	Value
Absolute maximum external voltage	5.5V




WARNING Exceeding these limits may result in permanent damage to the board.

6.3. VBUS Output Pin

The dsPIC33CK256MC005 Curiosity Nano provides a VBUS output pin that supplies 5V for powering external components. The VBUS voltage is not regulated and directly follows the USB input voltage, which may vary depending on the USB source. VBUS is protected by the same start-up delay and current limiting described in the [Power Supply](#) chapter. Be aware that as the current load on the VBUS output increases, the output voltage may decrease. The chart below illustrates how the VBUS output voltage varies with different current loads.

Figure 6-3. Load Current Impact on VBUS Output Voltage at 5V USB



6.4. Cut Straps

Curiosity Nano boards feature two cut straps for power measurement and isolation:

J200 - Power Supply Strap:


Cutting this strap fully separates the target power from the level shifters and on-board power supply. This allows for accurate current measurements when using an external power supply.



Info: Leakage back through the load switch is in the microampere range.

J201 - Target Power Strap:

For current measurements using the on-board power supply, cut this strap to measure the current drawn by the target. A 100 mil pin header can be mounted to J201 for easier connection of a measuring instrument.

Figure 6-4. Power Supply Cut Straps

6.5. Low-Power Measurement

Power for the target device is supplied via the on-board regulator or the VTG pin, routed through the Target Power Strap J201. To accurately measure the current consumption of the target device and any connected peripherals, cut the [Target Power Strap \(J201\)](#) on the bottom side and connect an ammeter across it.

To measure the minimum power consumption of the target device, follow these steps:

1. Cut the Target Power Strap (J201) with a sharp tool.
2. Solder a 1x2 100 mil pin header into the footprint.
3. Connect an ammeter across the pin header.
4. Write firmware that:
 - a. Tri-states any I/O connected to the on-board debugger.
 - b. Sets the target device in its lowest power sleep mode.
5. Program the firmware into the target device.
6. Measure the current draw.

The five on-board level shifters can each leak up to 2 μ A, totaling up to 10 μ A. To reduce leakage, keep the I/O pins to the level shifters tri-stated. For full isolation, disconnect the level shifters as described [here](#). With the USB connected, the level shifters and voltage monitoring draw about 100 μ A; with the USB disconnected, leakage drops to 5 μ A or less.

6.6. Power Supply Exceptions

This section summarizes most issues that can arise with the power supply.

Target Voltage Shuts Down

If the target draws too much current, the MIC5353 regulator may trigger thermal shutdown. Reduce the load to restore operation.

Target Voltage Setting is Not Reached

The MIC5353 output is limited by the USB input voltage (4.4–5.25V). If the set voltage isn't reached, use a higher-quality USB source or supply external voltage via the VTG pin.

Target Voltage is Different From Setting

Applying external voltage to VTG without pulling VOFF low can cause voltage mismatch. If the voltage deviates by more than ± 100 mV, the debugger disables the regulator and the PS LED blinks rapidly. Remove the external voltage to restore normal operation.

No or Very Low Target Voltage and PS LED is Blinking Rapidly

A full or partial short circuit can cause this and is a specific case of the issue above. Remove the short circuit, and the on-board debugger will re-enable the on-board target voltage regulator.

No Target Voltage and PS LED is Lit (Case 1)

This situation occurs if the target voltage is set to 0.0V. To fix this, set the target voltage to a value within the specified voltage range for the target device.

No Target Voltage and PS LED is Lit (Case 2)

This situation can occur when cutting the Power Supply Strap (J200) and/or the Target Power Strap (J201) and leaving them open. Restore the connection by bridging or adding a jumper.

VBUS Output Voltage is Low or Not Present

Excessive current on VBUS triggers the [MIC2009](#) current limit, cutting off VBUS. Reduce the load to restore output.

7. Hardware Revision History and Known Issues

Provides information about the latest board revision, known issues, and differences from previous versions.

7.1. Identifying Product ID and Revision

There are two ways to find the revision and product identifier of the dsPIC33CK256MC005 Curiosity Nano: the kit window in your Microchip development environment or the sticker on the bottom of the PCB.

The kit window appears in Microchip development environments when the dsPIC33CK256MC005 Curiosity Nano is connected to the computer. In the VS Code® environment, the kit window is accessed through the tool window.

The first nine digits of the serial number, listed under kit information, contain the product identifier and revision.



Tip: If closed, the Kit Window can be opened in VS Code® using the Command Palette (**Ctrl + Shift + P**) and typing the command **MPLAB: Show kits view**.

The same information is found on the sticker on the bottom side of the PCB. The data matrix code on the sticker contains a string with the product identifier 02-01628, revision, and serial number.

The string in the data matrix code has the following format:

```
nnnnnnnnrrfffsssss
```

n = product identifier

r = revision

f = fabrication code

s = serial number

8. Document Revision History

Revision A (May 2026)


This is the initial version of the document.

9. Appendix

The Appendix contains the product's Schematic, Assembly Drawing, Pinout Mapping and Bill of Materials.

9.1. Schematic

Figure 9-1. dsPIC33CK256MC005 Curiosity Nano Device Schematic



9.2. Assembly Drawing

Figure 9-3. dsPIC33CK256MC005 Curiosity Nano Assembly Drawing Top






Figure 9-4. dsPIC33CK256MC005 Curiosity Nano Assembly Drawing Bottom




9.3. Curiosity Nano Explorer


Figure 9-5. Curiosity Nano Explorer Pinout Mapping



Curiosity Nano Explorer Mapping



mikroBUS™ Socket



9.5. Bill of Materials

Figure 9-7. dsPIC33CK256MC005 Curiosity Nano Bill of Materials

Bill of Materials		dsPIC33CK256MC005 Curiosity Nano	
Part Number: EV08P02A Assy Number: 02-01628 PCB Number: 04-12659 Assy Revision: 1 Creation Date: 12/5/2025		M	
Designator	Description	Manufacturer	Part Number
C1, C100, C101, C102, C104, C105, C201, C202, C207, C208	CAP CER 0.1uF 16V 10% X7R SMD 0402	Samsung Electro-Mechanics	CL05B104KO5NNNC
C103, C200, C203, C204	CAP CER 2.2uF 10V 10% X5R SMD 0402	Samsung Electro-Mechanics	CL05A225KP5NSNC
C205	CAP CER 4.7uF 10V 10% X5R SMD 0603	Samsung Electro-Mechanics	CL10A475KP8NNNC
C209	CAP CER 1uF 6.3V 10% X5R SMD 0402	KEMET	C0402C105K9PACTU
D100	LED YELLOW DIFFUSED 1608 SMD	ROHM	SML-D12Y1WT86
D200	DIO LED YELLOW-GREEN 2.2V 20mA 25mcd Clear SMD 0402	ROHM	SML-P12MTT86R
J203	CON USB2.0 Type-C Female SMD R/A	KLS Electronic	KLS1-5409
Q200	TRANS FET N-CH DMN65D8LFB-7B 260mA 60V 430mW X1 DFN1006-3	Diodes Inc.®	DMN65D8LFB-7B
Q201	TRANS FET P-CH CSD25501F3 -20V -3.6A 0.076R LGA	Texas Instruments	CSD25501F3T
R100, R101, R102, R200, R201, R202, R203, R204, R205, R207, R210, R213, R214	RES TKF 47k 1% 1/16W SMD 0402	Yageo Group	RC0402FR-0747KL
R103, R104, R209, R212, R215, R218	RES TKF 1k 1% 1/10W SMD 0402	Panasonic	ERJ-2RKF1001X
R105	RES TKF 0R 1/16W SMD 0402	Stackpole Electronics	RMCF0402ZT0R00
R206	RES TKF 27k 1% 1/16W SMD 0402	Yageo Group	RC0402FR-0727KL
R208	RES TKF 33k 1% 1/16W SMD 0402	Yageo Group	AC0402FR-0733KL
R211	RES TKF 330R 1% 1/10W SMD 0402 AEC-Q200	Panasonic	ERJ-2RKF3300X
R216, R217	RES TKF 5.1k 1% 1/10W SMD 0402	Panasonic	ERJ-2RKF5101X
SW100	SWITCH TACT SPST 12 50mA TS604VM1-035CR-R SMD	Dailywell Electronics Co., Ltd.®	TS604VM1-035CR-R
Test2	FW, CNANO-DEBUGGER		
TEST FIXTURE1	Curiosity Nano Test Fixture	Raynen®	MCHP 15-00009
U204, U205, U207, U208, U209	IC VOLTAGE TRANSLATOR BI-DIR 1 CIRCUIT 74LVC1T45FW4-7 X2-DFN1010-6	Diodes Inc.	74LVC1T45FW4-7
Microchip Parts			
U100	MCHP MCU 16-BIT 100MIPS 256k 16k dsPIC33CK256MC005-I/PT TQFP-48	Microchip Technology	dsPIC33CK256MC005-I/PT
U200	MCHP ANALOG LDO ADJ 500mA MIC5353YMT-TR MLF-6	Microchip	MIC5353YMT-TR
U201	IC LOAD SWITCH HI SIDE 3A 6WLCSP	Microchip	MIC94163YCS-TR
U202	MCHP ANALOG POWER SWITCH 5.5V 2A MIC2009YML-TR MLF-6	Microchip	MIC2009YML-TR
U203	MCHP ANALOG LDO 3.3V MIC5528-3.3YMT-TR 6-TDFN	Microchip	MIC5528-3.3YMT-TR
U206	MCHP MCU 32-BIT 48MHz 256Kb 32Kb ATSAMD21E18A-MUT QFN-32	Microchip	ATSAMD21E18A-MUT
Y1	MCHP CLOCK OSCILLATOR SINGLE 8.000MHz DSC6011J12B-008.0000 VDFN-4	Microchip	DSC6011J12B-008.0000
Mechanical Parts			
LABEL1	LABEL PCBA 18x6mm Datamatrix Assy# / Rev / Serial / Date	ACT Logimark AS®	505462

Microchip Information

Trademarks

The “Microchip” name and logo, the “M” logo, and other names, logos, and brands are registered and unregistered trademarks of Microchip Technology Incorporated or its affiliates and/or subsidiaries in the United States and/or other countries (“Microchip Trademarks”). Information regarding Microchip Trademarks can be found at <https://www.microchip.com/en-us/about/legal-information/microchip-trademarks>.

Legal Notice

This publication and the information herein may be used only with Microchip products, including to design, test, and integrate Microchip products with your application. Use of this information in any other manner violates these terms. Information regarding device applications is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. Contact your local Microchip sales office for additional support or, obtain additional support at www.microchip.com/en-us/support/design-help/client-support-services.

THIS INFORMATION IS PROVIDED BY MICROCHIP “AS IS”. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, OR WARRANTIES RELATED TO ITS CONDITION, QUALITY, OR PERFORMANCE.

IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL LOSS, DAMAGE, COST, OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE INFORMATION OR ITS USE, HOWEVER CAUSED, EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP’S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THE INFORMATION OR ITS USE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THE INFORMATION.

Use of Microchip devices in life support and/or safety applications is entirely at the buyer’s risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip products:

- Microchip products meet the specifications contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is secure when used in the intended manner, within operating specifications, and under normal conditions.
- Microchip values and aggressively protects its intellectual property rights. Attempts to breach the code protection features of Microchip products are strictly prohibited and may violate the Digital Millennium Copyright Act.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of its code. Code protection does not mean that we are guaranteeing the product is “unbreakable”. Code protection is constantly evolving. Microchip is committed to continuously improving the code protection features of our products.