

Bluetooth LE module RYZ012x1

Bluetooth qualification acquisition

Introduction

This document describes how to acquire *Bluetooth®* qualification for a product with a Bluetooth Low Energy (hereinafter "Bluetooth LE") technology compatible module (hereinafter "Module") RYZ012x1.

Target Device

- Module
 - RYZ012A1
 - RYZ012B1

Note: This document will be a possibility that the contents change with a renewal in Bluetooth SIG website and change in the Bluetooth Qualification Program from now on.

Contents

1. Overview	2
1.1 Contents	2
1.2 QDID of the qualified design	3
1.3 How to read the application note	4
2. Pre-formalities	5
2.1 Bluetooth SIG Members registration and acquisition of personal account	5
2.1.1 Register the company to members of Bluetooth SIG (no charge)	5
2.1.2 Acquisition of the account of the member company's employee (no charge)	9
2.2 Purchase of Declaration ID	11
3. Product Registration (Declaration)	14
3.1 Perform RF-PHY test	14
3.1.1 For RYZ012A1 mounted product	14
3.1.2 For RYZ012B1 mounted product	14
3.2 Registering a device that implements Module	15
3.2.1 Product registration (Declaration)	15
3.2.2 Add a Product	22
Revision History	23

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Renesas Electronics Corporation is under license. Other trademarks and trade names are those of their respective owners.

1. Overview

This application note describes how to register (Declaration) a product using a Qualified Design Identification number (QDID) of our qualified design when selling a device equipped with the Module as a Bluetooth products.

Bluetooth SIG prescribes that it is necessary to satisfy the giving requirements of Bluetooth license to sell a product using Bluetooth technology and a trademark. Please confirm the governance document with the following URL for details.

<https://www.bluetooth.com/about-us/governing-documents>

1.1 Contents

The package contents of this application note are shown below.

r01an5900xx0100-ryz012x1-btcert.zip	
└── r01an5900ej0100-ryz012x1-btcert.pdf	Application note (English)
└── r01an5900jj0100-ryz012x1-btcert.pdf	Application note (日本語)
└── RYZ012A1-RFPHY-CF.zip	
└── RYZ012A1-RFPHY-CF\	RYZ012A1 RF-PHY Compliance Folder ^{(*)1}
└── 0_Contents\	Contents manual storage
└── 1_PICS_PIXIT\	ICS / IXIT ^{(*)2} documents storage
└── 2_Test_Plan\	Test Plan documents storage
└── 3_Test_Report\	Test Report and RF test system output data storage
└── 4_Declaration\	SDoC/DoC ^{(*)3} documents storage

*1: The "Compliance Folder" is a set of certification documents that summarizes the technical documents and test reports specified in the Qualification Program Reference Document (PRD).

*2: ICS - Implementation Conformance Statement
IXIT - Implementation Extra Information for Testing

*3: SDoC - Supplier Declaration of Conformity
DoC - Declaration of Compliance

Figure 1-1 The package contents

1.2 QDID of the qualified design

Figure 1-2 descriptions the composition of the product type (Controller Subsystem / Host Subsystem) of referenced qualified design.




Figure 1-2 Product type composition

Table 1-1 descriptions the qualified designs to refer to when registering the Module mounted products. Please refer to "3. Product Registration (Declaration)" for how to refer the qualified design.

Table 1-1 The qualified designs referenced in the Module mounted products

Qualified Design ID (QDID)	Product Type	Spec Name	Listing Date
136037	Controller Subsystem	5.0	2019-07-15
160268	Host Subsystem	5.2	2020-12-23

1.3 How to read the application note

This application note will be easier to understand if you read it according to the flow of Figure 1-3 according to your purpose and conditions.




Figure 1-3 How to read the application note

2. Pre-formalities

It is describing the pre-formalities required to acquire Bluetooth qualification.

2.1 Bluetooth SIG Members registration and acquisition of personal account

Member registration to SIG is needed to use a license of Bluetooth and the brand. Operation on the web necessary to qualification acquisition and product registration (Declaration) becomes possible after member registration. This application note describes registration of "Adopter" member class.

2.1.1 Register the company to members of Bluetooth SIG (no charge)

(1) Display the following URL by the browser. Click the [Apply for Adopter Membership] button at the middle of the displayed [Become a Bluetooth SIG Member] page.

<https://www.bluetooth.com/develop-with-bluetooth/join>





Figure 2-1 [Apply for Adopter Membership] button

(2) Since the application page for Bluetooth SIG membership will be displayed, please check the details on the preparation described in [① Prepare your application materials].

- Copy of corporate registration (PDF).
- Power of attorney

If the applicant is different from the representative of the company, you may be asked for a power of attorney. Please prepare a letter of attorney in English that you can confirm that you have the authority to sign on behalf of the representative of the company. There is no official template, but the signature of the representative is mandatory.

(3) Select the country with [★ Start Here:] at the bottom of the same page, enter the applicant's Email address, and click the [Start Membership Application] button to display the form input page.]



Start Here:

Select the Country of Your Company's jurisdiction of formation: To get started, please use the drop down below to indicate the country of your company's jurisdiction of formation. You must select a country to continue.

Japan

If the country given here does not match the country on your company's formation documents you may be required to start the application process over.


[Get help on Jurisdiction Country.](#)

Enter Your Business email address: Start Membership Application

This email will be used to verify user applicants and register individual user accounts under your company's membership.

Figure 2-2 [Start Membership Application] button

(4) Check the contents of the displayed form and enter necessary information.



Membership Application Form

1 COMPANY INFO 2 YOUR INFO 3 ADDRESS(ES) 4 REVIEW DETAILS

Part 1: Company Information

Company's Legal Name * Required Cannot be left blank.

Entity Type * Corporation Limited Liability Company (Member Managed) Limited Liability Company (Manager Managed) Limited Partnership Other (explain)

Doing Business As / Trading As Optional


Business Identification Number Optional

Figure 2-3 Form input page

The form will be displayed in the order of [Part 1: Company Information] → [Part 2: My Information] → [Part 3: Office Locations].

For [Company's Legal Name] in [Part 1: Company Information], enter the name stated in the copy of corporate registration. [Company's Formation Documents] will upload the PDF file of the copy of corporate registration.

When you have completed all forms, click the [Review Application Details] button under the [Part 3: Office Locations] form to display the [Review, Sign, and Submit] page.



Postal Code * (i)


Country/Region * (i)

Business Phone * (i)

Previouss Review Application Details

Figure 2-4 [Review Application Details] button

(5) When the [Review, Sign, and Submit] page is displayed, confirm the input contents.



Bluetooth®

Membership Application Form

1 COMPANY INFO 2 YOUR INFO 3 ADDRESS(ES) 4 REVIEW DETAILS

Review, Sign, and Submit

MEMBERSHIP APPLICATION FORM

Company Information Edit My Information Edit

Company's Legal Name: 1234567890

Entity Type: Corporation

Name: 1234567890

Username: 1234567890

Job Title: 1234567890

Figure 2-5 [Review, Sign, and Submit] page

(6) If there is no error in the input content, move to the [Signature and Submission] below than middle of the page, confirm the contents of the declaration statement of the membership agreement, check the check box at the beginning.

Signature and Submission

kana sada ("Signing Agent") is the ippan of Legal Name ("Applicant Company"). By typing his or her name or other symbol of Signing Agent's signature in the Signature Field below, Signing Agent:

Personally certifies that the above information is true and correct, and Signing Agent has corrected any errors in the above information by using the "Edit" buttons;

Represents and warrants that Signing Agent has been duly authorized to submit this Membership Application on behalf of Applicant Company; and that Signing Agent has read, fully understands, and is duly authorized to bind Applicant Company to each of the following hyperlinked agreements (collectively, the "Membership Agreements"): (1) the [Bluetooth SIG Membership Commitment Agreement](#), (2) the [Bluetooth SIG Patent/Copyright License Agreement](#), and (3) the [Bluetooth SIG Trademark License Agreement](#).

Represents and warrants that Applicant Company does not, by its governing documents or other applicable law, require more than one signatory, a company stamp or seal, or a witnessed signature in order to be legally bound to the Membership Agreements.

Agrees on behalf of Signing Agent and Applicant Company to contract in English and electronically, adopts the characters or symbols input in the signature field below as Signing Agent's signature, with the same effect as an ink signature, and electronically signs each of the Membership Agreements.

Agrees, on behalf of Applicant Company, that Applicant Company will comply with the Membership Agreements.

Agrees to the [Bluetooth SIG Terms of Use \("TOU"\)](#) and that all use of any account issued to Signing Agent by Bluetooth SIG and Bluetooth SIG's websites and all applications, databases, software, plug-ins, test scripts, tools, and services that Signing Agent may access with his or her user account is subject to and will be in compliance with the TOU, the Membership Agreements, and all other policies and procedures of Bluetooth SIG.

Certifies that Signing Agent understands that the Membership Application Form is an offer by Applicant Company to enter into the Membership Agreements that may be accepted or rejected by Bluetooth SIG in its sole discretion and that Applicant Company will not become a member and Bluetooth SIG has not entered into the Membership Agreements with Applicant Company until Signing Agent receives a written notification (which may be by email) from Bluetooth SIG that Applicant Company's application has been accepted and membership issued.

If any of the foregoing is not correct or Signing Agent does not agree and certify to the foregoing, Signing Agent must exit the Membership Application Form without signing.

Figure 2-6 [Signature and Submission]

Finally sign the [Signature] text box under the declaration and click the [Signature Confirmed - Submit Application] button to complete the online process.

If any of the foregoing is not correct or Signing Agent does not agree and certify to the foregoing, Signing Agent must exit the Membership Application Form without signing.

Signature:

By:

Its:

Date: 2021-04-26

Figure 2-7 [Signature Confirmed - Submit Application] button

When the application is accepted, the applicant will receive an Email from the person in charge of the Bluetooth SIG, so please submit a power of attorney if requested.

2.1.2 Acquisition of the account of the member company's employee (no charge)

(1) Display the following URL by the browser. Click the [Click here] button of the [Employee User Accounts] at the bottom of the displayed page.

<https://www.bluetooth.com/develop-with-bluetooth/join>




Figure 2-8 Apply for employee user account

(2) In the text box on the displayed the [User Account Application] page, enter the Email address of the employee who applies for the account and click the [Submit Email Address] button.





Figure 2-9 [User Account Application] page

(3) A registration confirmation Email will be sent from the Bluetooth SIG to the account applicant. Click on the URL listed in the Email and enter the "My Information" on the opened WEB page.

(4) After completing the entry you will receive an Email asking for the creation of a password so please access the URL stated in the Email and complete the creation of the password. Acquisition of the employee's user account is complete with this.

(5) By clicking the [**Login**] at the upper left of <<https://www.bluetooth.com>> and entering the user name and password on the [Log In] page opened, you will be accessible to the member page.



The image shows a screenshot of a web browser displaying the 'Log In' page of the Bluetooth website. The page has a light gray background. At the top center, the word 'Log In' is displayed in a large, bold, black font. Below it, there are two input fields: 'Username' and 'Password', both containing placeholder text ('username' and 'password' respectively). To the right of the 'Password' field is a blue rectangular button with the text 'Log In' in white. Above this button is a small checkbox labeled 'Remember Me' with a checked mark. At the bottom of the page, there are two links: 'Forgot username or password?' and 'Help with logging in'. Below these links is a blue rectangular button with the text 'Not a Member? Join the SIG for Free'. At the very bottom, there is a small link: 'Is your company a Bluetooth SIG member? Create a user account.'

Figure 2-10 [Log In] page

2.2 Purchase of Declaration ID

When product registering (Declaration) by referring to the Qualified design, it is necessary to purchase Declaration ID. Below is the Web operation when the application company pays purchase cost directly to Bluetooth SIG.

Notes:

1. When requesting remittance to a certification body, please follow the instructions of the certification body.
2. For the purchase procedure, please use the same user account as "3. Product Registration (Declaration)" described later.

(1) After login to <<https://www.bluetooth.com>>, starting the Launch Studio from the following URL and select the [Manage Declaration IDs] tab.

<https://launchstudio.bluetooth.com>




Figure 2-11 [Manage Declaration IDs] tab

Click the "[fees page](#)" in the description to see the price of the Declaration ID.

Click the [Pay Declaration Fee] button on the left side to display the [Pay Declaration Fee] panel.

(2) Enter necessary items to the displayed [Pay Declaration Fee] panel.

- Select [Standard] for [Declaration Type].
- Enter "1" in [Quantity].

- In [Payment Method], select [Credit Card] or [Invoice]. The following input items change according to the selection contents of [Payment Method], so please enter the necessary items for each. Items related to company address are automatically entered from user account information.




Figure 2-12 [Pay Declaration Fee] panel

- (3) When all input is completed, click the completion button at the bottom of the panel. The completion button changes depending on the item selected in [Payment Method]. When [Credit Card] is selected, it becomes [Pay Declaration Fee], and if you select [Invoice] it will be [Create Invoice]. The payment procedure when [Credit Card] is selected is now complete.




Figure 2-13 [Pay Declaration Fee] button




Figure 2-14 [Create Invoice] button

Click on the [Create Invoice] button to open Invoice PDF file and save it. (The same invoice is also attached to the Email sent from the Bluetooth SIG to the Invoice applicant.)

Please make overseas remittance procedure to the account described in Invoice.

Note: Please write Invoice number "INVxxxx" of the top right of the Invoice in the telegram (message) column of the overseas remittance request form submit to the bank. If this number is not described, Issuance destination of the Declaration ID becomes the unknown.




Figure 2-15 Invoice sample

You can confirm the Declaration ID you purchased on the [Manage Declaration IDs] tab of the Launch Studio.

3. Product Registration (Declaration)

3.1 Perform RF-PHY test

Product registration (Declaration) cannot register a product whose design does not match the referenced qualified design. If there is a change in the design of the RF part, it is necessary to perform RF-PHY test at the Bluetooth Qualification Test Facility (BQTF) and obtain evidence to prove that there is no problem with the characteristics. If your product is subject to audit under Bluetooth SIG Enforcement and you are required to provide evidence, you will need to submit the evidence obtained.

3.1.1 For RYZ012A1 mounted product

RYZ012A1 has already obtained evidence to prove that there is no problem with its characteristics by perform RF-PHY test on the design changes of the RF part.

Please keep the compliance folder ("RYZ012A1-RFPHY-CF.zip" in "Figure 1-1 The package contents") included in the application note as evidence.

3.1.2 For RYZ012B1 mounted product

Since RYZ012B1 uses an external antenna, the RF pattern (including antenna change) from the RF output terminal to the antenna is different from RYZ012A1. Perform the RF-PHY test according to the following procedure for the design changes in the RF part.

(1) Supports the following Implementation requirements for the equipment under test (EUT)

- Operation with regulated power supply
- Wired connection using a coaxial connector such as SMA

(2) Ask BQTF for RF-PHY test and Bluetooth Qualification Consultants (BQC) support.
Select BQTF from the following URL.

<https://www.bluetooth.com/develop-with-bluetooth/qualification-listing/qualification-test-facilities>

(3) Submit the following information and data to BQTF

- Product Information (Product Name, Model Number, Product Description)
- ICS / IXIT
- Operating manual
- When correcting for loss of SMA conversion cable or pattern, inform each loss value

(4) Conducting the following two items RF-PHY test at BQTF

Table 3-1 QDID of Core Specification

Test Case ID (TCID)	Description
RF-PHY/RCV/BV-01-C	Receiver sensitivity
RF-PHY/TRM/BV-01-C	Output power

(5) Keep of compliance folder

The compliance folder will be sent from BQTF via an electronic medium (CD-R) or file transfer system after the test, so keep it with the compliance folder included in the application note ("RYZ012A1-RFPHY-CF.zip" in Figure 1-1 The package contents) as evidence.

3.2 Registering a device that implements Module

This section describes how to register (Declaration) a device mounted the Module as a Bluetooth product. Purchase of Declaration ID is required for product registration. Refer to "2.2 Purchase of Declaration ID" and perform necessary procedures.

3.2.1 Product registration (Declaration)

After purchasing the Declaration ID, please perform product registration operation on the Bluetooth SIG WEB site as follows.

- (1) After log In to <<https://www.bluetooth.com>>, starting the Launch Studio from the following URL and select the [Getting Started] tab.




Figure 3-1 [Getting Started] tab

(2) Click the [Start the Bluetooth Qualification Process with No Required Testing] button at the displayed [Getting Started] tab.




Figure 3-2 [Start the Bluetooth Qualification Process with No Required Testing] button

(3) Enter the basic information of the project on the displayed page.

The screenshot shows the 'Project Basics' input page. The title is 'Qualification Project with No Required Testing'. It includes fields for 'Project Name' (with a value of 'New Project') and 'Referenced Qualified Design' (with a search bar and a 'Search' button). Below the fields are buttons for 'Save and continue to Product Declaration' and 'Save All Changes'.

Figure 3-3 [Project Basics] input

- In [Project Name], enter any project name.

The image contains two screenshots of a web-based application for Bluetooth qualification. Both screenshots show the 'Project Basics' step of the process, specifically the 'Qualification Project with No Required Testing' section. The 'Referenced Qualified Design' field is highlighted with a red box. In the first screenshot, the input '136037' is shown, with a dropdown menu below it displaying '136037 | Controller Subsystem | Telink BLE Controller | Telink Semiconductor (Shanghai) Co., Ltd'. In the second screenshot, the input '160268' is shown, with a dropdown menu below it displaying '160268 | Host Subsystem | Telink BLE Host Subsystem | Telink Semiconductor (Shanghai) Co., Ltd'. Both screenshots also show a 'Save All Changes' button.

Figure 3-4 Referenced QDID input

- In "Referenced Qualified Design", enter the two QDIDs of "Table 1-1 The qualified designs referenced in the Module mounted products".

Project Basics > Product Declaration > Declaration ID > Review & Submit

Qualification Project with No Required Testing

Get help on this step [↗](#)

Project Name * LE Sample Project

Referenced Qualified Design *

Search by QDID [🔍](#) [?](#)

If you don't have this number, ask your supplier or [Search Listings](#).

136037 | Controller Subsystem | Telink BLE C [✖](#)

160268 | Host Subsystem | Telink BLE Host S [✖](#)

[Save and continue to Product Declaration](#) [↗](#) [Save All Changes](#)

Figure 3-5 [Save and continue to Product Declaration] button

- When input is completed, click the [Save and continue to Product Declaration] button in the lower left.

(4) When the [Product Declaration] page is displayed, set "Listing Date" (Date on which you want to display the registered product in the public list database) in the [Required for submission, YYYY-MM-DD] text box. "Listing Date" can also be set using the calendar displayed by clicking on the text box. Listing Date can be specified up to 90 days later.

Project Basics > **Product Declaration** > Declaration ID > Review & Submit

Product Declaration

Begin the Declaration Process by describing each of your products using the [Product Listing](#) feature.

Bluetooth technology.

Get help on this step [↗](#)

Listing Date * Required for submission, YYYY-MM-DD [?](#)

Figure 3-6 [Product Declaration] page

Click [+Add a Product] button displayed at the bottom of the page after setting "Listing Date".




Figure 3-7 [+Add a Product] button

The [Add/Edit products] panel will be displayed, please enter product information. When input is completed, click [Save] button.





Figure 3-8 [Add/Edit products] panel

(5) Confirm that the input contents are displayed in the product list and click the [Save and continue to Declaration ID] button.




The screenshot shows a table with a single row of data. The columns are: Product Name, Product Website, Product Category, Publish Date, Archive Date, Model Number, Subset ID, and Description. The data in the table is as follows:

Product Name	Product Website	Product Category	Publish Date	Archive Date	Model Number	Subset ID	Description
LE Sample Product	www.productwbsite.com	Unique Products	2021-06-30		LESP-01		Sample product with Bluetooth LE module RYZ012A1.

Below the table are three buttons: 'Save and return to Project Basics' (disabled), 'Save and continue to Declaration ID' (highlighted with a red box), and 'Save All Changes'.

Figure 3-9 Product List

(6) A list of available Declaration IDs is displayed. Select the ID to be used for this product registration and click the [Save and continue to Review] button.



The screenshot shows a table titled 'Available Declaration IDs' with two rows of data. The columns are: ID, Type, and Notes. The data in the table is as follows:

ID	Type	Notes
None		
D04-0000	Standard	

Below the table are three buttons: 'Save and return to Product Declaration' (disabled), 'Save and continue to Review' (highlighted with a red box), and 'Save All Changes'.

Figure 3-10 [Available Declaration IDs] list

(7) Since the [Review] page is displayed, confirm that the contents of [Project Details] are correct.

Figure 3-11 [Project Details]

If the contents are correct, check the declaration statement at the bottom of the page and check the check box at the beginning of the declaration statement.

Finally sign the [Signature] text box below the declaration and click the [Signature Confirmed - Complete Project & Submit Product (s) for Qualification] button to complete the online procedure.

Figure 3-12 [Signature Confirmed - Complete Project & Submit Product (s) for Qualification]

(8) After registration is complete, download SDoC / DoC and keep it in the compliance folder.

Registered products can be confirmed on the Launch Studio's [My Listings] tab.

3.2.2 Add a Product

This section describes how to add another device implementing the Module to the list registered (Declared) with "3.2.1".

- (1) After login to <<https://www.bluetooth.com>> using the same account as 3.2.1, to start Launch Studio from the following URL and select the [My Listings] tab.
<https://launchstudio.bluetooth.com>
- (2) Click the Declaration ID number of the list created in 3.2.1 to display the [Declaration Details] page.
- (3) Click the [+Add a Product] link on the left side of the page to start the "Add Products" process.
- (4) Click the [+Add a Product] button at the bottom of the displayed page.
- (5) The [Add/Edit products] panel will be displayed, please enter product information. When input is completed, click [Save] button.
- (6) Confirm that the input content is displayed in the product list and click [Continue to Review & Submit] button.
- (7) Since the [Review] page will be displayed, confirm that the contents of [Product Listing (s)] are correct.
If the contents are correct, check the declaration statement at the bottom of the page and check the check box at the beginning of the declaration statement.
Finally sign the [Signature] text box below the declaration statement and click the [Signature Confirmed - Complete Project & Submit Product (s) for Qualification] button to complete the online procedure.
- (8) After registration is complete, download SDoC / DoC and keep it in the compliance folder.

Revision History

Rev.	Date	Description	
		Page	Summary
1.00	Jun.30.21	–	First edition issued

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. **RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.**
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit: www.renesas.com/contact/.