



#### SNYPER-LTE+ / Spectrum Case Contents

- 1 SNYPER-LTE+ or SNYPER-LTE+ Spectrum
- 2 PSU with 4 Adapter Heads
- 3 0.5M USB Cable
- 4 USB Car Charger
- 5 Omni-directional Antennas – General Purpose (Blue) and 2600MHz (Silver/Grey)
- 6 LiveSCAN Directional Antenna (Spectrum model only)
- 7 1.5M Extension Cable for LiveSCAN Antenna (Spectrum model only)








## · FIRST STEP BEFORE USE

- **BATTERY CHARGE**  
Charge the unit for 4-6 hours or until the red charge light is extinguished.
- **SET TIME**
  - 1) Power up the SNYPER 
  - 2) Select 'Setup' from the 'Main Menu'
  - 3) Select 'Set Time'
  - 4) Use the keypad arrows to set date/timeUse  **BACK** key to exit
- **SOFTWARE UPDATE**  
Go to <https://www.siretta.com/snyper-plus> to check for latest software.
- Your SNYPER is now ready to use




## · SURVEY


- **NEW SURVEY OPTIONS**
  - 1) Select Full, LTE, UMTS or GSM\*
  - 2) Press  to start survey
  - 3) Leave device to complete survey

\*The SNYPER-LTE+ (USA) does not survey the GSM band.
- **POST SURVEY OPTION 1**
  - 1) Select 'Show Results'
  - 2) Press  to start LiveSCAN (Spectrum only)Use  **BACK** key to exit
- **POST SURVEY OPTION 2**
  - 1) Select 'Show Summary'Use  **BACK** key to exit
- **POST SURVEY OPTION 3**
  - 1) Select 'Save Results'This is only necessary if Auto Save is off  
Use  **BACK** key to exit


## · SAVED RESULTS

- **STORED SURVEY**
  - 1) Select results file you wish to view
  - 2) Select 'Show Results', 'Show Summary' or 'Export Results'Use  **BACK** key to exit


## · SETUP

- Language: ENG/DEU/FRA/ITA/SPA  
Display: Screen brightness and text colours  
Auto off: Auto switch off and dimming  
Documents: File types and Auto Save  
Sound: On/Off  
System: Mode and region of operation  
Set Time: Set date and time  
Reset Menu: Return to default settings  
Use  **BACK** key to exit

## · ABOUT

- Key reference parameters about the device  
Use  **BACK** key to exit

## · PC CONNECT

- **PC CONNECT**
  - 1) Connect USB cable between device and PC
  - 2) Select ON to enable USB connection, begin results download
  - 3) Copy files required to PC
  - 4) Select OFF to disable connectionUse  **BACK** key to exit  
You can then view results files on your PC

For more detailed information, please visit our website: [www.siretta.com](http://www.siretta.com)