

# CUR 4000

## Programming Environment

**cur|SENS**  
Technology

**Copyright, Warranty,  
and Limitation of  
Liability**

The information and data contained in this document are believed to be accurate and reliable. The software and proprietary information contained therein may be protected by copyright, patent, trademark and/ or other intellectual property rights of TDK-Micronas. All rights not expressly granted remain reserved by TDK-Micronas.

TDK-Micronas assumes no liability for errors and gives no warranty representation or guarantee regarding the suitability of its products for any particular purpose due to these specifications.

By this publication, TDK-Micronas does not assume responsibility for patent infringements or other rights of third parties which may result from its use. Commercial conditions, product availability and delivery are exclusively subject to the respective order confirmation.

Any information and data which may be provided in the document can and do vary in different applications, and actual performance may vary over time.

All operating parameters must be validated for each customer application by customers' technical experts. Any mention of target applications for our products is made without a claim for fit for purpose as this has to be checked at system level.

Any new issue of this document invalidates previous issues. TDK-Micronas reserves the right to review this document and to make changes to the document's content at any time without obligation to notify any person or entity of such revision or changes. For further advice please contact us directly.

Do not use our products in life-supporting systems, military, aviation, or aerospace applications! Unless explicitly agreed to otherwise in writing between the parties, TDK-Micronas' products are not designed, intended or authorized for use as components in systems intended for surgical implants into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the product could create a situation where personal injury or death could occur.

No part of this publication may be reproduced, photocopied, stored on a retrieval system or transmitted without the express written consent of TDK-Micronas.

**TDK-Micronas  
Trademarks**

– curSENS

**Third-Party Trademarks**

All other brand and product names or company names may be trademarks of their respective companies.

**License Notice**

All other brand and product names or company names may be trademarks of their respective companies.

## Contents

Page	Section	Title
4	1.	<b>General Information</b>
4	1.1.	Certification
4	1.2.	Support
5	2.	<b>Main Panel</b>
7	3.	<b>Sensor Settings</b>
8	3.1.	Customer Setup Tab
10	3.2.	Signal Path Tab
13	3.2.1.	Temperature Drift Compensation Tool
15	3.2.2.	Backend Data Channel
16	3.3.	Customer IDs Tab
17	3.4.	RAM Registers Tab
19	3.5.	Buttons Area
20	3.6.	Setpoints Panel
21	4.	<b>Calibration Tool</b>
21	4.1.	Two-Point Calibration
23	4.2.	Multi-Point Calibration
25	5.	<b>Linearization Tool</b>
27	6.	<b>Development Mode</b>
29	7.	<b>Measurement Tool</b>
31	8.	<b>Application Note History</b>

**Release Note:****Revision bars indicate significant changes to the previous edition.**

## 1. General Information

This document is intended as guidance for programming CUR 4000 sensors using TDK-Micronas programming software. Every functionality integrated in the soft- and hardware is described. The different tabs of the programming environment, the register settings and the tools are explained in detail. In combination with the respective data sheet and application notes "CUR 4000 Programming Guide" and "CUR 4000 User Manual" it represents the complete customer documentation of the CUR 4000 linear and differential sensor for current measuring applications.

### 1.1. Certification

TDK-Micronas GmbH fulfills the requirements of the international automotive standard IATF 16949 and is certified according to ISO 9001. This ISO standard is a worldwide accepted quality standard.

### 1.2. Support

We kindly ask you to register on <https://service.micronas.com> in order to obtain access to the workgroups for our various product families. Here you are able to get support by opening a support ticket.

TDK-Micronas GmbH – Application Engineering


Hans-Bunte-Strasse 19

D-79108 Freiburg im Breisgau

## 2. Main Panel

After successful installation of the CUR 4000 Programming Environment the application can be started by running the file “CUR\_4000.exe” from the Windows start menu.

The **Main** panel (see [Fig. 2-1](#)) of CUR 4000 Programming Environment will appear after the start. The application is already running on startup. By clicking the grey stop button below the application will be stopped.



**Fig. 2-1:** Main Panel of CUR 4000 Programming Environment

To rerun the stopped application the white arrow next to the stop button (see [Fig. 2-2](#)) has to be clicked.



**Fig. 2-2:** Menu Bar at Stopped Application

### COM-Port

Once the application is running, as a first step the proper COM-Port connecting the PC to the used programming device (TDK Magnetic Sensor Programmer) has to be selected. A drop-down menu lists all available COM-Ports and offers a functionality to refresh this list, in case a new device has been plugged into the PC.

### TDK SPI Programmer V1.x

In case of a connected TDK SPI Programmer V1.x the Programming device is automatically detected as HID and the COM-Port selection is not needed (grayed out).

### SPI Frequency

The SPI frequency has to be selected via the drop-down menu.

## VSUP ON/VSUP OFF

Clicking the VSUP ON button switches on the supply voltage of the sensor connected to the programming device. The software then automatically checks whether the connected sensor type is supported by the CUR 4000 Programming Environment by reading the HW\_ID register. In case the communication with the programming device has been successfully established and the connected sensor is supported, the button label changes to VSUP OFF and all grayed-out buttons on the **Main** panel are activated. The menu for COM-Port is disabled and grayed-out as long as the supply voltage is turned on. If no supported sensor is connected or the VSUP OFF button is pressed, the Programming Environment changes back to its original state and the supply voltage is switched off.

## Output Monitoring

The Output Monitoring feature indicates with green LEDs, which of the connected sensors (on channel 1, 2 or on both channels) are supported by the CUR 4000 Programming Environment and visualizes their current output status. It is automatically enabled after an errorless power-on of the supply voltage and stays active as long as the supply voltage is turned on and no functional tool has been selected. This is realized by continuously reading the OUT register of the active sensors and indicating them on a vertical scale bar (in % of full scale). Additionally the clamping levels which are programmed to the sensors are shown as blue areas on the scale bar, indicating the limits of the sensors' outputs. This feature allows the user to get a first impression of the sensor's output behavior resulting from the currently programmed parameters.

## Version Indication

In the lower right corner of the panel the currently used version number of the programming environment (SW) and the firmware of the programming device (FW) are displayed in case of a power-up.


Provided an errorless power-on of the supply voltage, the **Main** panel also gives access to the different functional tools of the CUR 4000 Programming Environment.

- Sensor Settings (see [Section 3](#))
- Calibration Tool (see [Section 4](#))
- Linearization Tool (see [Section 5](#))
- Development Mode (see [Section 6](#))
- Measurement Tool (see [Section 7](#))

In case one of these tools is selected a new panel shows up and the **Main** panel becomes inactive until the new panel is closed.

### 3. Sensor Settings

The **Sensor Settings** panel is used to configure the CUR 4000. It gives access to the customer relevant register settings of the connected sensor (see [Fig. 3-3](#)). Clicking the Sensor Settings button on the **Main** panel of the CUR 4000 Programming Environment opens the **Sensor Settings** panel.



**Fig. 3-3:** Sensor Settings Panel – Customer Setup Tab (2Z)

The panel is divided into several function-related areas and buttons, which are described hereinafter. Fundamentally the panel consists of four tabs: the **Customer Setup** tab, the **Signal Path** tab, the **Customer IDs** tab and the **RAM Registers** tab. The **Buttons Area** is located below these tabs (see [Fig. 3-16](#)).

#### Sensor Selection

On startup the panel dynamically enables the selective sensors in the selection menu on top of the **Sensor Settings** panel (see [Fig. 3-4](#)). In case two supported sensors are available Sensor 1 will be chosen by default, indicated by the green circle. The user can switch between communication with Sensor 1 and Sensor 2 by clicking the grey circle of the desired sensor, which will turn green. In case only one supported sensor is available the selection of the other sensor will be disabled and grayed-out.

After switching the selected sensor the sensor type indication in the lower left corner as well as the functions of the **Sensor Settings** panel are updated accordingly




**Fig. 3–4:** Sensor Selection

In addition on startup all available registers of the sensor are read and entered into the appropriate drop down menus or control elements.

### 3.1. Customer Setup Tab

The **Customer Setup Tab** is selected by default when the Sensor Settings panel is opened. It is divided into four different areas (see [Fig. 3–3](#)).

The drop-down menus in the upper left area show the current setup parameters of the frontend (see [Fig. 3–5](#)). The first drop-down menu allows the customer to switch the sampling frequency (low-pass filtering) between 2, 4, 8, and 16 kHz. With the second pull-down menu the user selects whether the registers IPC\_CHAN0 to IPC\_CHAN2 are updated independently or only after IPC\_CHAN0 is read. The third pull-down menu shows the predefined hall plate configuration. The menu cannot be changed by the customer and is disabled. The fourth pull-down menu only appears when the pre-defined hall plate configuration is a 2Z configuration. Z4 + Z1 or Z4 - Z1 are selectable.



**Fig. 3–5:** Customer Setup Tab – Setup Frontend (2Z)

The area directly below the frontend area has an influence on the setup of the setpoints. Fixed or variable setpoints are selectable via the drop-down menu.

For the linearization the CUR 4000 offers two different possibilities:

1. Fixed setpoints: the customer is able to configure 33 equidistant setpoints.
2. Variable setpoints: 19 non-equidistant setpoints are available, of which 17 are freely selectable.



**Fig. 3–6:** Customer Setup Tab – Setup Setpoints


Setup Supply Supervision is the third area on the left hand side of the **Customer Setup** tab. The supply supervision offers the possibility to set an over- and an undervoltage threshold for supervision of the external power supply. The overvoltage threshold must be greater than the undervoltage threshold. The thresholds have a length of 8 bits each with a step size of 100 mV.



**Fig. 3–7:** Customer Setup Tab – Setup Supply Supervision

On the right hand side the customer can configure the standby mode:

- Wake up by sleep counter: disabled/enabled
- external wake up: disabled/enabled
- OUT / CUST\_COMP\_CH1, CUST\_COMP\_CH2, CUST\_COMP\_CH3 threshold wake up: disabled/enabled; when enabled, it wakes up the system if at least one threshold is exceeded



**Fig. 3–8:** Customer Setup Tab – Setup Standby (left: 2Z, right: 6Z)

**Note:** It is mandatory to set the lock bit after the sensor was configured and programmed. After the customer lock is activated (by writing and power-on-reset), it is not possible to program the sensor anymore.

### 3.2. Signal Path Tab

The second tab is the **Signal Path** tab. It contains all parameters used for adjusting the signal path. The current content of the registers (including the registers covered in the other tabs) can be read out by clicking the button **Read All Registers**. New values can be stored by clicking the button **Write All Registers**. Above the signal path frontend area the customer gets access to the phase correction, LP-Filter and the registers MAG\_LOW and MAG\_HIGH. Via the frontend area itself, the customer can configure the offset and gain settings for channel 1, channel 2, and/or channel 3 and get access to the Temperature Drift Compensation Tool. Moreover the signal path backend, including e.g. SP\_OFFSET and SP\_GAIN, can be configured. For details about each stage of the signal path and the relation of the parameters and the signal path, please refer to the signal paths of the application note "CUR 4000 User Manual".




Fig. 3-9: Sensor Settings Panel - Signal Path Tab

#### Low-Pass Filter

The Low-Pass (LP) Filter is a first order digital infinite impulse response (IIR) filter to reduce the sampling noise. With the **LOW\_PASS\_FILTER** register value it is possible to select different  $-3$  dB (cutoff) frequencies for CUR 4000. The register is 16-bit organized. In the **Signal Path** tab the  $-3$  dB filter frequency can be directly entered in Hertz. The highest allowed  $-3$  dB frequency is half of the selected sampling frequency. To disable the filter set the value to 0.

### Magnetic Field Range

MAG\_LOW and MAG\_HIGH define the low and the high level for the magnetic field range check function. The magnetic field range check compares the AMPLITUDE register value with an upper and lower limit threshold defined by the registers MAG\_LOW and MAG\_HIGH. If either the lower or the upper limit is exceeded the sensor indicates it on the sensor's output (error band active; error can be read out via DIAG\_0[5:4]). The registers MAG\_LOW and MAG\_HIGH have a length of 16 bits and are two's complement-coded (-32768...32767).

An example of how to calculate MAG\_LOW for a given magnetic field amplitude in mT is given below (valid if no customer offset is used).

Assuming to set the magnetic field low threshold to 10 mT the MAG\_LOW register value is calculated as:

$$\text{MAG\_LOW} = \frac{(\text{Mag\_Low} \times 128 \frac{1}{\text{mT}})^2}{32768} = \frac{(10 \text{ mT} \times 128 \frac{1}{\text{mT}})^2}{32768} = 50 \quad (1)$$

Assuming to set the magnetic field high threshold to 90 mT the MAG\_HIGH register value is calculated as:

$$\text{MAG\_HIGH} = \frac{(\text{Mag\_High} \times 128 \frac{1}{\text{mT}})^2}{32768} = \frac{(90 \text{ mT} \times 128 \frac{1}{\text{mT}})^2}{32768} = 4050 \quad (2)$$

The accuracy of MAG\_LOW and MAG\_HIGH values depends mainly on the sensitivity. The variation of the sensitivity is specified in the data sheet and is roughly  $\pm 8\%$ .

Default values: MAG\_LOW = 0 and MAG\_HIGH = 32767.

---

**Note:** The Mag\_Low and Mag\_High limits have to consider the temperature drift.


---

### Customer Offset

OFFSET\_CH1\_0...2, OFFSET\_CH2\_0...2, and OFFSET\_CH3\_0...2 support three polynomials of second order and describe the temperature compensation of the offset of channel 1, channel 2, and channel 3 (compensating a remaining offset in each of the three channels). This means a constant, linear and quadratic offset factor can be programmed individually for the three channels (temperature dependent offset). TDK-Micronas delivers precalibrated sensors. Nevertheless it is possible that due to the magnetic circuit an offset in channel 1, channel 2, and channel 3 occurs. This can be compensated with OFFSET\_CH1\_0...2, OFFSET\_CH2\_0...2, and OFFSET\_CH3\_0...2. A temperature compensation can be done in the Temperature Drift Compensation Tool. The registers have a length of 16 bits and are two's complement-coded with a range from -32768 to 32767. Default value of 0 corresponds to the neutral value 0%.

### Customer Gain


GAIN\_CH1\_0...2, GAIN\_CH2\_0...2, and GAIN\_CH3\_0...2 support three polynomials of second order and describe the temperature compensation of the sensitivity of channel 1, channel 2, and channel 3 (compensating the amplitude mismatches between the channels). This means a constant, linear and quadratic gain factor can be programmed individually for the three channels (temperature dependent gain). TDK-Micronas delivers precalibrated sensors with compensated gain mismatch between channel 1, channel 2, and channel 3. Nevertheless due to the magnetic circuit, a mismatch between the gains of the channels may occur. This can be compensated by GAIN\_CH1\_0...2, GAIN\_CH2\_0...2, and GAIN\_CH3\_0...2. A temperature compensation can be done in the Temperature Drift Compensation Tool. The registers have a length of 16 bits and are two's complement coded with a range from -32768 to 32767. The value 0 corresponds to 0%. Default values are: GAIN\_CHx\_0 = 8192, GAIN\_CHx\_1 = 0 and GAIN\_CHx\_2 = 0. The number 8192 as default value arises from the processing in the signal path, this is then multiplied by factor 4.



**Fig. 3-10:** Signal Path Tab – Frontend

### 3.2.1. Temperature Drift Compensation Tool

By clicking the Temperature Drift Compensation Tool button the user is able to perform a temperature compensation for the parameters Offset and Gain using the following window.



**Fig. 3-11: Signal Path Tab - Frontend Temperature Drift Compensation Tool**

If an offset and gain is used in the signal path it may be necessary to adjust this parameter to the temperature behavior of the magnetic system.

After selecting the temperature dependent parameter the user has to enter the target value at room temperature. This is followed by the selection of the corresponding channels.

Then two methods for the compensation data are selectable via the drop-down menu.

#### Method 1: Enter Temperature Coefficient

In case the temperature behavior of the magnetic system is a linear function and is already known, this method can be chosen. The temperature coefficient TC in %/K can be entered below the drop-down menu of the compensation data selection.

By clicking Calculate, the corresponding EEPROM temperature coefficients are calculated and shown in the lower left corner.

#### Method 2: Read Temperature Behavior From File

In case the temperature behavior of the complete magnetic system is not sufficiently described by a linear function or not known, it is recommended to measure the parameter change over temperature. For this method a measurement file must be generated.

The file has to fulfill the following requirements:

1. The data format is a text file ".txt".
2. The columns are tab separated.
3. The file has 2 columns:

**Column 1**

The first column contains the temperature values (TEMP\_ADJ) in LSB (Least Significant Bit). These values can be directly read from the sensor by using the Measurement Tool and selecting the TEMP\_ADJ parameter.

It is also possible to convert the ambient temperature from °C into LSB by the following equation:

$$\text{TEMP\_ADJ} = \frac{89.25}{^{\circ}\text{C}} \times T + 3720 \quad (3)$$

**Column 2**

The second column includes the parameter values at the temperature values listed in column 1 in relation to the parameter value at room temperature (RT = 25 °C). By using the Measurement Tool the registers COMP\_CHx (for Offset and Gain) shall be acquired. The best method is to acquire the data over the full temperature range. For example, the following values were measured:

**Table 3-1:** Example for Offset Change on Channel 1 over Temperature

Temperature in °C	TEMP_ADJ in LSB	Offset of COMP_CH1 in LSB
-40	150	4260
25	5951	4000
150	17108	3500

In this example the unit of the offset is LSB, which is not mandatory. The parameters can be measured in any unit (e.g. in mT). After the measurements the parameter values at the different temperatures are normalized to the parameter value at room temperature. The final file should look like the table below:

$$\text{Normalized Parameter (T)} = \frac{\text{Parameter}(T)}{\text{Parameter}(RT)} \quad (4)$$

**Table 3-2:** Example for a Temperature Behavior File

TEMP_ADJ in LSB	Normalized Parameter
150	1.065
5951	1.000
17108	0.875

By clicking Calculate the created file has to be selected in the next window. Afterwards the corresponding EEPROM temperature coefficients are calculated and transferred to the **Signal Path** panel.

### 3.2.2. Backend Data Channel

For a better understanding of the relation between the parameters and the signal path the user is referred to the diagrams of the signal paths in the application note “CUR 4000 User Manual”.




Fig. 3-12: Signal Path Tab – Backend

#### SP\_OFFSET

The register SP\_OFFSET shifts the signal to the desired range of the subsequent Set-point Linearization blocks. SP\_OFFSET = 0 is the neutral setting. The register has a length of 16 bits and is two's complement-coded (-32768...32767). It is automatically calculated in the Calibration Tool.

#### SP\_Gain (SP\_GAIN and nmult)

The parameter SP\_Gain scales the signals to the desired range of the subsequent Set-point Linearization blocks. SP\_Gain = 1 is the neutral setting. The parameter SP\_Gain consists of the register value SP\_GAIN multiplied by  $2^{nmult}$  to achieve gain factors up to 128 (default factor 1). The register SP\_GAIN has a length of 16 bits and is two's complement-coded. SP\_GAIN and nmult are automatically calculated in the Calibration Tool. SP\_Gain must be entered as a multiplier (not in LSB).

#### OUT\_OFFSET and Out\_Gain

The final customer-programmable scaling blocks are used to scale the signal according to the desired output signal range. This is realized by the EEPROM registers OUT\_OFFSET and OUT\_GAIN. The registers have a length of 16 bits and are two's complement-coded. Default value for OUT\_OFFSET is 0 and default value for OUT\_Gain is 1 (OUT\_GAIN = 16348). In case of OUT\_Gain is smaller than 0 the output signal is inverted. OUT\_OFFSET must be entered in LSB and Out\_Gain must be entered as a multiplier. They are automatically calculated in the Calibration Tool.

#### CLAMP\_LOW and CLAMP\_HIGH

The clamping level registers CLAMP\_LOW and CLAMP\_HIGH establish the minimum and maximum value of the data channel's output signal. They can be used to define the diagnosis band for the sensor output. The active output format the clamping levels can have values between -32767 and 32767. Both registers have a length of 16 bits and are two's complement-coded (-32768...32767).

**Note:** Setting any clamping value to -32768 is not allowed.

### DNC Filter

The DNC (Dynamic Noise Cancellation) filter is a non-linear filter and can be used for further noise reduction in addition to the first order low-pass filters after the A/D-converters. It decreases the output noise significantly by adding a low-pass filter with a very low cutoff frequency for signals below a certain signal change threshold (dnc\_threshold).

The cutoff frequency dnc\_-3dB\_frequency of this IIR filter (Infinite Impulse Response low-pass filter) of first order can be entered in Hertz (up to half of the sampling frequency) into the programming environment.

---


**Note:** To disable the DNC filter the EEPROM setting dnc\_threshold or dnc\_-3dB\_frequency must be programmed to 0.

---

### 3.3. Customer IDs Tab

The next tab is the **Customer IDs** tab. The CUSTOMER\_IDx registers contain 16 bit words and can be used to store customer specific content/production information, like serial number, project information, OEM codes, etc. All configurable customer specific content is defined in CUSTOMER\_ID0...9.


The current content of the registers can be read out by clicking the button Read All Registers. New values can be stored by clicking the button Write All Registers. On the left hand side the customer gets access to the Customer IDs register values.



**Fig. 3–13:** Sensor Settings - Customer IDs Tab

### 3.4. RAM Registers Tab

Last tab is the **RAM Registers** tab (see [Fig. 3-14](#)). In this area certain RAM registers can be read by clicking the Read RAM button (read RAM registers once/continuously).



**Fig. 3-14:** Sensor Settings – RAM Registers Tab

#### COMP\_CH1...3

The COMP\_CH1...3 registers contain the magnetic field information of channel 1, channel 2, and channel 3 after temperature-drift compensation of the Hall plates. These registers have a length of 16 bits each and are two's complement-coded (–32768...32767).

#### CUST\_COMP\_CH1...3

CUST\_COMP\_CH1...3 registers contain the customer compensated magnetic field information of channel 1, channel 2, and channel 3. These registers contain data which has been customer gain and offset corrected and Low Pass filtered. These registers have a length of 16 bits each and are two's complement-coded (–32768...32767).

#### MIX\_OUT

MIX\_OUT contains the digital value of the mixed signal channels. The register has a length of 16 bits. The full range is between –32768 and 32767.

#### SETPOINT\_IN and SETPOINT\_OUT

The SETPOINT\_IN register contains the gain and offset corrected position information. The SETPOINT\_OUT register contains the position information after setpoint adjustment. Accordingly, SETPOINT\_IN is the input and SETPOINT\_OUT is the result of the setpoint linearization block.

## OUT

The OUT register contains the magnetic field data after final gain and offset adjustment and clamping. It has a length of 16 bits and is two's complement-coded (-32768...32767).


## AMPLITUDE

The AMPLITUDE register contains the sum of squares of TDK-Micronas compensated magnetic field values on channel 1 to 3. It has a length of 16 bits (0...32767).

For updating the RAM Area, click on Read RAM. If the check box continuously is checked, the data will be read in a loop. To leave the continuous reading mode, the continuously check box has to be unchecked.

## Decode Diagnosis Bits

Clicking the Decode Diagnosis Bits button enables an overview of the DIAG\_0 and DIAG\_1 register. The single bits are decoded via green LEDs. If an error occurred the LED lights up. For detailed information about the single bits refer to the memory tables of the application note "CUR 4000 User Manual".



**Fig. 3–15:** Sensor Settings - RAM Registers Tab Decode Diagnosis Bits

---

**Note:** Diagnosis bits are latched in programming mode. A power-on-reset is necessary to reset the bits.

---

### 3.5. Buttons Area

The **Buttons Area** below the tabs described in the previous sections is always visible and accessible from the **Sensor Settings** panel (see [Fig. 3-16](#)). They are referring to all of the sensor settings tabs.



**Fig. 3-16:** Sensor Settings - Buttons Area

#### Read All Registers

The signal path registers and customer setup parameters are read from the sensor.

#### Write All Registers

The signal path registers and customer setup parameters are written and stored in the sensor. After using the Write button a power-on-reset is recommended to boot the sensor with the new customer setup parameters.

#### Set Default Values

The signal path and customer setup parameters are set to default values. To program the sensor with default values click Write All Registers immediately afterwards.

#### Setpoints

The **Setpoints** panel appears for setpoint configuration. For detailed information refer to [Section 3.6](#).

#### Load EEPROM File

Reads the customer setup and signal path values from an EEPROM dump file (without the Micronas calibration area). The EEPROM dump file must correspond to the form described in Save EEPROM File.

#### Save EEPROM File

An EEPROM dump of all parameters will be generated and saved to a file. The file contains the register numbers and their contents (clarified by the header). The values in the file are tab separated. The Micronas calibration area is located below.

#### Power-On-Reset

Power-On-Reset (POR) triggers a full reset of the selected sensor.

#### LOCK


The customer lock bit can be set by clicking the LOCK button. If the LOCK button has been clicked the CRC checksum over all customer settings (EEPROM) is calculated and stored in CUSTOMER\_CHECKSUM. After the customer lock is activated (by writing and power-on-reset), it is not possible to program the sensor anymore.

#### EXIT

Returns to the **Main** panel (see [Fig. 2-1](#)).

### 3.6. Setpoints Panel

The **Setpoints** panel can be called via the button Setpoints on the **Sensor Settings** panel. It gives the user access to the programmable setpoint values, which are part of the setpoint scaling block(s) of the signal path. At startup the programmed setpoint values of the sensor selected in the **Sensors Settings** panel are read out and displayed graphically and numerically according to the setpoints configuration. The desired setpoints configuration has to be stored before opening the **Setpoints** panel.



**Fig. 3-17: Setpoints Panel - Absolute View of the Setpoint Values**


The graph visualizes the transfer curve of the setpoint scaling block by plotting the setpoint values. The user is able to change each setpoint value individually.

The following actions are possible:

- Read Setpoints: the current setpoint values are read out and displayed according to the selected configuration.
- Write Setpoints: the displayed setpoint values are programmed to the sensor.
- Set Default Setpoints: the default setpoint values (neutral) are set and displayed according to the selected configuration.
- Load Setpoint-File: the setpoint values are loaded from an external text file and displayed according to the selected configuration.
- Save Setpoint-File: an EEPROM dump of all parameters (including the setpoint values) will be generated and saved to a file. Information about the structure of the file can be found in [Section 3.5, Save EEPROM File](#).
- EXIT: returns to the **Sensor Settings** panel without additional changes.

## 4. Calibration Tool

By clicking **Calibration Tool** on the **Main** panel (see [Section 2](#)) several calibration methods can be selected (see [Fig. 4-18](#)).




**Fig. 4-18:** Calibration Methods

The **Calibration Method Selection** panel offers two options: two-point calibration or multi-point calibration. Inside each **Calibration** panel it is possible to switch between sensor 1 and sensor 2. The two-point calibration can be performed on two sensors in parallel.


### 4.1. Two-Point Calibration

This method is used to adjust the sensor to the exact range of the application. For linear current measurements this method can be used.



**Fig. 4-19:** Two-Point Calibration Panel


This calibration method starts with the dialog to set the setpoints of the active sensor (Sensor 1 and/or Sensor 2) to default values.



**Fig. 4-20:** Setting Linearization Parameters to Default

### Enter Target Output Values

The first step of a calibration is the selection of the target output values. SP\_CP1 is the desired setpoint value at the first calibration point (CP1) and SP\_CP2 is the desired setpoint value at the second calibration point (CP2). SP\_CP1 and SP\_CP2 are pre-defined to -31744 and 31744 and will be decreased during the calibration calculation if necessary. Target Value 1 is the desired output value at the first calibration point (CP1) and Target Value 2 is the desired output value at the second calibration point (CP2). The target output values can be entered in Counts.



**Fig. 4-21:** Example Target Output Values

### Calibration Procedure

First, set the target output values as described above.

When the magnetic field is at the first calibration point click Calibration Point 1. After reaching the second calibration point click Calibration Point 2.


By clicking Calculate, the appropriate parameters for the calibration are calculated. These include nmult, SP\_GAIN, SP\_OFFSET, OUT\_GAIN, and OUT\_OFFSET. If the values SP\_CP1 and SP\_CP2 are adapted during the calculation the new values will be displayed. The updated values of SP\_CP1 and SP\_CP2 must be noted and used in the Linearization Tool if additional linearization is needed.

By clicking Write & Store the calibrated values are written and stored in the registers.

Exit ends the calibration and returns to the **Main** panel.


## 4.2. Multi-Point Calibration

The multi-point calibration can be used to program any arbitrary output characteristic over the full measurement range using variable setpoints (see [Fig. 4-22](#)).



**Fig. 4-22:** Exemplary Multi-Point Calibration Characteristic

Therefore the panel allows the user to define the desired output behavior by adding calibration points manually or loading a text file (see [Fig. 4-23](#)). The file shall contain two tab-separated columns, one counting the number of the calibration points and one with the according output values in percentage of full scale. The maximum number of available calibration points is determined by the number of the 17 available variable setpoints. At least two calibration points have to be used for a successful calculation. The target values can be set arbitrarily (increasing, steady, or decreasing).




**Fig. 4-23:** Multi-Point Calibration Panel

After the desired output characteristic is defined the calibration procedure can be started:

1. Setting the first calibration point: Move the application to the first calibration point and click Set Calibration Point 1. The MIX\_OUT value is read at this position for further calculation. The green box next to the target value indicates when the reading is finished. The button changes the text to Set Calibration Point 2.
2. Setting the remaining calibration points: Repeat step 1 for all remaining calibration points. When all calibration points have been set, the button Calculate is released.
3. Calculating the signal path parameters: Click Calculate for calculation of the appropriate signal path parameters according to the desired output behavior (SP\_GAIN, SP\_OFFSET, SPn, OUT\_GAIN, and OUT\_OFFSET). The algorithm scales the signal path in a way that the variable setpoints are directly mapped to the calibration points. The outer setpoints with fixed setpoint x-values are set to fix values (SP0\_Y = -32768 and SP(n)\_Y = 32767; n = 18). Unused setpoints are distributed equidistantly on a linear connection between the last calibration point and the outer setpoint SP(n).
4. Programming the calculated parameters: Click Write Parameters to write and store the calculated signal path parameters to the sensor. After programming the registers are readout again and compared with the ideal values. In case of an error during programming the user is notified by a pop-up window.

## 5. Linearization Tool

The CUR 4000 features, depending on the setting, a different number of variable or fixed (equidistant/ non-equidistant) setpoints (see [Section 3.6](#)) to linearize the output of the sensor. The **Linearization Tool** is used to calculate the setpoints. By clicking **Linearization Tool** on the **Main** panel ([Fig. 2-1](#)) the **Linearization Tool** panel appears (see [Fig. 5-24](#)). The menu on top of the panel allows selecting the sensor (Sensor 1 or Sensor 2), when two sensors are connected.



**Fig. 5-24:** Linearization Tool Panel

At first, a saved text file with measurement information over the full application range has to be loaded via the button **Load Meas. File**. The text file shall contain at least a column with the measurement number or the current value information and a column with the corresponding **SETPOINT\_IN** register values (see [Table 5-3](#)). The (arbitrary) naming of the columns shall be located in the first row (header). The data has to be tab-separated. Such measurement file can be created with the **Measurement Tool** described in [Section 7](#). Once the measurement file was successfully loaded, the **Linearize** button is enabled.


**Table 5-3:** Example File

Current in A	SETPOINT_IN value in LSB
-1000	-31744
-990	-31482
-980	-31192
....	....


### Linearize

By clicking **Linearize** the correction function (setpoints) is calculated. The setpoints are scaled in a way that the first value of the input file matches **SP\_CP1** and the last value of the input file matches **SP\_CP2**.

The user can select between different graphs via the drop-down menu at the lower left corner of the graph: data graph or linearity error graph.

**Data Graph (default)****Fig. 5–25: Data Graph Display**

With this selection the graph shows three lines: the white line represents the input values read from the file, the green line is the calculated correction curve and the red line is the expected output after the linearization.

**Linearity Error Graph****Fig. 5–26: Linearity Error Graph**

When linearity error graph is selected, the graph displays the expected linearity error in percentage of the full scale.


After successful calculation of the linearization parameters the Write Setpoints button is released, which triggers writing and storing of the calculated setpoints to the sensor.

When Save to File is clicked, a file will be generated with the input for the linearization (position and the corresponding SETPOINT\_IN value), the ideal output, the calculated error and the calculated setpoints.

## 6. Development Mode

The Development Mode can be used to address single registers and to set some programmer board functions.

**Note:** The lock bit can be accidentally set in the Development Mode by writing to the SETUP\_FRONTEND register (EXT EEPROM: 0x0A). After the customer lock is activated (by writing and power-on-reset), it is not possible to program the sensor anymore.



**Fig. 6–27:** Development Mode Panel

The menu on top of the panel allows selecting the sensor (Sensor 1 or Sensor 2), when two sensors are connected to the programming device. When only one sensor is connected, no selection is possible.

The CUR 4000 has 96 EEPROM registers. They are split into 80 EEPROM registers and 16 EXT EEPROM registers (extended EEPROM registers). For a complete list of registers (including RAM and hardware registers), the user is referred to the memory tables of the application note “CUR 4000 User Manual”.


A register can be selected via entering the register address in the Address field or clicking on the Register field and selecting one register. In case of an extended EEPROM register is to be read or written, the EXT button has to be activated.

### Read

Clicking Read will read the register value. The register value is shown at the right hand side of the Read button.

### Write

Clicking Write will write the data entered at the right hand side of the Write button into the desired register and read back the register. The received register value is shown at the right hand side of the Read button.



**Fig. 6–28:** Write 12793 into EXT Register 10

**Note:** After using the Write button a power-on-reset is recommended to boot the sensor with the new customer setup parameters.

Left from the indicated or entered data a small d is visible. By clicking d the data can easily be converted into different number formats: hex (x), dec (d), octal (o), binary (b) and SI-spelling (p).

When entering a register value at the right hand side of the Write button it shall be taken care that the indicated format matches to the format of the entered value. Otherwise the wrong bits can be programmed.

### Set


Via the drop-down menu the user is able to insert MSP commands himself or select one of the implemented MSP commands. Clicking the Set button after writing or selecting a command will send the command to the MSP. The response is then shown below the drop-down menu. For detailed information about all MSP commands, please refer to the TDK Magnetic Sensor Programmer V1.x application note.

The following commands are implemented:

- Get Firmware Version reads out the firmware version of the TDK-MSP
- Get Bit Time reads out the current bit time for the Biphase communication protocol
- Set Bit Time sets the desired bit time for the Biphase communication protocol
- Measure VOUT measures the output voltage
- Measure VSUP measures the supply voltage
- Power-On-Reset switches the supply voltage off and on again
- Pull-up OFF/ON enables or disables the pull-up resistor (pull-up = 3.6 kΩ) of the programming device between output and supply voltage.

## 7. Measurement Tool

The **Measurement Tool** panel (see [Fig. 7–29](#)) can be accessed from the **Main** panel (see [Section 2](#)). This tool enables the user to stepwise read out certain RAM register values of the sensor's signal path, show the measurement result on a plot and save it to a text file. The created measurement data file can be used in the **Linearization Tool** (see [Section 5](#)).




**Fig. 7–29:** Measurement Tool Panel with One Connected Sensor

The sensor selection menu on top allows the user to choose between the connected sensors for the measurements. Available and selected sensors are marked with a green circle. A sensor can be excluded from the measurements by clicking the green circle, which will turn grey.

The **Measurement Tool** panel offers the following functionality:

- RAM Selection for the measurement: The user is able to select the desired RAM registers which have to be included into the measurement via the drop-down menus. To deselect a RAM Selection the drop-down menu has to be empty. Then the indication field next to the drop-down menu is disabled. For selected RAM registers the indication fields are enabled corresponding to the sensor selection.
- The RAM Selection for Measurement can be saved to a text file by clicking the Save button, set to default by clicking the Default button. A new RAM selection can be selected after clicking the New button and with the Load button it is possible to load an already saved RAM Selection Measurement file into the RAM Selection.
- The SETPOINT\_IN value can be used in the **Linearization Tool** (see [Section 5](#)). The other parameters can be used for analyzing the input field components.
- Measurements per Point: This number defines how often the selected RAM register values are read out before averaging during a measurement sequence or a single read-out. This is helpful to avoid noise errors during the measurement and leads to more reliable results whereas a higher number (e.g. 10) of measurement points also increases the measurement time.
- Read Selected: With this button a single read-out of the selected RAM registers will be triggered. The number of Measurements per Point determines how often each RAM register value is read out. The averaged results are displayed in the corresponding fields in the middle of the RAM selection area example. This function can be used to determine if MIX\_OUT is increasing or decreasing, when moving the application from the start position towards the end position, which is a required information for a calibration of the sensor (see [Section 4](#)).

- Show Measurement Plot: This option displays the Measurement Plot. During the measurement procedure the plot shows the activated RAM register values (see [Fig. 7-30](#)).
- Start Measurement: This button starts the measurement procedure. The user is asked to move the application stepwise through the application range and to confirm each position, which triggers several read-outs (defined by the number of measurements per point) of the selected RAM registers. Instead of confirming the next position the user can also decide to stop the measurement procedure or to repeat the last measurement point. If Show Measurement Plot has been enabled the measurement plot shows the selected RAM register values, which have been read out at every position and updates the plot after each confirmed position. For a following linearization of the output characteristic with the **Linearization Tool** (see [Section 5](#)) the first and last measurement points shall match the first and second calibration points used during two-point calibration (see [Section 4-21](#)). The total number of positions for the measurement can be arbitrary.
- Save Measurement: After the measurement procedure it is possible to save the measured values into a text file by clicking the Save Measurement button. The user is asked to select a text file for the storage of the measured data. The text file containing the measurement results is created properly formatted for the **Linearization Tool** (see [Section 5](#)).



**Fig. 7-30:** Activated Measurement Plot During a Typical Measurement Procedure

## 8. Application Note History

1. CUR 4000 Programming Environment, March 1, 2021; APN000181\_001EN.  
First release of the application note.
2. CUR 4000 Programming Environment, June 8, 2021; APN000181\_002EN.  
Second release of the application note.

Major Changes:

- Description in [Section 4.1](#) updated