



Application Notes

AN_435

FT602 UVC Chip Configuration Guide

Version 1.1

Issue Date: 2017-04-18

This document provides a guide on how to use the FT602 Chip Configuration Programmer application for customizing the chip configuration.

Use of FTDI devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold FTDI harmless from any and all damages, claims, suits or expense resulting from such use.

Table of Contents

1	Introduction	3
1.1	Pre-requisite	3
2	User Interface	4
3	Chip Configuration: Common Configuration	6
3.1	Buffer Configuration	8
4	Advance configuration Settings	9
4.1	Camera Terminal Controls	14
4.2	Processing Unit Control	17
5	Contact Information	21
Appendix A – References		22
Document References		22
Acronyms and Abbreviations		22
Appendix B – List of Tables & Figures		23
List of Tables		23
List of Figures		23
Appendix C – Revision History		24

1 Introduction

This document explains how to use the FT602 Series Chip Configuration Programmer, a utility application for customizing the chip configuration.

1.1 Pre-requisite

A PC running Windows 7 Operating System or later is required.

The PC should also be installed with the Microsoft Visual C++ 2013 Redistributable (x86) package. Follow the following steps to install it:-

1. Go to <https://www.microsoft.com/en-us/download/details.aspx?id=40784>
2. Click 'Download' button
3. Check the 'vcredist_x86.exe' and click 'Next'.
4. After download completes, run 'vcredist_x86.exe' to install the package

Install FT602 WinUSB driver:

1. Run 'FT602WinUSBInstallation.exe'
2. Click 'Extract' button
3. Check License Agreement and click 'Next'
4. Click 'Finish' button when the driver installation is completed.

2 User Interface

Below is a screenshot of the FT602 Chip Configuration Programmer application (Click 'Read Configuration' button first).




Figure 1 - Application Screenshot


The application allows the user to write and read the device configuration.

Main Buttons	Description
Write Configuration	The fields from the UI will be selected as a new configuration and written to the device.
Read Configuration	Clicking this button will show the current settings that the device is configured with.

Save To File	This option allows the user to save the configuration to a file.
Read From File.	This option allows the user to read a configuration from a file and populate the UI fields. Later if the user wishes to write this to the device, a "write configuration" can be done.

Table 1 - Main UI Controls Description

Channels pages of the FT602 Configuration Programmer application allow for setting buffer sizes and some advanced features.


Figure 2 – Channels Page

3 Chip Configuration: Common Configuration

Controls		Default Value	Description
Vendor ID		0x0403	Vendor identification as specified in the idVendor field of the USB Device Descriptor
Product ID		0x602D	Product identification as specified in the idProduct field of the USB Device Descriptor Default is 0x602D for 4 channels. This will be changed automatically as and when the number of channels configured has been changed.
Strings	Manufacturer	FTDI	Name of Manufacturer as specified in the USB Device Descriptor
	Product Description	FTDI SuperSpeed Video Bridge	Product name as specified in the USB Device Descriptor
	Serial Number	000000000001	Serial Number as specified in the USB Device Descriptor
	Channel Description	FTDI SuperSpeed Video Channel	Each channel is a function and each function can have its own string to differentiate it from the others. This option is available in the channels page of the application.
Bus-powered/Self-powered		Self-powered	Bus-powered or self-powered capability as specified in Bit 6 of the bmAttributes field of the USB Configuration Descriptor
Remote Wakeup		Disabled	Remote wakeup capability as specified in the bmAttributes field of the USB Configuration Descriptor
Max Power (SuperSpeed)		50 (mA)	Maximum power consumption derived from the bMaxPower field of the USB Configuration Descriptor. This value is equivalent to bMaxPower/8 if USB 3 and bMaxPower/2 if USB 2.
FIFO Clock		100 MHz	Clock speed of the FIFO in MHz
FIFO Mode		600 Mode	Mode of the FIFO (245 mode or 600 mode) Note that the FIFO mode selected should match the protocol used by the external FIFO master. Data transfer will not work if the FIFO protocol used

Controls	Default Value	Description
		does not match.
Channel Configuration	4 Channels	One channel is one UVC interface. When 4 channels are selected, there will be 4 UVC interfaces.
FIFO Buffer	4K (Per Channel)	Total size of the FIFO buffer is 16K. As 4 Channels are selected in default configuration the default FIFO buffer per channel is 4K. This option is available in the channels page.
Burst Buffer	4K (Per Channel)	Max Burst is 16K. Hence the default is 4K per channel as 4 channels are selected by default. This option is available in the channels page.
I2C Speed	1MHZ	Supports 1MHz, 400KHz and 100KHz. 1MHz is the default.
I2C Address	0x0D	I2C address
Interrupt Enabled.	Set	Enables an interrupt.
Interrupt Latency (bInterval)	9	Minimum latency is 2** $(bInterval-1)$ USB frames. Default value of 9, will give a latency of 2** $(9-1)$ USB frames. That is 256 frames. As 1 frame is 125us, this gives a latency of 32ms. bInterval can be modified to reduce or increase this latency. Minimum value is 1 and the max is 16.

Table 2 – User Configurable Common Configuration - Descriptions

Note: When calculating the maximum string length of a string descriptor the following rules must be applied:

Each string descriptor requires a 2 byte header therefore of the maximum 128 bytes there is $128-6=122$ bytes available.

As the data is sent in Unicode, this then divides down to $122/2=61$ bytes.

Additional restrictions are also applied:

Max size for SerialNumber is 16 characters

Max size for Description is 32 characters

Max size for Manufacturer is $61-32-16=13$ characters when Description and SerialNumber are maxed out.

3.1 Buffer Configuration

Whenever there is a channel configuration change, or FIFO buffer or burst buffer selection change, another configuration pop up will be shown so that buffers for all the channels can be configured at once.

NOTE: Whenever there is a change in buffer size, the total buffer size must be 16K. Otherwise the tool won't let the user program the configuration changes.

The picture below shows a configuration for two channels.




Figure 3 –Buffer Management

4 Advance configuration Settings

There are some advance settings available for expert users to configure the UVC terminal and processing controls.




Figure 4 –Advanced UVC Settings

Controls	type	Description
Camera Terminal Controls	Bitmap	<p>Refer to the USB Video Class 1.1 specification, section 3.7.2.3 Camera Terminal Descriptor for more details.</p> <p>This bitmap is used to enable or disable certain controls for the camera.</p> <p>When one of the read or write option is set, it indicates that the mentioned Control is supported for the video stream.</p> <p>When the 'Read' option is set, then all the GET control commands mentioned in the section 4.2.2 of the specification is supported. Similarly when the 'Write' option is set, SET command is supported.</p> <p>Following controls are available for user configuration.</p> <ul style="list-style-type: none"> ○ Auto-Exposure Mode ○ Auto-Exposure Priority ○ Exposure Time (Absolute) ○ Exposure Time (Relative) ○ Focus (Absolute) ○ Focus (Relative) ○ Iris (Absolute) ○ Iris (Relative) ○ Zoom (Absolute) ○ Zoom (Relative) ○ PanTilt (Absolute) ○ PanTilt (Relative) ○ Roll (Absolute) ○ Roll (Relative) ○ Focus, Auto
Processing Unit Controls	Bitmap (bmControls)	<p>Refer to the USB Video Class 1.1 specification, section 3.7.2.5 Processing Unit Descriptor for more details.</p> <p>This indicates the availability of certain processing Controls for the video stream.</p> <p>When any of the read or write option is set, it indicates that the mentioned Control is supported for the video stream.</p> <p>When the 'Read' option is set, then all the GET control commands mentioned in the section 4.2.2 of the specification is supported. Similarly when the 'Write' option is set, SET command is supported.</p> <p>Following controls are available for user configuration.</p> <ul style="list-style-type: none"> ○ Brightness ○ Contrast

Controls	type	Description
		<ul style="list-style-type: none"> ○ Hue ○ Saturation ○ Sharpness ○ Gamma ○ White Balance Temperature ○ White Balance Component ○ Backlight Compensation ○ Gain ○ Power Line Frequency ○ Hue, Auto ○ White Balance Temperature, Auto ○ White Balance Component, Auto ○ Digital Multiplier ○ Digital Multiplier Limit ○ Analog Video Standard
	Bitmap (bmVideoStandards)	<p>A bitmap of all analog video standards supported by the Processing Unit.</p> <p>A value of zero indicates that this bitmap should be ignored.</p> <p>Following options are available for user configuration.</p> <ul style="list-style-type: none"> ○ None ○ NTSC – 525/60 ○ PAL – 625/50 ○ SECAM – 625/50 ○ NTSC – 625/50 ○ PAL – 525/60
Frame Info	Resolution	Width * Height in pixels.
	Frame Interval	This value indicates the number of frames per second. For example, for a 60fps, the value should be 60.
	Color Primaries	<p>This defines the color primaries and the reference white.</p> <p>Following options are available to choose.</p> <p>0: Unspecified (Image characteristics unknown) 1: BT.709, sRGB (default) 2: BT.470-2 (M) 3: BT.470-2 (B, G) 4: SMPTE 170M 5: SMPTE 240M</p> <p>Please refer to 3.9.2.6 Color Matching Descriptor of UVC specification 1.1.</p>

Controls	type	Description
	Transfer Characteristics	<p>This field defines the optoelectronic transfer characteristic of the source picture also called the gamma function.</p> <p>Following options are available for selection.</p> <p>0: Unspecified (Image characteristics unknown) 1: BT.709 (default) 2: BT.470-2 M 3: BT.470-2 B, G 4: SMPTE 170M 5: SMPTE 240M 6: Linear ($V = L_c$) 7: sRGB (very similar to BT.709)</p> <p>Refer to 3.9.2.6 Color Matching Descriptor of UVC specification 1.1.</p>
	Matrix Coefficients	<p>Matrix used to compute luma and chroma values from the color primaries.</p> <p>0: Unspecified (Image characteristics unknown) 1: BT. 709 2: FCC 3: BT.470-2 B, G 4: SMPTE 170M (BT.601, default) 5: SMPTE 240M</p> <p>Refer to 3.9.2.6 Color Matching Descriptor of UVC specification 1.1.</p>
	FCC (Four Character Code).	<p>It's a sequence of 4 bytes used to uniquely identify data formats.</p> <p>Please visit http://www.fourcc.org/ for more information.</p> <p>Following option formats are available.</p> <ul style="list-style-type: none"> ○ YUY2 ○ YUYV ○ Y41P ○ YUVP ○ YUV4 ○ IYU2 ○ AYUV ○ NV12 ○ NV16

Controls	type	Description
		<ul style="list-style-type: none"><input type="radio"/> NV24<input type="radio"/> YV12<input type="radio"/> GREY<input type="radio"/> Y16<input type="radio"/> RGBP<input type="radio"/> RGB3<input type="radio"/> RGB4<input type="radio"/> BA24<input type="radio"/> BY8<input type="radio"/> BYR2
	Bits Per Pixel (Read only)	This is read only. And gets generated based on the FCC selected.

Table 3 – Camera Terminal, Processing Unit & Frame Information

4.1 Camera Terminal Controls

A separate tab named “*Camera Setting config*” is provided in the tool in the channels page .This allows the user to define the default values, steps (Resolution), min and max values of each control.

Refer to the section 4.2.2.1 Camera Terminal Control Requests of UVC specification 1.1.




Figure 5 –Camera Terminal Configurable Options

The table below shows each configurable control where the user is allowed to define the values.

Controls	Description
Exposure Time (Absolute)	<p>Refer to Section 4.2.2.1.4 Exposure Time (Absolute) Control of UVC 1.1 for more information.</p> <p>The Exposure Time (Absolute) Control is used to specify the length of exposure. This value is expressed in 100μs units, where 1 is 1/10,000th of a second, 10,000 is 1 second, and 100,000 are 10 seconds. A value of zero (0) is undefined. Note that the manual exposure control is further limited by the frame interval, which always has higher precedence. If the frame interval is changed to a value below the current value of the Exposure Control, the Exposure Control value will automatically be changed. The default Exposure Control value will be the current frame interval until an explicit exposure value is chosen</p> <p>The setting for the attribute of the addressed Exposure Time (Absolute) Control:</p> <p>0: Reserved</p> <p>1: 0.0001 sec</p> <p>...</p> <p>100000: 10 sec</p> <p>...</p>
Focus (Absolute)	<p>Refer to section 4.2.2.1.6 Focus (Absolute) Control of UVC 1.1 for more information.</p> <p>The Focus (Absolute) Control is used to specify the distance to the optimally focused target. This value is expressed in millimeters. The default value is implementation-specific.</p>
Iris (Absolute)	<p>Refer to section 4.2.2.1.9 Iris (Absolute) Control of UVC 1.1 The Iris (Absolute) Control is used to specify the camera's aperture setting. This value is expressed in units of $f_{stop} \times 100$. The default value is implementation-specific.</p>
Objective Focal Length / Zoom (Absolute)	<p>Refer to the section 4.2.2.1.11 Zoom (Absolute) Control of UVC 1.1 The Zoom (Absolute) Control is used to specify or determine the Objective lens focal length. This control is used in combination with the wObjectiveFocalLengthMin and wObjectiveFocalLengthMax fields in the Camera Terminal descriptor to describe and control the Objective lens focal length of the device (see section 2.4.2.5.1 "Optical Zoom"). The MIN and MAX values are sufficient to imply the resolution, so the RES(steps) value must always be 1. The MIN, MAX and default values are implementation dependent.</p>

Controls	Description
Pan (Absolute)	Refer to section 4.2.2.1.13 PanTilt (Absolute) Control of UVC 1.1. The dwPanAbsolute is used to specify the pan setting in arc second units. 1 arc second is 1/3600 of a degree. Values range from -180*3600 arc second to +180*3600 arc second, or a subset thereof, with the default set to zero. Positive values are clockwise from the origin (the camera rotates clockwise when viewed from above), and negative values are counterclockwise from the origin.
Tilt (Absolute)	Refer to section 4.2.2.1.13 PanTilt (Absolute) Control of UVC 1.1 for more information. The dwTiltAbsolute Control is used to specify the tilt setting in arc second units. 1 arc second is 1/3600 of a degree. Values range from -180*3600 arc second to +180*3600 arc second, or a subset thereof, with the default set to zero. Positive values point the imaging plane up, and negative values point the imaging plane down
Roll (Absolute)	Refer to section 4.2.2.1.15 Roll (Absolute) Control of UVC 1.1 for more information. The Roll (Absolute) Control is used to specify the roll setting in degrees. Values range from -180 to +180, or a subset thereof, with the default being set to zero. Positive values cause a clockwise rotation of the camera along the image viewing axis, and negative values cause a counterclockwise rotation of the camera.

Table 4 – Camera Terminal Control Options

4.2 Processing Unit Control

A separate tab named “*Processing Unit config*” is provided in the tool in the channels page. This allows the user to define the default values, steps (Resolution), min and max values of each control.

Refer to section 4.2.2.3 Processing Unit Control Requests of the UVC specification 1.1.




Figure 6 –Processing Unit Control Options

The following table presents a detailed description of all possible Controls a Processing Unit can incorporate. For each Control, the layout of the parameter block together with the appropriate Control Selector is listed for all forms of the Get/Set Processing Unit Control request. All values are interpreted as unsigned unless otherwise specified.

Controls	Description
Backlight compensation	<p>Refer to section 4.2.2.3.1 Backlight Compensation Control of the UVC spec 1.1 for more information. The Backlight Compensation Control is used to specify the backlight compensation. A value of zero indicates that the backlight compensation is disabled. A non-zero value indicates that the backlight compensation is enabled. The device may support a range of values, or simply a binary switch. If a range is supported, a low number indicates the least amount of backlight compensation. The default value is implementation-specific, but enabling backlight compensation is recommended.</p>
Brightness	<p>Refer to section 4.2.2.3.2 Brightness Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the brightness. This is a relative value where increasing values indicate increasing brightness. The MIN and MAX values are sufficient to imply the resolution, so the RES value must always be 1. The MIN, MAX and default values are implementation dependent.</p>
Contrast	<p>Refer to section 4.2.2.3.3 Contrast Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the contrast value. This is a relative value where increasing values indicate increasing contrast. The MIN and MAX values are sufficient to imply the resolution, so the RES value must always be 1. The MIN, MAX and default values are implementation dependent.</p>
Gain	<p>Refer to section 4.2.2.3.4 Gain Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the gain setting. This is a relative value where increasing values indicate increasing gain. The MIN and MAX values are sufficient to imply the resolution, so the RES value must always be 1. The MIN, MAX and default values are implementation dependent.</p>
Hue	<p>Refer to section 4.2.2.3.6 Hue Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the hue setting. The value of the hue setting is expressed in degrees multiplied by 100. The required range must be a subset of -18000 to 18000 (-180 to +180 degrees). The default value must be zero.</p>
Saturation	<p>Refer to section 4.2.2.3.8 Saturation Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the saturation setting. This is a relative value where increasing values indicate increasing saturation. A Saturation value of 0 indicates grayscale. The MIN and MAX values are</p>

Controls	Description
	<p>sufficient to imply the resolution, so the RES value must always be 1.</p> <p>The MIN, MAX and default values are implementation-dependent</p>
Sharpness	<p>Refer to section 4.2.2.3.9 Sharpness Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the sharpness setting. This is a relative value where increasing values indicate increasing sharpness, and the MIN value always implies "no sharpness processing", where the device will not process the video image to sharpen edges. The MIN and MAX values are sufficient to imply the resolution, so the RES value must always be 1. The MIN, MAX and default values are implementation-dependent</p>
Gamma	<p>Refer to section 4.2.2.3.10 Gamma Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the gamma setting. The value of the gamma setting is expressed in gamma multiplied by 100. The required range must be a subset of 1 to 500, and the default values are typically 100 (gamma = 1) or 220 (gamma = 2.2).</p>
White Balance Temperature	<p>Refer to the section 4.2.2.3.11 White Balance Temperature Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the white balance setting as a color temperature in degrees Kelvin. This is offered as an alternative to the White Balance Component control. Minimum range should be 2800 (incandescent) to 6500 (daylight) for webcams and dual-mode cameras. The supported range and default value for white balance temperature is implementation-dependent.</p>
White Balance Blue	<p>Refer to section 4.2.2.3.13 White Balance Component Control of the UVC spec 1.1 for more information.</p> <p>The setting for the blue component of the addressed White Balance Component control.</p>
White Balance Red	<p>Refer to section 4.2.2.3.13 White Balance Component Control of the UVC spec 1.1 for more information.</p> <p>The setting for the red component of the addressed White Balance Component control.</p>

Controls	Description
Digital Multiplier Step	<p>Refer to section 4.2.2.3.15 Digital Multiplier Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify the amount of Digital Zoom applied to the optical image. This is the position within the range of possible values of multiplier m, allowing the multiplier resolution to be described by the device implementation. The MIN and MAX values are sufficient to imply the resolution, so the RES value must always be 1. The MIN, MAX and default values are implementation dependent. If the Digital Multiplier Limit Control is supported, the MIN and MAX values shall match the MIN and MAX values of the Digital Multiplier Control.</p>
Digital Multiplier Limit	<p>Refer to section 4.2.2.3.16 Digital Multiplier Limit Control of the UVC spec 1.1 for more information.</p> <p>This is used to specify an upper limit for the amount of Digital Zoom applied to the optical image. This is the maximum position within the range of possible values of multiplier m. The MIN and MAX values are sufficient to imply the resolution, so the RES value must always be 1. The MIN, MAX and default values are implementation dependent.</p> <p>A value specifying the upper bound for Z'cur (see section 2.4.2.5.2 "Digital Zoom" of UVC spec 1.1.)</p>
Power Line Frequency	<p>Refer to the section 4.2.2.3.5 Power Line Frequency Control of the UVC spec 1.1 for more information.</p> <p>This control allows the host software to specify the local power line frequency, in order for the device to properly implement anti-flicker processing, if supported. The default is implementation-specific.</p> <p>The setting for the attribute of the addressed Power Line Frequency control:</p> <ul style="list-style-type: none"> 0: Disabled 1: 50 Hz 2: 60 Hz

Table 5 – Processing Control & Description

Appendix B – List of Tables & Figures

List of Tables

Table 1 - Main UI Controls Description	5
Table 2 – User Configurable Common Configuration - Descriptions	7
Table 3 – Camera Terminal, Processing Unit & Frame Information	13
Table 4 – Camera Terminal Control Options	16
Table 5 – Processing Control & Description	20

List of Figures

Figure 1 - Application Screenshot	4
Figure 2 – Channels Page	5
Figure 3 – Buffer Management	8
Figure 4 – Advanced UVC Settings	9
Figure 5 – Camera Terminal Configurable Options	14
Figure 6 – Processing Unit Control Options	17